

WELD TESTER

MM-315B-00-1  

OPERATION MANUAL



Thank you for purchasing our Weld Tester **MM-315B-00-1□**.

Please read this manual carefully to ensure correct use. Keep the manual handy after reading for future reference.

Contents

1. Special Notes.....	1-1
(1) Safety Precautions	1-1
(2) Precautions for Handling.....	1-4
(3) On Disposal	1-6
2. Features	2-1
3. Packing List	3-1
(1) Main Body and Accessories.....	3-1
(2) Options.....	3-1
4. Names and Functions of Parts of the Weld Tester.....	4-1
5. Measurement	5-1
(1) Setting the Toroidal Coil.....	5-1
(2) Supplying Power	5-2
(3) Checking Measurement Setting	5-3
(4) Measurement Settings	5-4
a. Range Setting	5-4
b. Impulse No. Setting.....	5-5
c. Setting of the First Cycle	5-8
d. Setting of the Last Cycle	5-9
(5) Checking Conduction Degrees	5-10
(6) Current Measurement of Inverter Welders	5-11
(7) All Impulse Memory	5-13
(8) Display in Unit of Half Cycle.....	5-16
(9) Forced Measurement Cycle	5-16
(10) Overflow Display	5-16
6. Button and Functions	6-1
7. Specifications	7-1
8. Outline Drawing	8-1
9. Charging the Battery	9-1
(1) Connecting the Unit and Charger.....	9-1
(2) When should the Unit be Recharged	9-1
(3) Measurement during Recharging.....	9-1
(4) Service Life of the Nickel-Hydrogen Batteries.....	9-2
(5) Replacing the Nickel-Hydrogen Batteries.....	9-2
10. Calibration.....	10-1

1. Special Notes

(1) Safety Precautions

Prior to use, read these "Safety Precautions" carefully to gain a full understanding of the proper method of use.

- The precautions listed here are designed to ensure safe use and proactively prevent risks and damage to the user and other people.
- All precautions are critical for safety. Please read them all.
- The hazard signs have the following meanings:

 DANGER	Indicates a high risk of death or serious injury if precautions are not correctly observed.
 WARNING	Indicates a risk of death or serious injury if precautions are not correctly observed.
 CAUTION	Mishandling may cause risk of injury and physical damage.
	These symbols indicate "prohibition." They are warnings concerning actions out of the scope of the warranty of the product.
	These symbols indicate actions that operators must take.
	Each symbol with a triangle indicates a DANGER, WARNING, or CAUTION to the operator.

**DANGER****Never disassemble, repair or modify the device.**

These actions can cause electric shock and fire. Consult us or your distributor for battery replacement, inspection and repair.

**Never burn, destroy, cut, crush or chemically decompose the device.**

This product incorporates parts containing gallium arsenide (GaAs).

**WARNING****Do not insert your fingers or hands between the electrodes.**

When welding, keep your fingers and hands away from the electrodes.

**Do not touch any welded part or electrode during welding or just after completion of welding.**

The welded parts of a workpiece, electrodes, and the arm are very hot. Do not touch them; burns may result.

**Apply the specified supply voltage.**

Application of a voltage outside the specified range may result in fire or electric shock.

**Use the specified cables and connect them securely.**

Failure to do so or improper connection may result in a fire or electric shock.

**Keep the power and connection cables free of damage.**

Do not walk on, twist or tug the cables.
Damaged cable may result in an electric shock, short circuit, or fire.
For repair or replacement, consult us or your distributor.

**Stop the operation if any trouble occurs.**

Continuous operation after occurrence of a trouble such as burning smell, abnormal sound, abnormal heat, smoke, etc. can cause electric shock and fire. If such a trouble occurs, immediately consult us or your distributor.

**Persons with pacemakers must stay clear of the welding machine.**

A person who uses a pacemaker must not approach the welding machine or walk around the welding shop while the welding machine is in operation, without being permitted by his/her doctor. The welding machine generates a magnetic field and has effects on the operation of the pacemaker while it is turned on.

**Protective gear must be worn.**

Put on protective gear such as protective gloves, long-sleeve jacket, leather apron, etc. Spatters can burn the skin if they touch the skin.

**Wear protective glasses.**

If you look at the flash directly during welding, your eyes may be damaged. If any spatter gets in your eye, you may lose your eyesight.

**CAUTION****Do not expose to water or other liquid.**

Exposing electrical components to water or other liquid may result in electric shock or short-circuiting.

**Keep combustible matter away from the device.**

Spatter may ignite combustible matter. If it is impossible to remove all combustible matter, cover it with non-combustible material.

**Do not cover the device with a blanket, cloth, etc.**

Do not cover the device with a blanket, cloth, etc. while it is in use. The cover may be overheated and burned.

**Wipe off dust from the power plug and securely insert it all the way.**

Dust or improper insertion may lead to the plug heat up and catch fire.

**Hold the power plug when removing or inserting it.**

Removing the power plug by pulling on the cable may damage the power cable, resulting in an electric shock or causing the cable to catch fire.

**If you do not use the device for extended periods, remove the power plug from the outlet.**

Failure to do so may deteriorate the insulation, resulting in an electric shock, current leakage or fire.

**Keep a fire extinguisher nearby.**

Keep a fire extinguisher in the welding shop in case of fire.

**Maintain and inspect the device periodically.**

Maintain and inspect the device periodically, and repair any damage nearby before starting operation.


**Use ear protectors.**

Loud noises can damage hearing.


(2) Precautions for Handling

- Avoid the following locations when installing the device:
 - Humid location (humidity of above 90%)
 - Extremely hot (above 40°C) or cold (below 0°C) locations
 - Near a high noise source
 - Location where chemical substances, etc. are handled
 - Location where condensation occurs
 - Dusty location
 - Location exposed to direct sunlight
 - Location that is inclined, insecure, unstable, or weak
- Check the voltage and power frequency before installation.
- Keep the exterior clean with a soft cloth or cloth lightly dampened with water. For stains, clean them off using a diluted neutral detergent or alcohol.


Do not use thinner or benzene as they may cause discoloration or deformation.
- To prevent malfunction, do not allow any foreign objects such as screws or coins to enter the device.
- Operate the device according to the procedure described in the Operation Manual.
- Operate the buttons with care. Rough operation or the use of a tool or pen tip may result in damage or malfunction.
- Use fully charged batteries. Even if the display does not prompt you to charge the batteries, using batteries that are not fully charged may result in degraded measurement accuracy. (Before using the tester for the first time, always charge the batteries.)
- Use only the included or specified chargers.




- Do not charge for more than 48 hours.




- Do not short-circuit the plug while the charger is connected to an outlet.




- Do not short-circuit the connector of the charger using a screwdriver, etc.




- Do not use the accessory charger for any unit other than the **MM-315B-00-1** □.




- Remove the charger from the outlet when it is not in use.



- Even if the unit is not used for an extended period, charge it once every six months.



- Do not use disposable alkaline batteries.



(3) On Disposal

This product incorporates parts containing gallium arsenide (GaAs). At the time of disposal, separate it from general industrial waste or domestic waste and carry out the disposal in accordance with applicable laws and regulations.

2. Features

The **MM-315B-00-1** □ Weld Tester is a handheld instrument for measuring weld current.

- Battery-driven type. Can be used anywhere freely.
- Small and light design for ease of use.
- Current, cycle and conduction degrees can be measured by connecting a toroidal coil (sold separately).
- Multi-step weld memory function.

3. Packing List

Check the contents of the package. In the case of damaged or missing items, please contact us.

(1) Main Body and Accessories

Item		Model	Qty
Main body		MM-315B-00-1 □	1
Charger	MM-315B-00-10/12	UU311-7516	1
	MM-315B-00-15 ^{*1}	-	-
Power plug for overseas, C type (MM-315B-00-12 only)		WP-3	1
Leather case		PC1212359	1
Carrying case		A3-02977	1
Japanese panel seal ^{*2}		P-0493	1
Operation manual		AS1212372(OM1212374,OM1212375)	1

*1 The **MM-315B-00-15** does not come with a charger. Use a charger with the following specifications.


Output: 7 V±10%, 100 mA minimum

Polarity: Negative Center


*2 The Japanese panel seal is for adding Japanese signage on the panel display.
Put the seal on the panel sheet.

(2) Options

Item	Model
Toroidal coil	MB-500-15-00



4. Names and Functions of Parts of the Weld Tester



5. Measurement


CAUTION

- Prior to using the tester for the first time, be sure to charge the batteries, which may not be sufficiently charged immediately after purchase. Refer to “Chapter 9 Charging the battery” for the battery-changing procedure.
- Measure an alternating current in AC mode and a direct current in DC mode. Accurate measurements may not be made in an improper mode.

Measure the weld current, using this instrument.

(1) Setting the Toroidal Coil


Mount the coil on the welder as shown below, and connect the cord to the connector of the **MM-315B-00-1□**.



The toroidal coil is calibrated at the center.


Line up the ends of the coil, and fasten both ends using the Velcro strips.

DO




Match up the ends of the coil


DO NOT



Cross the coil



Fasten with tape



CAUTION

- To the extent possible, use the toroidal coil without changing its shape. Bending and unbending it repeatedly may result in breakage of the internal wires.

(2) Supplying Power

Press the
ON button.

5	0	H	z		A	C	
---	---	---	---	--	---	---	--

The measurement conditions are displayed for 0.7 seconds, and then the unit buttons to the initial display. The above display shows the unit set at 50 Hz AC. When it is set to 60 Hz DC, the display shows the following:

6	0	H	z		D	C	
---	---	---	---	--	---	---	--

<Initial display>

CURR./DEG.					TIME		
0	.	0	0	K	0	0	C
Current value					Cycle value		

K refers to kA (used to measure current values), and C means CYCLES.

The position of the decimal point indicates that the Low range (the 9.99-kA range) has been selected. For DC welding, when measurement in seconds (SEC) has been selected, the following display appears:


CURR./DEG.					TIME		
0	.	0	0	K	.	0	0
Current value					Seconds		

Time is measured in seconds.

After switching , when the initial display is shown, the unit is ready for measurement. The measurement schedules are those set before the OFF button was pressed. The weld current can be measured when the initial display is shown. If the initial display is shown after the unit has been turned on, the unit is ready for measurement. When the impulse No. is 0, all impulses are monitored.

When the weld current is to be measured after the measurement schedules are checked and set as specified in "Chapter 4 (3)", "Chapter 4 (4)", press the

 button to show the initial display.



(3) Checking Measurement Setting


Measurement setting can be checked as follows.

Press the  button.	The following display appears:					
	L	o			0	0 1
	RANGE		IMPULSE NO.		FIRST CYC.	
	RANGE				FIRST CYCLE --- First cycle to be measured. 1-99 cycles	
					IMPULSE NO.--- Number of impulses to be measured. Shows all impulses when set to 0.	
					Lo: 9.99-kA range Hi: 49.9-kA range	

Above, the Low range and Impulse No. 0 are shown, and the First Cycle is 1.

The above display will be shown when the  or  button is pushed. In addition, when the , , or  button is pushed, the setting of each can be checked. To change these settings, follow the procedures specified in "Chapter 4 (4)". Item buttons are only for checking measurement schedules.

To measure the weld current, press the  button to show the initial display.



(4) Measurement Settings

Measurement values can be set as follows.

To set the measurement values, use the **RANGE**, **IMPULSE NO.**, and **FIRST CYC.** buttons (white) to select each mode. Use the **+** and **-** buttons to set data.

a. Range Setting

The cursor is in the Lo range, at Chapter 4 (3), indicating that this mode can be set. Press **+** in this situation.


Press + .	<table border="1"> <tr> <td>H</td> <td>i</td> <td></td> <td></td> <td>0</td> <td></td> <td>0</td> <td>1</td> </tr> <tr> <td colspan="2">RANGE</td> <td colspan="2">IMPULSE NO.</td> <td colspan="4">FIRST CYC.</td> </tr> </table>	H	i			0		0	1	RANGE		IMPULSE NO.		FIRST CYC.			
H	i			0		0	1										
RANGE		IMPULSE NO.		FIRST CYC.													

The range display changes from Lo to Hi, indicating that the 49.9-kA range has been selected. Next, press the **-** button.

Press - .	<table border="1"> <tr> <td>L</td> <td>o</td> <td></td> <td></td> <td>0</td> <td></td> <td>0</td> <td>1</td> </tr> <tr> <td colspan="2">RANGE</td> <td colspan="2">IMPULSE NO.</td> <td colspan="4">FIRST CYC.</td> </tr> </table> The range changes to Lo again.	L	o			0		0	1	RANGE		IMPULSE NO.		FIRST CYC.			
L	o			0		0	1										
RANGE		IMPULSE NO.		FIRST CYC.													

Current Ranges:

Lo range:	1.00 kA - 9.99 kA
Hi range:	5.0 kA - 49.9 kA



b. Impulse No. Setting

To set the Impulse No. to 1, press



Press 	<table border="1"><tr><td>L</td><td>o</td><td></td><td></td><td> 0 </td><td></td><td>0</td><td>1</td></tr></table> RANGE IMPULSE NO. FIRST CYC. Cursor moves to IMPULSE NO.	L	o			0		0	1
L	o			0		0	1		

Next, press the



button.

Press  .	<table><tr><td>L</td><td>o</td><td></td><td></td><td><u>1</u></td><td></td><td>0</td><td>1</td></tr></table> The Impulse No. becomes 1.	L	o			<u>1</u>		0	1
L	o			<u>1</u>		0	1		

The Impulse No. is set to 1. Hold down the



button until the figure reaches 9.

Press +.

L	o			1		0	1
---	---	--	--	---	--	---	---

↓

L	o			2		0	1
---	---	--	--	---	--	---	---

⋮

L	o			9		0	1
---	---	--	--	---	--	---	---

The number increases to 9.

To return to 1, press the



button. Hold down the



button until the figure reaches 1.

Press .

L	o			9		0	1
---	---	--	--	---	--	---	---

↓

L	o			8		0	1
---	---	--	--	---	--	---	---

⋮

L	o			1		0	1
---	---	--	--	---	--	---	---

The Impulse No. becomes 1.

NOTE1. Impulse No. Setting and DisplayWhen the Impulse No. is 0

When the Impulse No. is 0, the display will disappear to signal the start of the welding, and the instrument monitors all impulses.


For example, suppose the following settings were used to monitor the weld shown below.

Setting

L	o			0		0	1
---	---	--	--	---	--	---	---

FIRST CYC.

IMPULSE NO. 0

Weld Pattern

When the Impulse No. is 0, I will monitor all currents.


When the Impulse No. is 1-9

The display shows the information only for the number that has been set when the Impulse No. is 1 to 9. For example, when the Imp. No. is set to 2 and the weld pattern is the same as Imp. No. 0, the following is displayed:

Setting

L	o			2		0	1
---	---	--	--	---	--	---	---

└─ Impulse No. 2


Weld Pattern

When the  button is pressed for measurement, and there is no impulse for the number set,

*	S	E	T		E	R	R
---	---	---	---	--	---	---	---

is displayed. As to judgment of the Impulse No., refer to All Impulse Memory in "Chapter 5 (7)".

When the Impulse No. is 1 - 9, I will monitor only the selected impulse.



c. Setting of the First Cycle

Now press the  button.

Press  .	L	o		0	1		0	1


The cursor moves to FIRST CYC. Press  and set the First Cycle to 3.

Press  .	L	o		0	1		0	1
	L	o		0	1		0	2
L	o		0	1		0	3	

The First Cycle is set to the 3rd cycle.

To measure weld the current, press the  button to show the initial display.

When the First Cycle is set to 3, if the following current is supplied, the measured interval will be as follows:



$$\frac{\text{Displayed current}}{\text{Average true values}} = \frac{I_{31} + I_{32} + I_{41} + I_{42} + I_{51} + I_{52} + I_{61} + I_{62}}{8}$$

Measurement starts at the third cycle; the first and second cycles are ignored. With the above procedure, measurement settings are complete.

To measure the weld current, be sure to press the  button to show the initial display.

d. Setting of the Last Cycle

You can select whether to include the Last Cycle when measuring the weld current.

First, press the  button.

Press  .	<table border="1"> <tr> <td>L</td><td>o</td><td></td><td>0</td><td>1</td><td></td><td>0</td><td>1</td> </tr> </table>	L	o		0	1		0	1
L	o		0	1		0	1		

The cursor moves to FIRST CYC.

Next, hold down the  button for three seconds. The display shows the following for two seconds and returns. Hold down this button for three seconds to switch between LAST OFF and LAST ON.

Hold down  for three seconds.	<table border="1"> <tr> <td>L</td><td>A</td><td>S</td><td>T</td><td></td><td>O</td><td>F</td><td>F</td> </tr> </table>	L	A	S	T		O	F	F
	L	A	S	T		O	F	F	
or <table border="1"> <tr> <td>L</td><td>A</td><td>S</td><td>T</td><td></td><td>O</td><td>N</td><td></td> </tr> </table>	L	A	S	T		O	N		
L	A	S	T		O	N			

LAST OFF: Does not include the Last Cycle.

LAST ON: Includes the Last Cycle.

To measure the weld current, be sure to press the  button to show the initial display.

(5) Checking Conduction Degrees

After the weld current is measured, press $\frac{\text{CURR.}}{\text{DEG.}}$ while the current value is displayed. The conduction degrees can be checked.

Press $\frac{\text{CURR.}}{\text{DEG.}}$	<table border="1"> <tr> <td>5</td><td>.</td><td>5</td><td>0</td><td>K</td><td>1</td><td>0</td><td>C</td> </tr> </table> The Current and Cycles are shown.	5	.	5	0	K	1	0	C
	5	.	5	0	K	1	0	C	
<table border="1"> <tr> <td>1</td><td>0</td><td>6</td><td>°</td><td></td><td>1</td><td>0</td><td>C</td> </tr> </table> The conduction degrees are shown.	1	0	6	°		1	0	C	
1	0	6	°		1	0	C		

Press $\frac{\text{CURR.}}{\text{DEG.}}$ again; the current and cycle values are shown. The current and conduction degrees are measured at the same time. Be sure to check both displays by pressing $\frac{\text{CURR.}}{\text{DEG.}}$.


In DC measurement, the conduction degrees will be as follows:

*	*	*	°		1	0	C
---	---	---	---	--	---	---	---

In DC measurement, the conduction degrees are shown.

About Conduction Degrees:

For single-phase AC welders, waveforms A and B, which have the same RMS value, are shown below.





Though the RMS current values are the same, the time during which the current doesn't flow differs (TA in A, TB in B).

This causes the heated workpiece to cool. In other words, A is more likely to produce spatter-free, high-quality welds due to the shorter period of time with no current flow. On the other hand, with B, the welding transformer has a greater remaining capacity, so the weld current can be increased.

(6) Current Measurement of Inverter Welders

Current measurement of inverter welders is described here.

First, press the  button.

Press  .	A <u>C</u> The present setting is shown.
---	--

Press  to enter DC mode.

Press  .	D <u>C</u>
---	---

Next, press the CYC./SEC. button to show the time-display SEC.

Press  .	C Y C <u>—</u>
---	---

Press ; SEC is shown.

Press  .	S E C <u>—</u>
---	---

Now, the time display will be 0.00 seconds when the  button is pressed.

The  button does not function when the unit is not in DC mode.

Next, it is time to set the start of measurement.

Press the  button.

Press  .	L o 1 0 <u>1</u>
---	---


With the above procedure, setting of the measurement conditions is complete.

To measure the current, press the  button to show the initial display.

When the time shows SEC (seconds), the weld time is divided into 10-ms blocks from the start of the weld, and the number in FIRST CYC shows at which block the measurement begins as shown in the figure below.

For example, when this number is set to 2, the measurement interval is as shown below.

The blocks from 2 on will be measured.



$$\frac{\text{Displayed current values}}{\text{Average true values}} = \frac{I_2 + I_3 + I_4}{3}$$

In the case of DC measurement, when I_5 becomes less than 75% of I_4 , measurement is complete.

Measured readout	<table><tr><td>4</td><td>.</td><td>5</td><td>0</td><td>K</td><td>.</td><td>0</td><td>4</td></tr></table>	4	.	5	0	K	.	0	4
4	.	5	0	K	.	0	4		


The above shows a current value of 4.50 kA, and a weld time of 0.04 seconds (40 ms).

(7) All Impulse Memory

Storing data:

The **MM-315B-00-1□** is able to store up to 9 pulsations with more than 1 cool cycle in the memory.

Weld pattern




The following table shows the weld pattern:

Display Impulse No.	Current	Time	Conduction Degrees
1	2.45 kA	3 cycles	84
2	7.21 kA	4 cycles	137
3	5.50 kA	2 cycles	118


The unit stores current, time, and conduction-degree values in its memory for up to 9 pulses.

Those from 10 on are not stored.

In addition, when the interval between impulses is more than 0.5 seconds, the following weld is considered Impulse No. 1 and stored.




The basis for determining Impulse 1 is as follows:



All previous memory information is cleared when the power is shut off or a new weld is performed.


Confirmation of All Impulse Memory

After the weld is performed using the previous weld schedule, press the  button.




The Impulse No. 1 current value is shown.

To check the time, press  again.



The cycle value of Impulse No. 1 is shown.

To check the conduction degrees, press  again.




The conduction degrees of Impulse No. 1 are shown.

By using the  and  buttons, the Impulse No. can be changed and the values checked.

In other words, the  button is used to select the current, time, and conduction-degree displays. The  and  buttons are used to set the impulse No.

Search for the spot to be displayed using the MR, +, and - buttons.



Select display
by MR.


Set the Impulse
No. using the
+ and
- buttons.

Press the



button to measure the current.

Use the MR button to move across the table, and the - | + buttons to move up and down the table.



(8) Display in Unit of Half Cycle

A half-cycle weld is indicated by adding a decimal point to the left of the cycle symbol C. The point indicates 0.5 cycles, such as when a 12.5-cycle weld is performed, the display will be as follows:


8	.	5	0	K	1	2	.C
---	---	---	---	---	---	---	----

The decimal point indicates 0.5 cycles.

(9) Forced Measurement Cycle

If a current value is low in the early period of welding, it may not be measured. (It tends to occur when an upslope is used.)

In this case, set a current higher than the level at the end of measurement in the setting cycle of NCT. Once a current higher than the level at the end of measurement flows, the setting of NCT becomes invalid, and the measurement is complete with a current lower than the level at the end of measurement.



(10) Overflow Display

When the measured current values exceed the maximum setting range, the overflow mark (↑) will be displayed. In addition, when the time exceeds 99 cycles in AC and 40 cycles in DC, the overflow mark (↑) will be shown in the time display.

(Example)

↑	.	↑	↑	K	1	2	C
↑	↑	.	↑	K	1	2	C
8	.	6	0	K	↑	↑	C


The current is over the limit in the Lo range.

The current is over the limit in the Hi range.

The time is over the limit in the Lo range.

Overflow-mark display standards

Current values	Low range		> 9.99 kA
	High range		> 49.9 kA
Time	AC		> 99 CYCLES
	DC	CYC.	> 40 CYCLES
		SEC.	> 0.80



6. Button and Functions

Button	Name	LCD display	Description
ON Power ON/OFF ↑	Power ON button	5 0 H z A C ↓ 0 . 0 0 K 0 0 C Initial display	The display indicates the set frequency, AC or DC current measurement for 0.7 seconds and returns to the initial display.
OFF Power ON/OFF ↑	Power OFF button		Power OFF button
MR To check pulsation ↑	Memory Read button Maximum 9 welds can be put into memory	MR M 9 . 9 9 K 1 Current values display MR M 9 9 C 1 Impulse No. and Cycle values display MR M 1 2 0 ° 1 Conduction degrees display when no data to measure * N O D A T A	Press  button and the current values of Impulse No. on the right are shown. Press  button again and the cycle values are shown. Press  button again and the conduction degrees values are shown. Press  button again and the current values are shown. Use  or  button to change Impulse No. When there is no weld, NO DATA appears.
 To measure the current ↑	Current/Conduction Degree Selection button	 9 . 9 9 K 1 0 C Current values display  1 2 0 ° 1 0 C Conduction degrees display	Whenever the  button is pressed, the current or conduction degree is selected. Do not press this button during welding, as the measured values become inaccurate. Measurement can only be conducted in this mode.

Button	Name	LCD display	Description
Range RANGE	Range button		Select the range. + Hi ... 49.9-kA range - Lo ... 9.99-kA range
Impulse No. IMPULSE NO.	Impulse NO.		Set the Impulse No (No. 0 – 9). + increases the number. - decreases the number.
FIRST CYCLE FIRST CYC.	First Cycle button		Set the First Cycle (1 - 99 cycles). + increases the number. - decreases the number.
LAST CYCLE FIRST CYC.	First Cycle button		Set the Last Cycle. To select OFF/ON, hold down the button for three seconds.
50Hz/60Hz 50Hz/60Hz	50/60-Hz selection button		Select 50 Hz, 60 Hz. + 60Hz - 50Hz
AC/DC AC/DC	AC/DC selection button		Select AC, DC. + DC - AC
CYC./SEC. CYC./SEC.	DC measurement, item selection button		Receives button input only in DC mode. Set the time measurement item in DC mode. + for SEC and - for CYC.

To check measurement schedules

5. Button and Functions

Button	Name	LCD display	Description
	Data decrease button	N C T 0 ← Forced measurement cycle	Set the forced measurement cycle. To display, hold down the Data decrease button for three seconds.  increases the number.  decreases the number. After the trigger is recognized, measurement continues for the time specified here even when the current reaches the measurement end level. If the current higher than the measurement level is not detected within 500 ms after the trigger start, however, the measurement is not obtained and is ignored. The default is 0.
	Data increase button	T R G L V L 5 ← Current trigger level	Set the current trigger level (0 – 9). To display, hold down the Data decrease button for three seconds.  increases the number.  decreases the number. Increasing the value makes it easier to activate trigger. Decreasing the value makes it harder to activate trigger. The default is 5.
	Data increase button		Increase the data by 1 using the + button when the number is set.
	Data decrease button		Decrease the data by 1 using the - button when the number is set.

To check measurement schedules

↑ Forced measurement cycle

To set measurement schedules

↑ Data increase

↑ Data decrease

7. Specifications

Pickup	By the toroidal coil (MB-500-15) (optional)		
Measurement	Current	Measurement Range	1 kA - 9.99 kA (9.99 - kA range, Lo range) 5 kA - 49.9 kA (49.9 - kA range, Hi range)
		Measured Values	Root mean square (RMS)
		Accuracy	<9.99kA range> - Single-phase AC welding power supply $\pm (1\%rdg+9dgt)$ - DC inverter welding power supply $\pm (1\%rdg+15dgt)$ <49.9kA range> - Single-phase AC welding power supply $\pm (1\%rdg+3dgt)$ - DC inverter welding power supply $\pm (1\%rdg+5dgt)$
		Impulse No.	0 - 9
		First Cycles	1 - 99 cycles
		Measurement End	AC Less than 2% of full scale DC Less than 75% of the preceding cycle
		Display	3-digit
	Weld Time	Measurement Range	AC 1 - 99 cycles DC Cycles 1 - 40 cycles Seconds 0.01 - 0.80 seconds
		Measured Values	Number of cycles or time required for a full welding cycle
		Accuracy	± 0 cycles / ± 0.01 seconds
		Display	2-digit
	Conduction Degrees	Measurement Range	30 - 180°
		Measured Values	Maximum conduction degrees of the measured interval
		Accuracy	$\pm 9^\circ$
		Display	3-digit
	Multi-Step Weld Memory Function	Impulse No.	Up to 9 steps are stored in memory. The Impulse No. is reset to the initial setting with more than 0.5 seconds of cooling time.
Mass	500 g (including 4 nickel-hydrogen batteries)		
Outer Dimensions	164 (H) × 74 (W) × 30 (D) mm (excluding projections)		
Power Supply	Nickel-hydrogen batteries, 1.2 V × 4		
Ambient Temperature	0 - 40°C		
Accessory Charger*	Input 100 V to 240 V AC, 50/60 Hz (MM-315B-00-10/12)		
Automatic Power Off	When there is no button operation or no current measurement is performed for seven minutes.		




* The **MM-315B-00-15** does not come with a charger. Use a charger with the following specifications.

Output: 7 V $\pm$ 10%, 100 mA minimum

Polarity: Negative Center

8. Outline Drawing

(Unit: mm)




9. Charging the Battery

(1) Connecting the Unit and Charger

This tester is designed specifically for use with nickel-hydrogen batteries. Recharging is performed by the charger.

Connecting the charger



Connect the plug to the recharge connector of the unit, and plug the charger into an outlet. Fifteen hours are required to fully recharge the unit. Do NOT charge for more than 48 hours. Excessive charging will shorten the service life of the batteries. Be sure to charge at a room temperature of 35°C or lower.

(2) When should the Unit be Recharged

Recharge the unit when the word shown below appears and the power is shut off.

B	A	T	T	E	R	Y	
---	---	---	---	---	---	---	--

When the battery discharge is excessive, the above display may not be shown.

(3) Measurement during Recharging

It is possible to conduct measurement with the recharge plug inserted into the unit, but in order to obtain more accurate measurement, it is recommended that measurement be conducted after recharging is complete and the plug has been removed.

(4) Service Life of the Nickel-Hydrogen Batteries

1) Cycle life of charge/discharge

More than 500 charges/discharges are possible with proper use. If the length of use becomes very short, even when the batteries have been charged properly, it may be necessary to change the batteries.


Refer to Replacing the Nickel-Hydrogen Batteries in “Chapter 9 (5)”.

2) Batteries after extended period of use

The batteries can normally be used for 3 to 5 years with proper use. However, if they are not used for an extended period, their life will be shortened.

(5) Replacing the Nickel-Hydrogen Batteries

It is possible to conduct measurement with the recharge plug inserted into the unit, but in order to obtain more accurate measurement, it is recommended that measurement be conducted after recharging is complete and the plug has been removed.



Battery

Item name	Model	Specification
Nickel-hydrogen battery	210AAHCB-UC4	AA battery (UM-3) IEC/JIS model No.: HR6 Voltage: 1.2 V Capacity: 2050 mAh



WARNING

Do NOT short-circuit between positive and negative terminals; fire may result.

10. Calibration

To maintain the performance of the **MM-315B-00-1□**, it is necessary to calibrate it periodically. The calibration is carried out at our factory.

Send us your toroidal coil along with the **MM-315B-00-1□** for calibration. As the conditions of degradation for the **MM-315B-00-1□** differ depending on the operation environment, it is necessary to calibrate the **MM-315B-00-1□** and the toroidal coil together.

Contact us for details on calibration.



AMADA WELD TECH CO., LTD.

EU Declaration of Conformity

The company/manufacturer: **AMADA WELD TECH CO., LTD.**
95-3, Futatsuka, Noda-City, 278-0016 JAPAN

Herewith declares in his own sole responsibility conformity of the product

Designation: **Weld Tester**

Types/Serial Number, etc.: **MM-315B-00-10 / MM-315B-00-12 / MM-315B-00-15**

With applicable regulations below

EC Directive: **Low Voltage Directive 2014/35/EU**
EMC Directive 2014/30/EU
RoHS Directive 2011/65/EU , (EU)2015 / 863

Harmonized European/International Standards applied:
ISO 12100 : 2010 , ISO 13849-1 : 2015 , ISO 61010-1 : 2010+A1 : 2016
IEC 61326-1 : 2020

Importer Distributor in EU: **AMADA WELD TECH GmbH**
(please place distributor/importer stamp here) Lindberghstrasse 1, DE-82178 Puchheim, GERMANY
Tel: + 49 8983 9403 - 0

Division:

AMADA WELD TECH CO., LTD.

2022.1.28
Noda-City/Japan 2022-01-28
Place and Date

T. Jingu
Toshiaki Jingu / General Manager Quality Guarantee Department
Name/Signature/Position

Note: This Declaration certifies conformity with the above mentioned Directive(s), but gives no assurances of properties within the meaning of the Law concerning product liability and ProdSG. It becomes invalid if any technical or other modification are carried out without manufacturers consent.

64G091-07-5