DC INVERTER WELDING POWER SUPPLY

IS-600A

OPERATION MANUAL



Z12OM1185333-04

Thank you for purchasing our DC Inverter Welding Power Supply **IS-600A**. This operation manual describes its method of operation and precautions for use. Read this operation manual carefully prior to use. Store appropriately for ready reference.

Contents

1. Special Notes	
(1) Safety Precautions1-	1
(2) Precautions for Handling ······1-	4
(3) On Disposal	5
(4) Warning Label for Safety ·····1-	
2. Features 2-	1
3. Name and Functions of Each Section	
(1) Front Panel····································	
(2) Rear Panel	3
(3) MA-627A (Sold Separately)·····3-	4
4. How to Operate Screens	
	1
(2) POWER SUPPLY STATE Screen ·······	ി റ
(4) MONITOR Screen ······4-	
(5) MONITOR SET Screen ······4-	.12
(6) COPY SETUP DATA Screen ······4-	.13
(7) MODE SELECT Screen ······4-	15
(8) MONITOR MODE Screen4-	-22
(9) STEPPER COUNT Screen ······4-	24
(10) I/O CHECK Screen ······4-	
(11) RESET TO DEFAULT Screen	26
(12) PROGRAM PROTECT MODE Screen4-	26
5. Connection Procedures	
(1) Basic Configurations	1
(2) Connecting	4
6. Interface	
(1) Connection Diagram for External Input/Output Signals	
(2) Description of External I/O Signals ·······6-	3
(3) Connection of Input Signals	
7. Basic Operation7-	1
8. Timing Chart	
(1) Basic Sequence	1
(2) Detailed Description of Welding Current and Sequence	2
in the Event of an Error ·····8-	2
9. Maintenance	4
(1) Filter Cleaning and Replacement ······9-	1
10. Specifications	~ 4
(1) Specifications	J-1
(2) Options (Sold Separately)······10 (3) Duty Cycle Graph ······10	ノ-3) 5
(4) Board List for Maintenance	
	J-0


 (5) Major Components List
11. External Communication Function (1) Introduction(2) Data Transmission(3) Configuration
(3) Configuration 11-2 (4) Protocol 11-3 (5) Data Code Table 11-6
12. Outline Drawing 12-1
 13. Troubleshooting (1) Fault Code List (2) When the Welding Does not Start Even if the Start Signal is Input

1. Special Notes

(1) Safety Precautions

Before using, read "Safety Precautions" carefully to understand the correct method of use.

- These precautions are shown for safe use of our products and for prevention of damage or injury to operators or others. Be sure to read each of them, since all of them are important for safety.
- The meaning of the words and symbols is as follows.







Do not touch the inside of the Power Supply except as instructed.

The interior of this Power Supply carries high voltage. It is very dangerous to touch any parts except as instructed. Do not touch.

When inspecting the interior of the Power Supply, be sure to turn off the power source of the Power Supply and wait at least 5 minutes.

These actions can cause electric shock and fire. Perform only the



maintenance described in the operation manual. Never burn, destroy, cut, crush or chemically decompose the Power Supply.

This product incorporates parts containing gallium arsenide (GaAs).

Never disassemble, attempt to repair, or modify the Power Supply.

1. Special Notes

	M WARNING
	Do not insert your fingers or hands between the electrodes. When welding, keep your fingers and hands away from the electrodes.
	Do not touch any welded part or electrode during welding or just after completion of welding. The welded parts of a workpiece, electrodes, and the arm are very hot. Do not touch them; burns may result.
	Ground the equipment. If the Power Supply is not grounded, you may receive an electric shock in the event of malfunction or current leak.
	Connect the specified cables securely. Cables of insufficient current capacities and loose connections can cause fire and electric shock.
\bigcirc	Do not damage the power cable and connecting cables. Do not tread on, twist, or apply force to any cable. Doing so may cause the power cable and connecting cables to become broken, leading to electric shock and fire.
\bigcirc	Do not use any damaged power cable, connecting cable, or plug. Failure to observe this precaution can lead to electric shock, short circuit, or fire. If any part must be replaced or requires repair, consult us or your distributor.
	Stop the operation if any trouble occurs. Continuous operation after occurrence of a trouble such as burning smell, abnormal sound, abnormal heat, smoke, etc. can cause electric shock and fire. If such a trouble occurs, immediately consult us or your distributor.
	Persons with pacemakers must stay clear of the welding machine. A person who uses a pacemaker must not approach the welding machine or walk around the welding site while the welding machine is in operation, without being permitted by his/her doctor. The welding machine generates a magnetic field and has effects on the operation of the pacemaker while it is turned on.
	Protective gear must be worn. Put on protective gear such as protective gloves, long-sleeve jacket, leather apron, etc. Surface flash and expulsion can burn the skin if they touch the skin.
U	Wear protective glasses. If you look at the flash directly during welding, your eyes may be damaged. If any surface flash and expulsion gets in your eye, you may lose your eyesight.

Ų	Apply the specified supply voltage. Application of a voltage outside the specified range may result in fire or electric shock.
	Do not allow water to come in contact with the equipment. Water on the electric parts can cause electric shock and short circuit.
Ų	Use proper tools (wire strippers, pressure wire connectors, etc.) for terminal treatment of the connecting cables. Do not cut the wire conductor; fire or electric shock may result.
	Install the equipment on a firm and level surface. Injury may result if the equipment falls or is dropped.
\bigcirc	Do not sit on or place objects on the Power Supply. Failure to observe this precaution may lead to malfunction.
Ū	Keep combustible matter away from the Power Supply. Surface flash and expulsion may ignite combustible matter. If it is impossible to remove all combustible matter, cover it with non-combustible material.
\bigcirc	Do not cover the Power Supply with a blanket, cloth, etc. Do not cover the Power Supply with a blanket, cloth, etc. while it is in use. The cover may be overheated and burned.
\bigcirc	Do not use this Power Supply for purposes other than welding. Use of this Power Supply in a manner other than specified can cause electric shock and fire.
Ų	Use ear protectors. Loud noises can damage hearing.
	Keep a fire extinguisher nearby. Keep a fire extinguisher in the welding shop in case of fire.
	Maintain and inspect the Power Supply periodically. Maintain and inspect the Power Supply periodically, and repair any damage nearby before starting operation.

(2) Precautions for Handling

- Any work on this Power Supply must be performed only by the personnel with sufficient knowledge and experience regarding an inverter welding power supply.
- Install this Power Supply on a firm and level surface. Operation on an incline may result in malfunction.

For ventilation, provide 10-cm clearances at the intake and exhaust.

- When transporting or moving the Power Supply, do not lay it down and be sure to hold the underside when transporting. Holding a projection such as the terminal cover may cause damage. Also, handle the Power Supply with care so as not to make an impact such as drop on it. Moving the Power Supply by hand must be done by at least two people.
- Do not install the Power Supply in the following locations:
 - Damp areas (where the humidity is higher than 90%),
 - areas where temperatures are above 40°C or below 5°C
 - areas near a high noise source,
 - areas where chemicals are handled,
 - areas where water may condense,
 - dusty areas,
 - areas exposed to large amounts of vibration or shock, and
 - areas at an altitude above 1000 meters.
- Clean the exterior of the Power Supply using a soft, dry cloth or one slightly dampened with water. If the Power Supply is very dirty, use diluted neutral detergent or alcohol. Do not use paint thinner, benzine, etc., as they may discolor or deform the Power Supply.
- Do not insert a screw, coin, etc. into the Power Supply, as they may cause malfunction.
- Operate the Power Supply in accordance with the method described in this operation manual.
- Press switches/buttons carefully by hand. Handling them roughly (using a screwdriver or the tip of pen) may result in a malfunction or failure.
- Press switches/buttons one at a time. Pressing more than one switch/button at a time may result in a malfunction or failure.
- The Power Supply is not equipped with auxiliary power such as an outlet for lighting.
- The program box, cable to supply power, the welding head, the welding transformer, and cables for connecting among the welding head, the welding transformer and the Power Supply are separately needed to use the Power Supply.
- The I/O signal line to start the Power Supply is not attached. Prepare the crimp-on terminal and line for wiring to the terminal block.

1. Special Notes

(3) On Disposal

This product incorporates parts containing gallium arsenide (GaAs). At the time of disposal, separate it from general industrial waste or domestic waste and carry out the disposal in accordance with applicable laws and regulations.

(4) Warning Labels for Safety

On the main body are warning labels for safety. Their locations and meanings are as noted below.

1)



Location: Power Supply interior, side surface of acrylic cover. Meaning: **Danger.**

2)



Location: Power Supply interior, side surface of acrylic cover. Output terminal cover. Rear panel. Meaning: **Shock hazard.**

2. Features

The FINE SPOT-INVERTER **IS-600A** is a DC inverter, large-capacity power supply specially designed for spot welding and fusing.


The power supply is compact and convenient to transport or reposition. A monitor function is provided to enable judgment of defective or non-defective welding.

- Welding-current monitoring function for judgment of weld quality
- Six control systems (Primary constant-current effective value control, Secondary constant-current effective value control, Secondary constant-power effective value control, Primary constant-current peak value control, Secondary constant-voltage effective value control, and Constant-phase control) for stable weld quality
- Comes equipped with a current-shutoff function, which shuts off current in response to external input (e.g., displacement of the electrode), ensuring stable fusing.
- Use of an inverter allows for high power factor and stable power conditions
- Easy setting of a variety of items through the menu selection system
- Four protective functions for maximum ease of operation
 - Overcurrent-detection function
 - No-current / no-voltage detection function
 - Thermostat-fault detection function
 - Self diagnostics
- The model number is different depending on the current setting range.

Model No.	Current setting range
IS-600A-00-01/-00-02	02.0–20.0 kA
IS-600A-01-01	0.50–9.99 kA

3. Name and Functions of Each Section

(1) Front Panel



- 1) **[WELD POWER] lamp (Green LED)** This lamp lights when the power is supplied to the Power Supply.
- 2) [READY] lamp (Green LED)

This lamp lights when the system is ready to start welding.

To turn on this lamp, writing data into the flash memory is complete and:

- · [WELD ON/OFF] key
- WELD ON/OFF setting for program unit MA-627A and
- External WELD ON signal

must all be on.

3. Name and Functions of Each Section

3) [START] lamp (Green LED)

This lamp remains lit while the start signal is input.

4) [WELD] lamp (Green LED)

This lamp remains lit while the welding current is flowing.

5) [TROUBLE] lamp (Orange LED)

This lamp lights when an error is detected. At this time, the program unit emits a beeping sound, and the Power Supply operation is interrupted.

6) [TROUBLE RESET] key

If this key is pressed while the **[TROUBLE] lamp** is lit, the lamp is turned off. The **[TROUBLE] lamp** lights up again, however, as long as the error remains uncorrected. Eliminate the cause of the error before pressing this **[TROUBLE RESET] key**.

If the **[TROUBLE] lamp** lights up during operation, press the **[TROUBLE RESET] key**, then input the start signal again; operation will then resume.

7) [WELD ON/OFF] key

This key is one of those required to activate the **[READY] lamp**. Pressing this key alternately lights and shuts off this lamp. When the key is toggled on, the **[READY] lamp** lights, and when the key is toggled off, the lamp is turned off.

8) [RS485/RS232C] connector

For external communication. (See **11. External Communication Function**.)

9) [COIL IN] connector

For toroidal coil connection. Used for secondary constant-current effective value control, secondary constant-power effective value control, and constant-phase control. (The toroidal coil is an optional component.)

10) [PROGRAM MONITOR I/O] connector

Connects to Program Unit **MA-627A**. Used for welding schedule setting and/or reviewing monitor results.

11) Filter Cover

An air filter is provided inside this cover, which must be removed for maintenance of the air filter (See **9. Maintenance**).





The fan motor may cause injury to fingers.


Be sure to turn off the power supply before replacing or cleaning this component.

12) Welding Current Input Breaker Lever

Raise the lever to supply power and lower it to shut off power.

3. Name and Functions of Each Section

(2) Rear Panel



 Connecting terminal block for external input/output signal This terminal block is used to input the schedule signals and output trouble signals.


2) Welding Transformer [I/O] connector

For connecting the [SENS] cable for our welding transformer.

- 3) **Terminal block for welding power input/output** This terminal block is used to connect to the input of the welding transformer and the welding power supply (three-phase).
- 4) Cable gland

Two pieces for Input/Output cables and one piece for I/O cable are supplied. Insert cables into them and tighten caps to fix cables and protect the Power Supply interior.

(3) MA-627A (Sold Separately)



1) [TROUBLE RESET] key

If this key is pressed while the **[TROUBLE] lamp** on the Power Supply is lit, the lamp goes off. This key has the same function as the **[TROUBLE RESET] key** on the Power Supply.

2) [CURSOR] keys

These keys are used to move the cursor (> or (>) to select an item.

3) [+ON/-OFF] keys

These keys are used to change the value of a selected item or to turn the item on and off. When the **[+ON] key** is pressed, the selected value increases, and if the **[-OFF] key** is pressed, the value decreases. The selected item is activated by pressing the **[+ON] key**, and turned off by pressing the **[-OFF] key**.

4) [ENTER] key

This key is used to write the set or changed value and [ON/OFF] data to the **MA-627A**. After any data is set or changed, be sure to press this **[ENTER] key** to write the relevant data before moving the cursor.

If this [ENTER] key is not pressed, the MA-627A will not save the set data.

5) [MENU] key

This key is used to display the **[MENU] screen**. Press this key to return to the **[MENU] screen** from any other screen.

6) **Connector**

This connector is used to connect the circuit cable. Connect the other end of the cable to the **[PROGRAM MONITOR I/O] connector** of the Power Supply.

CAUTION		
No settings or changes may be made to any item from the receipt of the start signal through the end of the weld sequence and turning off the Start signal. If setting is performed while the start signal is input, the following screen appears. Turn off the start signal and press [TROUBLE RESET] key 1).		
IS -600A IS BUSY OR NOT CONNECTED		
Please RESET key in		

(Note) While the start signal is input, 1) **[TROUBLE RESET] key**, **[TROUBLE RESET] key** on the front panel (see **(1) 6)**) and the error reset input terminal of the external I/O (see **6. Interface**) do not work. Be sure to turn off the start signal before resetting an error.


4. How to Operate Screens

Appearance of characters used in the following explanation	
Shaded characters (000)	An item for which a value must be input, or which must be set ON or OFF. Move the cursor () to the number (or to ON or OFF) to be selected or changed, and press the [+ON/-OFF] key .
Outlined characters (000)	An item that is indicated on-screen but that cannot be changed.

(1) MENU Screen

The **MA-627A** has various functions that are set from the respective screens. The **[MENU] screen** displays these functions in menu form.

Move the cursor (>) to the desired item; press the **[ENTER] key** to move to the selected screen (with the exception of the **MODE SELECT screen**).



(2) POWER SUPPLY STATE Screen

This screen is used to display and set data for the Power Supply.

	-POWER SUPPLY STATE	
(a) ——	- LCD CONTRAST $(T:0 \rightarrow 7:D)$	2
(b) ——	— CONTROL #	01
(c) —	— PROGRAMMED DATE	2000. 01. 01
(d) ——	— WELD TRANS FREQUENCY	1000 Hz
(e)——	— POWER SOURCE FREQUENCY	50 Hz
(f)	— MA-627A ROM VERSION #	[V00-00A]
(g) —	— IS -600A ROM VERSION #	[V00-00A]

(a) LCD CONTRAST

Sets the screen contrast. The contrast can be set in a range from 0 to 7. The larger the value, the darker the screen. Adjust the contrast if the screen is difficult to view.

(b) CONTROL

Input the identification No. of your Power Supply.

If you have two or more Power Supply units, input 01 for the first one, 02 for the second one, 03 for the third one, and so on.

(c) PROGRAMMED DATE

Input the date on which a schedule is set as data. The date does not affect the set schedule. When the Power Supply memory is initialized, the date is also initialized to the date on which the ROM version is created.

(d) WELD TRANS FREQUENCY

Change the output frequency of the inverter power supply for the Power Supply. (Fixed to 1,000 Hz and cannot be changed.)

(e) POWER SOURCE FREQUENCY

The frequency of the welding power is measured and indicated automatically.

(f) MA-627A ROM VERSION

Indicates the ROM version No. of program unit MA-627A.

(g) IS-600A ROM VERSION

Indicates the ROM version No. of the Power Supply.

(Note) The Power Supply writes data into the flash memory on the control board when a setting is changed or a schedule data is copied. The **[READY] lamp** on the front panel and the external **READY** signal are turned off during writing. Check that the **[READY] lamp** is turned on to start welding. It takes about 2 seconds at longest to write data into the flash memory.

(3) SCHEDULE Screen

Up to 255 welding schedules can be set on the Power Supply. These schedules are indicated as **SCHEDULE** #1 to #255.

This screen is used to set the **SCHEDULE** No., length of weld time, welding current, and so on. This data can be indicated using the 12 modes shown below, but the indicated items are the same for all modes.

The **ms mode** or **CYC mode** can be changed via **WELD TIME** (See (7)(i)) on the **MODE SELECT screen**.

(a) —	-SCHEDULE #255	WELD ON/OFF OFF (f)	
(b) —	SQD SQZ CO TIME 0000 0000 00 UP WELD DOWN		(Note) The screen shows the
(c) { (g) —	1 000 000 000 2 000 000 000 3 000 000 000 PAGE DOWN ⊽ HEAT	ms 1. 00kA ms 1. 00kA ms 1. 00kA CTRL0: <primary rms="">(e)</primary>	settings for IS-600A-01-01 . The settings surrounded with frames are02.0kA or 02.0kW for IS-600A-00-01/00-02 .

<Primary constant-current effective value control **ms mode**> <Primary constant-current

-SCHEDULE #001 WELD ON/OFF OFF	-SCHEDULE #00
SQD SQZ COOL1 COOL2 HOLD OFF	SQD SQZ
TIME 0000 0000 000 000 000 0000ms	TIME 000 000
UP WELD DOWN HEAT	UP WELD
1 000 000 000 ms 1.00kA	1 00 00
2 000 000 000 ms 1.00kA	2 00 00
3 000 000 000 ms 1.00kA	3 00 00
PAGE DOWN ∇ HEAT CTRLO: <primary rms=""></primary>	PAGE DOWN ∇

a minary constant surront		
effective value control	CYC mode>	

-SCHEDULE #001 WELD ON/OFF OFF SQD SQZ COOL1 COOL2 HOLD OFF TIME 000 000 00 00 00 00 000 00 CYC UP WELD DOWN HEAT 1 00 00 00 CYC 1.00kA 2 00 00 00 CYC 1.00kA 3 00 00 00 CYC 1.00kA PAGE DOWN 7		
TIME 000 000 000 000 000 000 000 CYC UP WELD DOWN HEAT HEAT	-SCHEDULE #00	01 WELD ON/OFF OFF
UP WELD DOWN HEAT 1 00 00 00 CYC 1. 00kA 2 00 00 00 CYC 1. 00kA 3 00 00 OCYC 1. 00kA	SQD SQZ	Z COOL1 COOL2 HOLD OFF
1 00 00 00 CYC 1.00kA 2 00 00 00 CYC 1.00kA 3 00 00 00 CYC 1.00kA	TIME 000 000	00 00 00 00 00 00 00 00 00 00 00 00 00
2 00 00 00 CYC 1. 00kA 3 00 00 00 CYC 1. 00kA	UP WELD	
3 00 00 00 CYC 1. 00kA	1 00 00	00 CYC 1.00kA
	2 00 00	00 CYC 1.00kA
PAGE DOWN \triangledown HEAT CTRL0: <primary rms=""></primary>	3 00 00	00 CYC 1.00kA
	PAGE DOWN \triangledown	HEAT CTRLO: <primary rms=""></primary>

<secondary constant-current<="" th=""><th><secondary constant-current<="" th=""></secondary></th></secondary>	<secondary constant-current<="" th=""></secondary>
effective value control ms mode >	effective value control CYC mode >
-SCHEDULE #001 WELD 0N/0FF 0FF	-SCHEDULE #001 WELD ON/OFF OFF
SQD SQZ COOL1 COOL2 HOLD 0FF	SQD SQZ COOL1 COOL2 HOLD OFF
TIME 0000 0000 000 000 0000 0000ms	TIME 000 000 00 00 000 00 CYC
UP WELD DOWN HEAT	UP WELD DOWN HEAT
1 000 000 000 ms 1.00kA	1 00 00 00 CYC 1.00kA
2 000 000 000 ms 1.00kA	2 00 00 00 CYC 1.00kA
3 000 000 000 ms 1.00kA	3 00 00 00 CYC 1.00kA
PAGE DOWN ⊽ HEAT CTRL1: <secondary rms=""></secondary>	PAGE DOWN ⊽ HEAT CTRL1: <secondary rms=""></secondary>

The items (a) to (f) indicated at the top screen are described beginning on Page 4-5.

<secondary constant-power<br="">effective value control ms mode></secondary>	<secondary constant-power<br="">effective value control CYC mode></secondary>
effective value control ms mode> -SCHEDULE #001 WELD ON/OFF OFF SQD SQZ COOL1 COOL2 HOLD OFF TIME 0000 0000 000 0000 0000 0000 UP WELD DOWN HEAT 1 000 000 000 ms 1 00kW 2 000 000 000 ms 1 00kW 3 000 000 ms 1 00kW PAGE DOWN T HEAT CTRL2: <power< td=""> FMS</power<>	-SCHEDULE #001 WELD ON/OFF OFF SQD SQZ COOL1 COOL2 HOLD OFF TIME 000 000 00 00 000 00 CYC UP WELD DOWN HEAT 1 00 00 00 CYC 1.00kW 2 00 00 00 CYC 1.00kW 3 00 00 00 CYC 1.00kW PAGE DOWN 7 HEAT CTRL2: <power rms<="" td=""></power>
<primary constant-current<br="">peak value control ms mode> -SCHEDULE #001 WELD 0N/0FF 0FF SQD SQZ COOL1 COOL2 HOLD 0FF TIME 0000 0000 000 000 0000 0000ms UP WELD DOWN HEAT 1 000 000 000 ms 1.00kA 2 000 000 000 ms 1.00kA 3 000 000 000 ms 1.00kA A 000 000 ms 1.00kA PAGE DOWN ⊽ HEAT CTRL3:<primary limit=""></primary></primary>	<pre><primary constant-current="" control="" cyc="" mode="" peak="" value=""> -SCHEDULE #001 WELD 0N/0FF 0FF SQD SQZ COOL1 COOL2 HOLD 0FF TIME 000 000 00 00 000 00 000 CYC UP WELD DOWN HEAT 1 00 00 00 CYC 1.00kA 2 00 00 00 CYC 1.00kA 3 00 00 00 CYC 1.00kA PAGE DOWN ⊽ HEAT CTRL3: <primary limit=""></primary></primary></pre>
<pre><secondary constant-voltage="" control="" effective="" mode="" ms="" value=""> -SCHEDULE #001 WELD 0N/0FF 0FF SQD SQZ COOL1 COOL2 HOLD 0FF TIME 0000 0000 000 000 0000 0000ms UP WELD DOWN HEAT 1 000 000 000 ms 0.20V 2 000 000 000 ms 0.20V 3 000 000 000 ms 0.20V PAGE DOWN ⊽ HEAT CTRL4:<v0ltage rms=""></v0ltage></secondary></pre>	<pre><secondary constant-voltage="" control="" cyc="" effective="" mode="" value=""> -SCHEDULE #001 WELD 0N/0FF 0FF SQD SQZ C00L1 C00L2 H0LD 0FF TIME 000 000 00 00 00 000 00 CYC UP WELD D0WN HEAT 1 00 00 00 CYC 0.20V 2 00 00 00 CYC 0.20V 3 00 00 00 CYC 0.20V PAGE D0WN ⊽ HEAT CTRL4:<v0ltage rms=""></v0ltage></secondary></pre>
<constant-phase control="" mode="" ms=""> -SCHEDULE #001 WELD 0N/0FF 0FF SQD SQZ COOL1 COOL2 HOLD 0FF TIME 0000 0000 000 000 000000000ms UP WELD DOWN HEAT 1 000 000 000 ms 10.0 % 2 000 000 000 ms 10.0 % 3 000 000 000 ms 10.0 % PAGE DOWN ∇ HEAT CTRL5:<fixed pulse=""></fixed></constant-phase>	<constant-phase control="" cyc="" mode=""> -SCHEDULE #001 WELD ON/OFF OFF SQD SQZ COOL1 COOL2 HOLD OFF TIME 000 000 00 00 00 000 00 CYC UP WELD DOWN HEAT 1 00 00 00 CYC 10.0 % 2 00 00 00 CYC 10.0 % 3 00 00 00 CYC 10.0 % PAGE DOWN \forall HEAT CTRL5 :<fixed pulse=""></fixed></constant-phase>

(a) SCHEDULE

Select from #1 to #255 to set the **SCHEDULE**. Normally select #1 first, then select additional schedules in sequential order.

(b) TIME

Set the time for each operation during welding. Units of time are in ms or CYC. For each operation, see **8. Timing Chart**.

SQD / Squeeze delay time	Length of time added to SQZ; only for the first weld after start signal in repeat operation
SQZ / Squeeze time	Length of time until proper squeeze is applied to workpiece
COOL1 and COOL2 / Cooling time 1 and Cooling time 2	Length of time to cool workpiece after turning off welding current
HOLD / Hold time	Length of time to hold workpiece after turning off welding current
OFF / Off time	Length of time to turn off valve signal between repeated operations (No repeat operation if set to "0".)

(c) WELD (1, 2, 3)

Set the length of time to allow welding current to flow.

UP

Set the upslope time (to increase the welding current gradually).

DOWN


Set the downslope time (to decrease the welding current gradually).

(Note) Upslope / Downslope waveform when COOL (cooling time) is set to 0.

The welding current normally increases from the minimum value to the set value in Upslope and decreases from the set value to the minimum value in Downslope, but the following is an exception.


① When the upslope time is set for the subsequent stage in the multi-stage welding.

The upslope in the subsequent stage starts from the set current of the previous current. (See example below.)



When the Power Supply starts with the following setting, E-10 (schedule setting error) will occur.

• When the current value in the previous stage is equal to or larger than the current value in the subsequent stage even with the upslope setting in the subsequent stage. (See example below.)




When producing a waveform like this, set COOL between WELD1 and WELD2.

WELD1 > WELD2.


^② When the downslope time is set for the previous stage in the multi-stage welding.

The downslope in the previous stage ends at the set current of the subsequent stage. (See example below.)



When the Power Supply starts with the following setting, E-10 (schedule setting error) will occur.

• When the current value in the previous stage is equal to or smaller than the current value in the subsequent stage even with the downslope setting in the previous stage. (See example below.)



When producing a waveform like this, set COOL between WELD2 and WELD3.

(Note) Set 1 ms or more for at least one of WELD1, WELD2 and WELD3. Also, set the total time of UP and DOWN to be shorter than WELD. If not, E-10 (Schedule setting error) will be displayed.

(d) HEAT

Set the welding current for **WELD1**, **WELD2**, and **WELD3**, respectively. When **CTRL** is changed, the items to be set also change.

<primary constant-current="" control="" effective="" value=""></primary>	Effective value of current
<secondary constant-current="" control="" effective="" value=""></secondary>	Effective value of current
<secondary constant-power="" control="" effective="" value=""></secondary>	Effective value of electric power
<primary constant-current="" control="" peak="" value=""></primary>	Peak value of current
<secondary constant-voltage="" control="" effective="" value=""></secondary>	Effective value of voltage
<constant-phase control=""></constant-phase>	Pulse width when full wave is 100%

(e) HEAT CTRL

Select one from the following six welding current control methods.

0	<primary rms=""></primary>	Primary constant-current effective value control
1	<secondary rms=""></secondary>	Secondary constant-current effective value control
2	<power rms=""></power>	Secondary constant-power effective value control
3	<primary limit=""></primary>	Primary constant-current peak value control
4	<voltage rms=""></voltage>	Secondary constant-voltage effective value control
5	<fixed pulse=""></fixed>	Constant-phase control

ATTENTION

When using another manufacturer's transformer and **SECONDARY RMS>**, **POWER RMS>**, or **FIXED PULSE>**, connect the toroidal coil (sold separately) to the secondary of the transformer. An unconnected toroidal coil will be judged as a "No Current" event and error message E-05 (13. Troubleshooting) will be displayed.



Even though E-05 (No Current error) is displayed, current is flowing. Exercise caution in handling.


(f) WELD ON/OFF

One of the settings required to turn **ON** the **[READY] lamp** of the Power Supply. **ON: WELD ON OFF: WELD OFF**

(Note) Even if this switch is **ON**, the Power Supply cannot supply welding current if the **[WELD ON/OFF] key** on the front panel or external **WELD ON** signal is **OFF**. In order for the Power Supply to supply welding current, this switch, the **[WELD ON/OFF] key**, and the external **WELD ON** signal must all be **ON**.

(g) PAGE DOWN


When the cursor is at ∇ , moving the cursor down will change the display to the screen shown below. Use Δ or ∇ to scroll up or down through different screens.



(h) PULSATION

Set the number of repetitions in the field for weld time in the **COOL1** and **WELD2**. (See the figure below.)

Timing chart obtained when **PULSATION** is set to "3"



(Note) PULSATION

- When performing a welding with the setting **PULSATION** to 2 or more and **COOL1** (cooling time) to 0, set the control system to the primary constant-current effective value control or the primary constant-current peak value control. If a welding is performed with the other controls, control and monitored value may not function correctly.
- When performing a welding with the setting PULSATION to 2 or more, only the last welding data is displayed as the monitored value of WELD2 after completion of sequence. In the timing chart above, the data of the third time is displayed. (See (4) MONITOR Screen.) Also, if the current gets out of the range of upper/lower limit judgment during repeated PULSATION operation, a caution signal is output after completion of welding. (See (5) MONITOR SET Screen.)

(i) VALVE


Two valves (welding heads) can be connected to the Power Supply. Use this setting to select which of the two valves to use.

(j) GAIN (1–9)

Sets the amount of feedback correction in Primary constant-current effective value control, Secondary constant-current effective value control, Secondary constant-power effective value control, and Secondary constant-voltage effective value control. Though **1** is normally used, the larger value will give the shorter rise time. (Invalid in Primary constant-current peak value control and Constant-phase control.)

(Note) Control gain refers to a correction amount in feedback control.

Although the current rises more rapidly with greater control gain, the current waveform may experience overshoot. On the other hand, a smaller control gain suppresses current waveform overshoot but causes a slower increase in current. The Power Supply offers nine (9) choices of gain levels (1–9).



(k) TURN RATIO

Set the welding transformer turns ratio. The turns ratio can be set in a range from 001.0 to 199.9.

(I) PAGE UP

When the cursor is at Δ , moving the cursor up will return the display to the previous screen.


ATTENTION

When using **<PRIMARY RMS>** or **<PRIMARY LIMIT>**, always set the correct turns ratio.

An incorrect ratio will result in malfunction.

(4) MONITOR Screen

In this screen, you can confirm the operational conditions during welding. Monitored data is displayed for each **SCHEDULE**.



(Note) The screen shows the settings for **IS-600A-01-01**. The settings surrounded with frames are 00.0kA for **IS-600A-00-01/00-02**.

(a) SCHEDULE

Set the No. of the **SCHEDULE** to monitor. The measured values (welding current, voltage, etc.) for welding within that **SCHEDULE** are displayed. The Power Supply stores the latest measured values of each **SCHEDULE** No. The stored measurement values are not erased even when the power is turned off, and thus can be checked for the next job.

(b) TIME

The lengths of periods during which current was supplied in the course of **WELD1**, **WELD2** and **WELD3** operations are displayed. As units of time, **ms** and **CYC** may be selected. Either unit can be selected via the **MODE SELECT screen**. (See (7)(i).)

(c) CURRENT

The welding current is displayed.

(d) VOLT

The measured voltage is displayed when the voltage detection cord is connected and the secondary voltage is input.

(e) POWER

The measured electric power (measured current x measured voltage) is displayed when the toroidal coil and voltage detection cord are connected and the secondary current and secondary voltage are input.

(f) PULSE

The widest pulse among the supplied primary pulse current is displayed as a percentage of pulse width in full wave mode. The pulse width in full wave mode varies with the frequency setting (**WELD TRANS FREQUENCY**).

(g) STEP

The present number of steps is displayed when **STEPPER MODE** is activated on the **MODE SELECT screen**. (In the example above, the VALVE 1 is set to STEP 1, the VALVE 2; STEP 3.)

(h) STEPPER COUNT

The number of welds in the present step is displayed when **STEPPER MODE** (see (7)(f)) is activated on the **MODE SELECT screen**.

(i) WELD COUNT

The present number of welds is displayed when the **WELD COUNT** (see (7)(g)) is activated on the **MODE SELECT screen**.

(Note) Monitored value

- Only the last monitored value and the number of counts of each **SCHEDULE** are kept for a period of 10 days after the power is turned off.
- When the repetition welding is performed with **PULSATION** or OFF time setting, only the last data is displayed as the monitored value. The passing data is not displayed.

(5) MONITOR SET Screen

Set the conditions for determining a good or bad weld, including values for welding current, upper or lower limits for the secondary voltage, etc.

If the monitored welding current, secondary voltage, etc., do not meet the set conditions, a caution signal is output, and can be used to activate an alarm buzzer, alarm lamp, or similar event.

	(t) I		(c) 		(c	d) (a	a) 		
-MONITOR SET				S	CHE	DULE	#00)1		
	CUF	RENT	١	VOLT	P	OWER-	I PU	LSE —	— (e))
WELD1 HIGH	9.	99kA	9.	99V	99.	99kN	10	00%		
LOW	0. (00kA	0.	00V	00.	00kN				
WELD2 HIGH	9. 9	99kA	9.	99V	99.	99kN	10	00%		
LOW	0. (00kA	0.	00V	00.	00kN				
WELD3 HIGH	9. 9	99kA	9.	99V	99.	99kN	10	00%		
LOW	0.	00kA	0.	00V	00.	00kN				

(Note) The screen shows the settings for IS-600A-01-01.

The settings surrounded with frames change as follows for **IS-600A-00-01/00-02**: 9.99 kA -> 99.9 kA

0.00 kA -> 00.0 kA

(a) SCHEDULE

Input the No. of the **SCHEDULE** to monitor (to set the schedules).

(b) CURRENT

Set the upper limit (HIGH) and lower limit (LOW) of the welding current for each of **WELD1**, **WELD2** and **WELD3**.

(c) VOLT

Set the upper limit (HIGH) and lower limit (LOW) of the secondary voltage for each of **WELD1**, **WELD2** and **WELD3**.

(d) POWER

Set the upper limit (HIGH) and lower limit (LOW) of the electric power for each of **WELD1**, **WELD2** and **WELD3**.

(e) PULSE

If the ratio of welding current pulse / pulse width in full wave mode exceeds the percentage set in the **PULSE HIGH**, an ERROR signal is output. Pulse width is expressed assuming that the full wave is 100%.

(Note) Upper/Lower limit judgment value when STEPPER MODE is set to ON

The upper/lower limit judgment value set here is for the current when a welding is performed, not for the initial setting.

Therefore, when **STEPPER MODE** is set to ON to perform step-up (step-down) for the initial setting, the upper/lower limit judgment value is stepped up or down automatically.

Example) When the current is set to 2 kA, HIGH; 2.2 kA, LOW; 1.8 kA. When the step becomes 150%, HIGH and LOW become as follows.


> HIGH: 2.2 x 1.5 = 3.3 kA LOW: 1.8 x 1.5 = 2.7 kA

(6) COPY SETUP DATA Screen

The MA-627A can store data. (Refer to the figure shown below.)

When the **MA-627A** is connected to the Power Supply, the data stored in the Power Supply memory is displayed on the Monitor Panel.

When the data is changed and the **[ENTER] key** is pressed, the contents of the memory of the Power Supply are overwritten by the new setting.



When two or more the Power Supply units are used and the contents of the memory of the first unit need to be copied to the second unit, copy the data from the first unit to the memory of **MA-627A** temporarily, and then copy this data to the second unit.

Move the cursor (>) to the required item among (a) to (c), then press the **[ENTER] key**; the data will be copied.

- (a) IS-600A -----> MA-627A The data in IS-600A is copied to MEMORY of MA-627A.
- (b) IS-600A <----- MA-627A

The data in MEMORY of MA-627A is copied to IS-600A.

(c) SCHEDULE [001] -----> SCHEDULE [001]-[255]

This function is used to copy the **SCHEDULE** (welding condition).

The Power Supply can set up to 255 schedules, indicated as **SCHEDULE #1–#255**.

This function is also used to change from the **SCHEDULE #1** setting, to perform welding according to another schedule.

For example, **SCHEDULE #2** can be set by switching from **SCHEDULE #1** as follows:

- SCHEDULE [001] -----> SCHEDULE [002]-[002] (Be sure to press the [ENTER] key before moving the cursor)
- Move the cursor to the left of the letters of SCHEDULE and press the [ENTER] key.

The data for **SCHEDULE #1** is copied to **SCHEDULE #2** through this operation. Call up #2 on the **SCHEDULE screen**, and change the values, if necessary.

SCHEDULE #1 can be copied immediately to **SCHEDULE #2** via **SCHEDULE #4** through the following setting:

SCHEDULE [001] ----> SCHEDULE [002]-[004]

(7) MODE SELECT Screen

	-MODE SELECT		
(a)—	DELAY START SET	20ms	
(b) —	START SIG.MODE	MAINTAINED	
(c)—	END SIG.TIME	200 ms END SIG. MODE 1 —	-(d)
(e)—	PARITY CHECK	OFF STEPPER MODE OFF	– (f)
(g)—	WELD COUNT	OFF RE-WELD OFF	- (h)
(i)—	WELD TIME	ms	
(j) —	-PAGE DOWN	∇	

(a) DELAY START SET

One welding condition is determined via **DELAY START SET**, a value corresponding to chatter prevention time, after a start signal is input. The **DELAY START SET** period can be set in a range from 1 to 20 ms, in units of 1 ms.

(A)

(B)

D	ELAY START SET Set	etting	D	ELAY START SET S	etting
2ND STAGE	OFF	ON	2ND STAGE	OFF	ON
SCH1	OFF	ON	SCH1	OFF	OFF
SCH2	OFF	OFF	SCH2	OFF	OFF
SCH4	OFF	OFF	SCH4	OFF	OFF
SCH8	OFF G	ON	SCH8	OFF GFF	ON
SCH16	OFF	OFF	SCH16	OFF	ON
SCH32	OFF	OFF	SCH32	ON	OFF
SCH64	OFF	OFF	SCH64	OFF	OFF
SCH128	OFF	OFF	SCH128	OFF	OFF

In Fig. (A), schedule signals 1 and 8 are **ON**. Therefore, welding is performed using schedule No. 9. In Fig. (B), only schedule signal 8 is **ON**. As a result, welding is performed using schedule No. 8.

Schedule signals 16 and 32 are invalid because they are **OFF** when the schedule is determined.

(Note) When **DELAY START SET** is 1 ms or 2 ms


The schedule number when the 2ND STAGE signal is received is selected. Therefore, in Fig. (A) above, the schedule number is not selected and the schedule signal input error occurs. When **DELAY START SET** is 1 ms or 2 ms, input the schedule signal in advance before the 2ND STAGE signal is received.

(b) START SIG.MODE

Set the input method of the start signal to activate the Power Supply.


1) LATCHED

- The welding sequence halts if the 2ND STAGE signal stops during squeeze time (**SQZ**).
- The welding sequence proceeds to completion when the 2ND STAGE signal stops during Weld 1 time (**WE1**) or later.



2) PULSED


When the 2ND STAGE signal is input for more than the time set through **DELAY START SET** and then stops, the welding sequence will proceed to completion.



3) MAINTAINED

If the 2ND STAGE signal stops halfway through the welding sequence (from the beginning of initial squeeze delay time through the end of hold time), the welding sequence will halt at that point.

Note that the end signal will not be output at this time.



(c) END SIG.TIME

Set the length of time for output of the end signal. The output time can be set in a range from 10 to 200 ms and in units of 10 ms. The start signal is not received while the end signal is output.

(d) END SIG.MODE

Set the conditions for output of the end signal upon completion of the weld sequence.

- 0: Outputs the end signal even when the monitored value is outside the upper and lower tolerance limits. The end signal will not be output in the event of a no-current or overcurrent error.
- 1: The end signal will not be output if the monitored value is outside the upper and lower tolerance limits or in the event of a no-current or overcurrent error.
- 2: The end signal will be output even when the monitored value is outside the upper and lower tolerance limits and even in the event of a no-current or overcurrent error.

(e) PARITY CHECK

Select whether or not parity check is performed. (Set external input pin 13.)

When **PARITY CHECK = ON**

Parity check will be performed. This check allows for detection of a failure resulting from a wire break in the schedule selection signal lines. Be sure that the total number of closed schedule selection and parity signal lines is always odd. (Refer to **Note 1**, **"Schedule Nos. and Schedule Selection Pins."**)

When PARITY CHECK = OFF

Parity check will not be performed. (The terminal functions as the WE1STOP terminal.) The sequence will proceed to **COOL1** if external input pin 13 is closed during the **WE1** sequence operation. (Refer to **Note 2**, "**Current shutoff function.**")


IS-600A

SCHEDULE#	SCH 1	SCH 2	SCH 4	SCH 8	SCH16	 Close SCH32 	SCH64	SCH128	PARIT
1	•								
2									
3									
4									
5									
6									
7									
8									
9									
10									
11									
12									
13	•	l	•	•	l				
14				•	l				
15	•			•	l				
16		Ī		Ī					
17	•	l		1	•				
18									
19		•			•				
20									
:									
:									
:									
:									
:									
238						•			
239									
240									
241					•	•	•	•	_
242						•			
243						•			
244					•	•	•	•	
245			•		•	•	•	•	
246						•			
247	•	•	•		•	•	•	•	_
248	-	_	_		•	•	•	•	
249	•			•	•	•	•	•	
250	-			•	•	•	•	•	•
251	•	•		•	•	•	•	•	
252	-			•	•	•	•	•	
253	•		•	•	•	•	•	•	
254	-		•	•	•	•	•	•	
		•	— —	•	•	•	•	•	


Note 1: Schedule Nos. and Schedule Selection Pins

Note 2: Current shutoff function

The current shutoff function shuts off current when the proper weld penetration is achieved—for example, during fusing—thus preventing excessive penetration. (Refer to the figure below.)



Timing chart for stopping current



The **WE1STOP** signal shuts off current immediately when input during the **WE1** period, switching the sequence to **COOL1**. The **WE1STOP** signal will not shut off current if input during the **WE2** or **WE3** period.

The **WE2STOP** signal shuts off current immediately when input during the **WE2** period, switching the sequence to **COOL2**. The **WE2STOP** signal will not shut off current if input during the **WE1** or **WE3** period.

The **WE3STOP** signal shuts off current immediately when input during the **WE3** period, switching the sequence to **COOL3**. The **WE3STOP** signal will not shut off current if input during the **WE1** or **WE2** period.

When the welding stop signal is input before the start signal is received, the welding stop error occurs.

4. How to Operate Screens

(f) STEPPER MODE

Select whether or not to perform step-up (step-down) operation.

ON	Step-up (step-down) will be performed.
OFF	Step-up (step-down) will not be performed.

(g) WELD COUNT

Select whether or not to check the weld count. (Set external input pin 14.)

When WELD COUNT = ON

The weld count will be checked. (Refer to (a) of (8) MONITOR MODE Screen.)


When WELD COUNT = OFF

The weld count will not be checked. (The terminal functions as the WE2 STOP terminal.) The sequence will proceed to **COOL2** if external input pin 14 is closed during the **WELD2** sequence operation. (Refer to **Note 2**, **(7)(e)**.) When the WE2 STOP signal is input before the start signal is input, the welding stop error occurs.

(h) RE-WELD

Select whether or not to supply welding current again at the same location if the monitored current is lower than the lower limit. The second welding current will be 5% greater than the setting value.

ON	Welding current will be supplied again.
OFF	Welding current will not be supplied again.



RE-WELD Timing Chart

(i) WELD TIME

Use this setting to change the units for TIME, UP SLOPE, and DOWN SLOPE—the settings available on the (3) SCHEDULE Screen.

СҮС	50 Hz: 1 CYC = 20 ms 60 Hz: 1 CYC = 16.6 ms
ms	—

(j) PAGE DOWN

When the cursor is at ∇ , moving the cursor down will change the display to the screen shown below. Use Δ or ∇ to scroll up or down through different screens.

a)— b)—	-MODE SELECT COMM CONTROL COMM MODE	OFF RS-232C	PAGE UP COMM SPEED	∆ 38. 4k	—d) —c)

a) COMM CONTROL

Selects a communication function.

OFF	DFF No communication	
>	One-way communication	
<-> Both-way communication		

b) COMM MODE

Selects a communication mode.

RS-485	Communication by RS-485	
RS-232C	Communication by RS-232C	

c) COMM SPEED

Selects a communication speed.

9.6k	Communication at 9600 bps
19.2k	Communication at 19200 bps
38.4k	Communication at 38400 bps

d) PAGE UP

When the cursor is at Δ , moving the cursor up will return the display to the previous screen.

For details of the external communication, see **11. External Communication Function**.

(8) MONITOR MODE Screen

	-MONITOR MODE		
(a)	WELD COUNT	0000	
(b) —	NO CURRENT TIME	50ms	
(c)	NO CURRENT LEVEL	00. 0kA	
(d)	NO VOLTAGE LEVEL	0. 00V	
(e)	- MONITOR FIRST TIME	15ms	
(f)	- MONITOR SLOPE MODE	EXCLUDE	
(g) —	- CURRENT MONITOR NUMBER	1	

(a) WELD COUNT


A count error signal is output if the number of welds deposited while the external weld count signal is input is smaller than the value set for **WELD COUNT** (weld count signal is turned off before the number of welds set for **WELD COUNT** is not deposited). (Refer to the figure below.)

For example, if you set the number of welds to 5 from the programmable logic controller, select "5" for **WELD COUNT** as well.

This function can be turned **ON** or **OFF** through **WELD COUNT** on the **(7) MODE SELECT Screen**. (Refer to **(7)(g)**.)

To clear the count error signal, you need to input the weld count signal again or add required number of welds to make up for insufficiency.

The count error signal is not cleared if the error reset signal is input. Also, when required number of welds are added to make up for insufficiency, the count error signal is output until the insufficient number of welds is complete.



(b) NO CURRENT TIME

The absence of welding current will not be detected as a no-current or no-voltage error (see **13. Troubleshooting**) as long as the absence lasts for a period within the time set here.

If, for example, you select 3 ms, the absence of current will not be detected as an error as long as it lasts no more than 3 ms. An absence of current will be detected as an error if it lasts for 4 ms or more.

(c), (d) NO CURRENT LEVEL/NO VOLTAGE LEVEL

Set the current or voltage level for determining the absence of current or voltage as a no-current or no-voltage error.

The **[TROUBLE] lamp** will light up, and operation will stop if the monitored current or voltage falls below the level set here.


In the case of primary current control, supplying current with the welding transformer's secondary side open will cause an excitation current to flow through the primary side. Set the current level slightly higher than the monitored current.

(Note) No judgment as to no-current or no-voltage error will be made if you select 00.0 kA/0.00 V. If the toroidal coil and the voltage detecting cable are disconnected in the second control, excessive current may flow.

(e) MONITOR FIRST TIME

Use this setting to specify the start time to measure the monitored value (current, voltage, power, pulse width). The start time can be set in a range from 0 to 15 ms. Use this setting to exclude the initial rise of current from measurement.

The monitored value will not be displayed if the weld time is shorter than **MONITOR FIRST TIME**. The monitored value will not be also checked against the upper and lower tolerance limits.



t = MONITOR FIRST TIME

(f) MONITOR SLOPE MODE

Select whether or not to include a slope period in the monitored value to be displayed.


EXCLUDE	Slope period will not be included.
INCLUDE	Slope period will be included.

(g) CURRENT MONITOR NUMBER

Use this setting to switch between monitored currents to be displayed when our monitor unit **MA-628A** is connected. This function is not used with this system.

(9) STEPPER COUNT Screen

The Power Supply can change the level of the welding current depending on the welding conditions. The function to increase the welding current is called the "step-up" function, and that to decrease the welding current is called the "step-down" function. Set the step-up or step-down timing based on the number of welds.



As shown in the above figure, the current is stepped up or down to the value for **STEP2** following completion of the specified number of welds for **STEP1**.

Similarly, the current is stepped up or down to the value for **STEP3** following completion of the specified number of welds for **STEP2**.

(a) START ON STEP

The counting of welds starts from the **STEP** set here.

If, for example, you select **START ON STEP #3** as shown above, welds will be counted from the first weld in **STEP3**, even if welding for the first time. Further, the welding current will be increased (or reduced) by the extent you have set this value for **STEP3**.

Set the desired **STEP** No. 1–9 for **VALVE1** and **VALVE2** respectively.

(b) STEP 1-9

Set the welding current step-up ratio (**RATIO**) and the number of welds (**COUNT**) for each **STEP**. The sequence will proceed to the next **STEP** when the set number of welds is reached.

(c) VALVE

Make settings for (a) and (b) above for each valve number. Change the number to set the schedule for each valve.

4. How to Operate Screens

(10) I/O CHECK Screen

This screen is used to check the status of the external I/O signals. The "*" symbol appears when the corresponding input signal is **ON**. The asterisk disappears if the signal is **OFF**. Set the cursor reading to "0" to turn **OFF** the output signal, and "1" to turn it **ON**. Reception of an input signal while this screen is showing will not activate the corresponding function. You cannot move to another screen while the 1ST or 2ND STAGE signal is input.

-I/O CHE	ECK			
SCH01*	SCH128*	ERR RST*	NG	0 SOL1 0
SCH02*	PARITY*	STP RST*	CATN	0 SOL2 0
SCH04*	WE CNT*	W3 STOP*	END	0
SCH08*	WELDON*	1ST STG*	CTER	0
SCH16*	THERMO*	2ND STG*	REDY	0
SCH32*	FLW SW*		STED	0
SCH64*			WESG	0

Input signal

SCH01:	Pin 5	SCH128:	Pin 12	ERR RST:	Pin 23
SCH02:	Pin 6	PARITY:	Pin 13	STP RST:	Pin 24
SCH04:	Pin 7	WE CNT:	Pin 14	W3 STOP:	Pin 25
SCH08:	Pin 8	WELDON:	Pin 19	1ST STG:	Pin 16
SCH16:	Pin 9	THERMO:	Pin 20	2ND STG:	Pin 17
SCH32:	Pin 10	FLW SW:	Pin 21		
SCH64:	Pin 11				

Output signal

NG:	Pin 26	SOL1:	Pin 36
CATN:	Pin 27	SOL2:	Pin 37
END:	Pin 28		
CTER:	Pin 29		
REDY:	Pin 30		
STED:	Pin 31		
WESG:	Pin 32		


4. How to Operate Screens

(11) RESET TO DEFAULT Screen

This screen is used to initialize the Power Supply's memory (i.e., to restore the initial settings).

Initialization will not clear the memory of the MA-627A.

To initialize, move the cursor (>) over YES or NO and press the [ENTER] key.



(a) YES	Initializes the Power Supply memory (restores the initial settings). After initialization, the screen will reflect the settings shown in this chapter.
(b) NO	Returns the display to the MENU screen without initializing the Power Supply memory.

(12) PROGRAM PROTECT MODE Screen

When this function is used, set values cannot be changed by any person other than the supervisor.

PROGRAM PROTECT is usually set to OFF. When it is set to ON, set values cannot be changed until **PROGRAM PROTECT** is set to OFF again. Follow the procedure below to change the setting of **PROGRAM PROTECT**.

① Turn on the power supply with the [∇ (DOWN)] key pressed or connect the MA-627A to the circuit cable with the power supply turned on. The following screen is displayed.

-PROGRAM PROTECT MODE			
PROGRAM PROTECT	OFF		

⁽²⁾ When the **[ENTER] key** is pressed after the **[+ON] key** is pressed, ON is displayed.

You cannot go to other screens from this screen. Also, the external signals cannot be received.

4. How to Operate Screens

③ Turn off the power supply and turn on it again, or disconnect the **MA-627A** with the power supply turned on and connect to the circuit cable again.

When **PROGRAM PROTECT** is ON, the display of the **MENU screen** changes. **COPY SETUP DATA**, **I/O CHECK** and **RESET TO DEFAULT** are not displayed. On the other screens, the cursor can be moved and the settings can be checked, but the settings cannot be changed.

<When the PROGRAM PROTECT is OFF>

[MENU]	
>POWER SUPPLY STATE	COPY SETUP DATA
SCHEDULE	MODE SELECT
MONITOR	MONITOR MODE
MONITOR SET	STEPPER COUNT
	I/O CHECK
	RESET TO DEFAULT


<When the PROGRAM PROTECT is ON>

[MENU]	
>POWER SUPPLY STATE	
SCHEDULE	MODE SELECT
MONITOR	MONITOR MODE
MONITOR SET	STEPPER COUNT

5. Connection Procedures

(1) Basic Configuration


1 When using our dedicated transformer



All items are sold separately except for the **IS-600A**. (See **10. (2) Options (Sold Separately)**.)




Be sure to use the **SK-05741** [SENS] cable to connect the **IS-600A** with our welding transformer. (See **10.** (2) Options (Sold Separately).)



② When using our conventional transformer


All items are sold separately except for the **IS-600A**. (See **10. (2) Options (Sold Separately)**.)





③ When using another manufacturer's transformer

All items are sold separately except for the **IS-600A**. (See **10. (2) Options (Sold Separately)**.)




(2) Connecting


1 When using our dedicated transformer

1) Connection to the transformer's input terminal block and [SENS] cable Use the output cable to connect the welding power output terminal block on the Power Supply's rear panel with the welding transformer's input terminal block. For the output cable specification, see **10. (2) Options (Sold Separately)**.

According to the setting current value, the welding head and the secondary cable, connect the output cable to 0 V and 15 V, or 0 V and 13 V of the welding transformer's input terminal block.



When it is hard to connect cables to the **IS-600A** and the welding transformer terminal blocks, use the provided copper bars for mounting cable.



Use a sensing cable to connect the **Welding Transformer [I/O] connector** to the welding transformer. Bear the following in mind.

- **Do NOT connect** the **[COIL IN] connector** to the toroidal coil connector on the front panel.
- Be sure to keep the thermostat input terminal (No. 26) for the External Input/Output Signal open. (See **6. Interface**.)
- Connect the attached voltage detecting cable to the electrodes of welding head and insert the dedicated connector into the transformer's front panel in constant-voltage/constant-power control or when monitoring the secondary voltage.

2) Connecting the power cable

Connect the power supply to the **Welding Power Supply Breaker** on the rear panel and ground the [**PE**] terminal. (See **10. (2) Options (Sold Separately)**.)

 Connect the necessary cables to the Connecting terminal block for External Input/Output Signal (See 6. Interface.)

(Note) Install the attached ferrite core to the portion of the external input/output signal cable within 10 cm of the **IS-600A**.

4) Connecting the program unit

Connect the circuit cable to the **[PROGRAM MONITOR I/O] connector** on the front panel.

(Note) Install the attached ferrite core to the portion of the program unit connecting cable within 10 cm of the program unit.

- **2** When using our conventional transformer
 - 1) Connection to the transformer's input terminal block and [SENS] cable Use the output cable to connect the welding power output terminal block on the Power Supply's rear panel with the welding transformer's input terminal block. For the output cable specification, see **10. (2) Options (Sold Separately)**.



Use a sensing cable to connect the **Welding Transformer [I/O] connector** to the welding transformer. Bear the following in mind.



- Be sure to keep the thermostat input terminal (No. 26) for the External Input/Output Signal open. (See **6. Interface**.)
- Connect the attached voltage detecting cable to the electrodes of welding head and insert the dedicated connector into the transformer's front panel in constant-voltage/constant-power control or when monitoring the secondary voltage.
- Connecting a toroidal coil for secondary current detection
 Connect a toroidal coil to the [COIL IN] connector on the front panel. (Do not connect a toroidal coil when our transformer is used.)
- 3) Connecting the power cable

Connect the power supply to the **Welding Power Supply Breaker** on the rear panel and ground the [**PE**] terminal. (See **10. (2) Options (Sold Separately)**.)

- Connect the necessary cables to the Connecting terminal block for External Input/Output Signal (See 6. Interface.)
- Connecting the program unit Connect the circuit cable to the [PROGRAM MONITOR I/O] connector on the front panel.

③ When using another manufacturer's transformer

1) Connection to the transformer's input terminal block

Use the output cable to connect the welding power output terminal block on the Power Supply's rear panel with the welding transformer's input terminal block. For the connection to the welding transformer, refer to the operation manual for the welding transformer.

Connecting a toroidal coil for secondary current detection Connect a toroidal coil to the [COIL IN] connector on the front panel. (Do not connect a toroidal coil when our transformer is used.)

3) When there is thermo sensor in the welding transformer Connect to the thermo input terminal (Terminal No. 20) for External Input/Output Signals. (See 6. Interface.)

When detecting the secondary voltage Connect the voltage detecting cable to the voltage input terminal (Terminal No. 38 and 39). (See 6. Interface.)


- 5) Connecting the power cable Connect the power supply to the Welding Power Supply Breaker on the rear panel and ground the [PE] terminal. (See 10.(2) Options (Sold Separately).)
- 6) Connect the necessary cables to the Connecting terminal block for External Input/Output Signal (See 6. Interface.)

7) Connecting the program unit

Connect the circuit cable to the **[PROGRAM MONITOR I/O] connector** on the front panel.


6. Interface

(1) Connection Diagram for External Input/Output Signals





Be sure to keep the **THERMOSTAT** (pin 20) open when connecting our welding transformer to the Power Supply.



Terminal strip specifications		
Terminals connectable	Two pieces max.	
Pressure wire connectors	M3 or M3.5 (7.1 mm wide)	
Recommended wire size	0.75 mm ² min. for pin nos. 34 to 37 0.5 mm ² min. for pin nos. 1 to 33, 38 and 39	

(2) Description of External I/O Signals


Pin No.	Name	Description
1	INT.24V	24 V DC present. When using a contact, open collector (sink type), or PLC (programmable logic controller) as an input signal (e.g., for startup or schedule selection), connect pins 1 and 2. Note: Do not use pin 1 unless connecting it to pin 2 or 3. Failure to observe this precaution will result in malfunction.
2	EXT.COM	When using a contact, open collector (sink type), or PLC (programmable logic controller) as an input signal (e.g., for startup or schedule selection), connect pins 1 and 2. When using an external power supply as input signal, open pin 1 and connect pin 2 and the positive pin of the DC power supply or the COM pin.
3	STOP	Normally, connect pins 3 and 1. Opening this pin will cause an error message to appear, stopping operation. Open this pin when you wish to stop the sequence halfway through when using starting signal self-hold input.
4	СОМ	COM pin. This pin is internally connected to the GND chassis.
5 6 7 8 9 10 11 12	SCH 1 SCH 2 SCH 4 SCH 8 SCH16 SCH32 SCH64 SCH128	Schedule input pins. 5: Schedule 1; 6: Schedule 2; 7: Schedule 4; 8: Schedule 8; 9: Schedule 16; 10: Schedule 32; 11: Schedule 64; 12: Schedule 128 (See 4. (7) (e) Schedule Nos. and Schedule Selection Pins .)
13	WE1 STOP/ PARITY	Parity input or WE1 stop input pin. Switch between functions via the settings on the (7) MODE SELECT screen described in Chapter 4. When PARITY CHECK = ON This pin serves as the parity input pin, and allows for detection of failure resulting from a wire break in the schedule selection signal lines. Be sure that the total number of closed schedule selection and parity signal lines is always odd. (See 4. (7) (e) Schedule Nos. and Schedule Selection Pins.) When PARITY CHECK = OFF This pin serves as the WE1 stop pin. The sequence will switch to COOL1 if this signal is closed during the WE1 sequence operation.
14	WE2 STOP/ WELD COUNT	Weld count input or WE2 stop input pin.Switch between functions via the settings on the (7) MODESELECT screen described in Chapter 4.When WELD COUNT = ONThis pin serves as the weld count input pin. This pin allows youto determine whether or not the number of deposited welds hasreached the WELD COUNT setting.When WELD COUNT setting.When WELD COUNT = OFFThis pin serves as the WE2 stop input pin. The sequence willswitch to COOL2 if this signal is closed during the WELD2sequence operation.

Pin No.	Name	Description
15	СОМ	COM pin. This pin is internally connected to the GND chassis.
16	1ST	1ST STAGE input pin. (This function is not available with this Power Supply.)
17	2ND	2ND STAGE input pin. Closing this pin will start the sequence.
18	СОМ	COM pin. This pin is internally connected to the GND chassis.
19	WELD ON	Weld ON pin. Close this pin to turn ON the WELD ON signal, and open it to turn it OFF. Leaving this pin open will shut off welding current even when the sequence operation is performed. Use this pin, for example, to start the sequence experimentally.
20	THERMOSTAT	Thermostat input pin. Connect to the transformer thermostat or diode thermostat. Opening the pin will result in a thermostat error. Note that when connecting a sensing cable to the connector using our welding transformer, this pin must be left open. (See 5. Connection Procedures .)
21	FLOWSWITCH	Flow switch input pin. Opening this pin will result in a flow rate error.
22	СОМ	COM pin. This pin is internally connected to the GND chassis.
23	ERROR RESET	Error/caution reset input pin. Eliminate the cause of error or caution and close this pin to reset the error or caution indication.
24	STEP RESET	Step reset input pin. Closing this pin while the STEPPER is ON will reset the STEP number to 1.
25	WE3 STOP	WE3 stop input pin. Closing this pin during the WELD3 sequence will switch the sequence to HOLD. The current shutoff error occurs when the WE3 STOP signal is input before the start signal is input, even if WELD1 or WELD2 has been set.
26	NG	Error signal output pin. This signal is output upon completion of the welding sequence in the event of an operational error. If an error occurs, operation will halt until the reset signal is input. The contact is rated at 24 V DC at 20 mA (semiconductor switch).
27	CAUTION	Caution signal output pin. This pin is closed upon completion of the welding sequence if the measured value is outside the range set on the MONITOR SET screen. You can continue with your welding task even if a caution signal is activated. To cancel this caution output, input the reset or start signal. The contact is rated at 24 V DC at 20 mA (semiconductor switch).
28	END	End signal output pin. This pin is closed for a preset length of time after completion of the sequence. It is closed during the HOLD time, or for the length of time during which this pin is closed can be set in a range from 10 ms to 200 ms and in units of 10 ms. This signal is also output when the sequence operation is performed in the WELD OFF state. The contact is rated at 24 V DC at 20 mA (semiconductor switch).

6. Interface


Pin No.	Name	Description
29	COUNT ERROR	Count error output pin. This signal is output if the set number of welds is not reached during count input. The contact is rated at 24 V DC at 20 mA (semiconductor switch).
30	READY	Ready output pin. This pin is closed when the Power Supply is able to supply welding current. The pin is opened in the WELD OFF or error state. The contact is rated at 24 V DC at 20 mA (semiconductor switch).
31	STEP END	Step end output pin. This signal is output upon completion of the last step during the step-up operation and continues until the step reset signal is input. The contact is rated at 24 V DC at 20 mA (semiconductor switch).
32	WELD SIGNAL	Welding current timing output pin. This signal is output at the beginning of WELD1, 2, or 3. The contact is rated at 24 V DC at 20 mA (semiconductor switch).
33	ОИТ СОМ	Common pin for output pins. This pin is the common pin for the NG, CAUTION, END, COUNT ERROR, READY, STEP END, and WELD ON pins.
34	SOL POWER	Power input pins to drive the solenoid valve. Input 120 V AC or 24 V AC/DC power.
35	SOL COM	COM pin for the solenoid valve.
	SOL 1 SOL 2	Solenoid valve output pins. 36: SOL1; 37: SOL2 These pins are closed for the duration of 2ND STAGE input. The contacts are rated at 120 V AC or 24 V AC/DC at 0.5 A (semiconductor switches). Use a solenoid valve with a current capacity of 0.5 A or less.
38 39	VOLT SENS	Secondary voltage input pins. Connect to the electrodes of the welding head during constant-power or constant-voltage control or when monitoring the secondary voltage. (However, do NOT connect when using our dedicated inverter transformer and the voltage detecting cable.)

* When using 24 V DC solenoid, install diodes on measures to prevent surge voltage. Example) When inputting + to Terminal 34 and – to Terminal 35.




(3) Connection of Input Signals

1) Connection with equipment having a contact input Connect pins 1 and 2.




 Connection with equipment featuring NPN open collector output (when using internal power supply) Connect pins 1 and 2.




3) Connection with equipment featuring PNP current output (when using external power supply)

Connect the negative side of an external 24 V DC power supply to pin 2.



4) Connection with equipment featuring NPN open collector output (when using external power supply)

Connect the positive side of an external 24 V DC power supply to pin 2.



(Note) The circuit between pins 1-2-3, 4-5, 18-19-20, and 21-22 are closed when shipped. Disconnect unnecessary jumper wires referring to each connection.

7. Basic Operation

(1) Turn on the welding power.

1) Turn on the welding power. The **[WELD POWER] lamp** lights; the **[READY] lamp** blinks for 7 seconds, then goes off.

CAUTION

Check that the display screen and lamps are turned on normally and the fan motor is operated.

(2) Set the program unit.

- 1) Call up the **MENU screen**. If another screen is displayed, press the **[MENU] key**.
- 2) Move the cursor (>) to **SCHEDULE**, then press the **[ENTER] key**.
- 3) Set each item. For the initial weld, set each item slightly lower than the standard value.

(3) Start operation.

1) Input the start signal while the **[READY] lamp** is NOT on, and check each sequential operation.



WARNING

When confirming operation, check that the **SQD time** (squeeze delay time) and the **SQZ time** (squeeze time) are sufficient. If the welding current flows before the welding electrode force becomes sufficient, explosion may occur.

- 2) If no error is detected in 1) above, position a workpiece and begin welding. Turn on the [WELD ON/OFF] key on the front panel of the Power Supply, WELD ON/OFF of MA-627A and activate the external WELD ON signal. Check that the [READY] lamp is lit, and then supply the welding current. At this time, confirm that the welding current is flowing normally by checking the [WELD] lamp and the MONITOR screen.
- 3) Re-set the schedule to ensure that the workpiece will be welded adequately.
- 4) When welding multiple workpieces according to multiple schedules, change the **SCHEDULE #** and set a new time and welding current.
- 5) Set the upper and lower limits on the **MONITOR SET screen** for each **SCHEDULE #**.
- (Note) The Power Supply writes data into the flash memory on the control board when a setting is changed or a schedule data is copied. The **[READY] lamp** on the front panel and the external **READY** signal are turned off during writing. Check that the **[READY] lamp** is turned on to start welding. It takes about 2 seconds at longest to write data into the flash memory.


(4) Turn off the welding power.

1) Turn off the welding power; all LED lamps will be extinguished.

7. Basic Operation


8. Timing Chart

(1) Basic Sequence



- (Note 1) To stop the sequence during SQD or SQZ (possible only when LATCHED or MAINTAINED is selected for START SIG. MODE; see 4.(7)(b)), stop the start signal input for a period longer than that set for DELAY START SET.
- (Note 2) Repetition operation is not performed if the OFF time is not set.

(2) Detailed Description of Welding Current and Sequence in the Event of an Error



- (Note 1) The CAUTION output is ON until the RESET signal or the next start signal is received.
- (Note 2) The STEP END output is ON until the STEP RESET signal is received.

9. Maintenance


(1) Filter Cleaning and Replacement

The Power Supply's front air inlet is fitted with a filter. Clean the filter once every six months, observing the following procedure. If the filter is badly stained, replace it with a new one. If the filter is clogged, air will not flow adequately, causing internal temperature to rise and leading to malfunction.

• We do not offer replacement filters; please purchase these from the appropriate manufacturer.

[Manufacturer and Model Number of Replacement Filter] Manufacturer: NITTO KOGYO CORPORATION Model Number: SLP-F1 (10 sheet)

• Cut the replacement filter as shown:








Fan motor may hurt your finger. When cleaning or replacing the filter, be sure to turn off the power supply first.

9. Maintenance

- 1) Remove the filter cover as shown in the right-hand figure.
- 2) Filter is inside the filter cover (See the figure below). Remove it and cleanse with



3) Allow the filter to dry sufficiently. Then put the cleaned filter (or the new filter if replaced) back on the filter cover and re-attach the filter cover to the air inlet.

9. Maintenance

10. Specifications

(1) Specifications

*: selectable for every 255 schedules

Madal Na		IS-600A-		
Model No.		00-01	00-02	01-01
Welding power		3-phase, 200–240 V AC ±10% (50/60 Hz) (Voltage level is factory-set and is not field selecta		
Max. output current		600 A (peak value)		
Average max. duty cycle (See 10.(3).)	Output current [() indicates duty cycle.]	600 A (3%) 500 A (5%) 200 A (22.2%) 100 A (40%)		
Number of schedules		255		
Output frequency		1 kHz		
Control method *		Primary constant-current effective value control Secondary constant-current effective value control Secondary constant-power effective value control Primary constant-current peak value control Secondary constant-voltage effective value control Constant-phase control		value control value control control
Timer setting range *	SQD / squeeze delay time SQZ / squeeze time U1 / upslope 1 time WE1 / weld 1 time D1 / downslope 1 time COOL1 / cooling 1 time U2 / upslope 2 time WE2 / weld 2 time D2 / downslope 2 time COOL2 / cooling 2 time U3 / upslope 3 time WE3 / weld 3 time D3 / downslope 3 time HOLD / hold time OFF / off time (Note 1)			
Transformer turns ratio * (P/S RATIO)		1.0–199.9		
Pulsation setting * (PULSATION)		01–19		
Valve setting * (VALVE)		2 valves (VALVE1, VALVE2)		
Control gain * (GAIN)		1–9		
Setting range * (HEAT)	Constant current control (Note 2) Constant power control Constant voltage control Constant phase control	02.0–20.0 kW 0.50–9.99 0.20–9.99 V 0.20–9.99		0.50–9.99 kA 0.50–9.99 kW 0.20–9.99 V 10.0–99.9%
Current monitor * (CURRENT LOW/HIGH)	HIGH (upper limit) LOW (lower limit)			0.00–9.99 kA 0.00–9.99 kA

		IS-600A-			
Model No.		00-01	00-02	01-01	
Power monitor * (POWER LOW/HIGH)	HIGH (upper limit) LOW (lower limit)	00.00–99.99 kW 00.00–99.99 kW			
Voltage monitor * (VOLT HIGH/LOW)	HIGH (upper limit) LOW (lower limit)	0.00–9.99 V 0.00–9.99 V			
Pulse width monitor * (PULSE % HIGH)	HIGH (upper limit)	010–100%			
Step-up/-down (STEPPER COUNT)	STEP Up (down) ratio (RATIO) Counter setting (COUNT)	1–9 (9 steps) 50–200% 0000–9999			
Weld count monitor (WELD COUNT)		0000–9999			
State indicator LED		[WELD POWER] lamp [READY] lamp [START] lamp [WELD] lamp [TROUBLE] lamp [WELD ON/OFF] lamp			
Cooling method		Air-cooled (fan mo	tor)		
Operating environment (Note 3)	Ambient temperature Humidity Altitude	+5 to +40°C 90% max. (no condensation) 1000 m max.			
Transportation and storage conditions	Ambient temperature Humidity	-10 to +55°C 90% max. (no condensation)			
Heat-resistant class		E			
Case protection		IP20			
	Overcurrent	325 A Fuse			
Protective functions	No-current	 Power is turned off in the following cases: a. When a secondary current is not detected in Secondary constant-current effective value control, Secondary constant-power effective value control, Constant-phase control. b. When a primary current is not detected in Primary constant-current effective value control or Primary constant-current peak value control. 		detected in tive value control, ve value control, or ected in Primary ontrol or Primary	
	No-voltage	Under Secondary constant-voltage effective value control or Secondary constant-power effective value control, the supply of current is stopped when a secondary voltage cannot be detected.		r effective value bed when a	
	Temperature	Overheating of power unit of inverter and welding transformer are detected.			
Protective functions	Self-diagnostic error	Setting dates (e.g.	, schedule settings	s) are diagnosed.	
Setting accuracy (Note 4)		Within ±3% of full	scale		
Repetition accuracy (Note 4)		Within 4% of full so	cale		
Outline dimensions		457 (H) mm x 232 (W) mm x 608 (D) mm (Not including projection)			
Mass		31 kg			

Model No.		IS-600A-		
Model No.			00-02	01-01
Accessories	Fixing bracket: Cable gland: Operation manual: Copper bar for mounting cable: Ferrite core (Noise filter):	2 pcs. 3 pcs. 1 copy 7 pcs. 2 pcs.		

Note 1) No repetitive operation will be performed if "0" is selected for OFF (off time).

Note 2) Primary current can be set up to 600 A.

Note 3) Use this product in the environment without conductive dust. If conductive dust enters in the product, this may result in a failure, electric shock, or fire. When using this product in this environment, make contact with us.

Note 4) · Using the fixed load and the specified transformer

•The weld time is 100 ms. The measurement range is from 60 ms to 100 ms.

•The voltage may be out of the range due to the induced electromotive force.

10. Specifications



1) Input Cables

Customer-procured cables must meet the specifications at right.

• IS-600A-00-01/-01-01

Model No.	Length
PK-06888-002	2 m
PK-06888-005	5 m
PK-06888-010	10 m
PK-06888-015	15 m
PK-06888-020	20 m

	Specifications of Standard Cable				
	Rated Voltage	600 V AC min.			
7	Section Area	38 mm ² min.			
	No. of Cores	4			
7	Cable Dia.	32 mm max.			

• IS-600A-00-02

Model No.	Length			s of CE Marking iant Cable
PK-06888-102	2 m		Rated Voltage	500 V AC min.
PK-06888-105	5 m		Section Area	35 mm ² min.
PK-06888-110	10 m		No. of Cores	4
PK-06888-115	15 m	ľ	Cable Dia.	38 mm max.
PK-06888-120	20 m			

2) Output Cables

Customer-procured cables must meet the specifications at right.

Model No.	Length	
PK-06889-002	2 m	
PK-06889-005	5 m	
PK-06889-010	10 m	

Specifications of Standard Cable and CE Marking Compliant Cable		
Rated Voltage	750 V AC min.	
Section Area	35 mm ² min.	
No. of Cores	3	
Cable Dia.	32 mm max.	

3) Others


Item	Model No.	Length]	
	SK-05741-002 *1	2 m	*1:	Used for connecting to our
	SK-05741-005 *1	5 m		dedicated inverter transformer.
	SK-05741-010 *1	10 m	*2:	
[SENS] cable	SK-07527-002 *2	2 m	Z .	Used for connecting to our conventional inverter
	SK-07527-005 *2	5 m		transformer.
	SK-07527-010 *2	10 m		

10. Specifications

ltem	Model No.	Length
	SK-02136-002	2 m
	SK-02136-005	5 m
Circuit cable	SK-02136-010	10 m
	SK-02136-015	15 m
	SK-02136-020	20 m

ltem	Model No.	Length
	MB-400L (Belt, 470 mm approx.)	
Toroidal coil	MB-800L (Belt, 890 mm approx.)	Cable, 2.8 m

(3) Duty Cycle Graph



(4) Board List for Maintenance

For repair or replacement, contact us.

Also, for models other than the models shown below, contact us.


Model Board	IS-600A-00-01/00-02/01-01
Main control board	ME-2037-00S1
Drive board	ME-2046-00
IGBT gate board	AS1005542
Snubber board	ME-2051-01

(5) Major Components List

ltem	Q'ty
Fan motor	1
Power transformer	1
Thermal protector	2
Diode module	1
IGBT module	2
Fast-blow fuse	1
Circuit breaker	1
Electromagnetic contactor	1

10. Specifications

(6) Schematic



10. Specifications

POWER SUPPLY STATE			
LCD CONTRAST			
CONTROL #			
PROGRAMMED DATE			
MODE SELECT			
DELAY-START SET			
START SIG. MODE			
END SIG. TIME			
END SIG. MODE	0	-	,
PARITY CHECK	NO	•	OFF
STEPPER MODE	NO	•	OFF
WELD COUNT	NO	•	OFF
RE-WELD	NO	•	OFF
WELD TIME	sm	•	СУС
COMM CONTROL	OFF	۰ ۱	, , ,
COMM MODE	RS-232C	2C ,	RS-485
COMM SPEED	9.6k	9.6k , 19.2k	, 38.4k
MONITOR MODE			
WELD COUNT			
NO CURRENT TIME			
NO CURRENT LEVEL			
NO VOLTAGE LEVEL			
MONITOR FIRST TIME			

10. Specifications 10-8

CURRENT MONITOR NUMBER

MONITOR SLOPE MODE

F	
∠	
\supset	
0	
C	
മ	
ш	
ቢ	
\frown	

STEPPER COUNT	COUNT				
	VALVE #	× ·	_		2
ITEMS		RATIO	RATIO COUNT	RATIO	COUNT
	STEP 1	100%		100%	
	STEP 2				
	STEP 3				
	STEP 4				
STEPPER	STEP 5				
	STEP 6				
	STEP 7				
	STEP 8				
	STEP 9				

(7) Schedule Data Table

	VALVE #															
GAIN													 		 	
PULSATION													 			
CTRL																
IDTH	WE3															
PULSE WIDTH	WE2															
PUL	WE1															
Ř	WE3															
POWER	WE2															
д.	WE1															
	WE3															
VOLT	WE2															
	WE1															
	WE3															
WE2																hi L
ວັ WE1																0
OFF	OFF															
HOLD																As needed conv and use this nade
DOWN3																
WE	3															
UP3	3															20
CO	OL2												 			▼ *
DO	WN2												 			
WE	2															
UP2	2															
CO	OL1															
DO	WN1															
WE1															 	
UP1															 	
SQZ																
SQI																
ITEMS	SCHEDULE#															
	sci															

IS-600A

As needed, copy and use this page.

	WE3	HIGH]
Й			 										
PULSE	WE2	н нен											
	WE1	HIGH											
	E3	LOW											
	WE3	HIGH											
ĒR	2	LOW											
POWER	WE2	HIGH											
	-	LOW											
	WE1	HIGH											نە
	3	LOW											* As needed, copy and use this page.
	WE3	HIGH											use th
		LOW H											y and
VOLT	WE2	HIGH 1								 			 ed, cop
		LOW F											neede
	WE1	HIGH L	 							 	 	 	 * As
		HI MOT	 							 	 	 	
	WE3	HIGH LO											
CURR	WE2	H LOW	 										
0	_	HIGH											
	Ξ	LOW											
	WE1	HIGH									 	 	
ITEMS	/	SCHDULE#											

IS-600A

11. External Communication Function

(1) Introduction


IS-600A can be used to set schedules from an externally-connected personal computer (abbreviated as PC) or to read monitored data and several kinds of status data.

(2) Data Transmission

ltem	Content
Transmission Mode	Select either of the followings at MODE SELECT Screen : * RS-485, Asynchronous, Half-Duplex * RS-232C
Transmission Rate	Select either of the followings at MODE SELECT Screen : 9600, 19200, 38400 bps
Data Format	Start bit: 1, Data bit: 8, Stop bit: 1, Parity bit: Even
Character Code	ASCII
Checksum Data	None
Connector	D-Sub 9 pins Pin Position In RS-485, 4: SG, 6: RS+, 9: RS- In RS-232C, 2: RXD, 3: TXD, 5: SG, 7: RTS


(3) Configuration

① RS-485



- Note 1: When controlling two or more devices with one host computer, register the device No. (CONTROL#) for each device. Set the device No. at **POWER SUPPLY STATE Screen** (See **4.(2)(b)**).
- Note 2: Do not assign one number to more than one device. Also, do not send data simultaneously from two or more devices in the single-directional communication mode. Otherwise, data collision and inappropriate system operations may result.
- Note 3: The RS-232C/RS-485 conversion adapter is not included in the accessories. It is required to prepare the adapter at customer's side.

2 RS-232C



Only a device can be connected.

(4) Protocol

1 Single-directional Communication Mode

(When --> is selected at COMM CONTROL in MODE SELECT Screen)

1) Monitor Data

Data strings:

! <u>01</u>	001	<u>:m</u> ,	<u>120</u>	, <u>1.20</u>	, <u>0.50</u> ,	00.60	, <u>20.0</u>	, <u>200</u>	, <u>2.00</u> ,	<u>1.50</u> ,	, <u>03.00</u> ,	, <u>40.0</u> ,
А	В	С	D	Е	F	G	Н	I	J	K	L	М

ADevice No.Fixed to 2 digits (01 to 31)BSchedule No.Fixed to 3 digits (001 to 255)CUnit of monitor timem: ms C: CYCDMonitor time of WE1Fixed to 3 digits (000 to 600) (ms) Fixed to 3 digits (000 to 030) (CYC)E*Monitor current of WE1Fixed to 4 digits (0.00 to 9.99) (kA)FMonitor voltage of WE1Fixed to 4 digits (0.00 to 9.99) (V)GMonitor power of WE1Fixed to 5 digits (000 to 600) (ms) Fixed to 5 digits (000 to 99.99) (kW)HMonitor power of WE1Fixed to 4 digits (0.00 to 99.99) (%)IMonitor time of WE2Fixed to 3 digits (000 to 030) (CYC)J*Monitor current of WE2Fixed to 4 digits (0.00 to 9.99) (kA)KMonitor voltage of WE2Fixed to 4 digits (0.00 to 9.99) (kA)KMonitor outrage of WE2Fixed to 4 digits (0.00 to 9.99) (kA)KMonitor rourrent of WE2Fixed to 4 digits (0.00 to 9.99) (kA)KMonitor power of WE2Fixed to 4 digits (0.00 to 9.99) (kW)MMonitor power of WE2Fixed to 4 digits (0.00 to 9.99) (kW)NMonitor power of WE2Fixed to 4 digits (0.00 to 99.99) (kW)NMonitor power of WE3Fixed to 3 digits (000 to 600) (ms) Fixed to 3 digits (000 to 030) (CYC)	
CUnit of monitor timem: ms C: CYCDMonitor time of WE1Fixed to 3 digits (000 to 600) (ms) Fixed to 3 digits (000 to 030) (CYC)E*Monitor current of WE1Fixed to 4 digits (0.00 to 9.99) (kA)FMonitor voltage of WE1Fixed to 4 digits (0.00 to 9.99) (V)GMonitor power of WE1Fixed to 5 digits (00.00 to 99.99) (W)HMonitor power of WE1Fixed to 4 digits (00.00 to 99.99) (%)IMonitor time of WE2Fixed to 3 digits (000 to 600) (ms) Fixed to 3 digits (000 to 030) (CYC)J*Monitor current of WE2Fixed to 4 digits (0.00 to 9.99) (kA)KMonitor voltage of WE2Fixed to 4 digits (0.00 to 9.99) (V)LMonitor power of WE2Fixed to 4 digits (0.00 to 9.99) (W)MMonitor power of WE2Fixed to 4 digits (0.00 to 9.99) (W)LMonitor power of WE2Fixed to 4 digits (0.00 to 9.99) (W)MMonitor power of WE2Fixed to 5 digits (00.00 to 9.99) (W)MMonitor power of WE2Fixed to 4 digits (00.00 to 9.99) (W)MMonitor power of WE2Fixed to 5 digits (00.00 to 9.99) (W)MMonitor power of WE2Fixed to 5 digits (00.00 to 99.99) (W)MMonitor power of WE3Fixed to 3 digits (000 to 600) (ms)	
CUnit of monitor timeC: CYCDMonitor time of WE1Fixed to 3 digits (000 to 600) (ms) Fixed to 3 digits (000 to 030) (CYC)E*Monitor current of WE1Fixed to 4 digits (0.00 to 9.99) (kA)FMonitor voltage of WE1Fixed to 4 digits (0.00 to 9.99) (V)GMonitor power of WE1Fixed to 5 digits (00.00 to 99.99) (W)HMonitor pulse width of WE1Fixed to 4 digits (00.00 to 99.99) (%)IMonitor time of WE2Fixed to 3 digits (000 to 600) (ms) Fixed to 3 digits (000 to 030) (CYC)J*Monitor current of WE2Fixed to 4 digits (0.00 to 9.99) (kA)KMonitor voltage of WE2Fixed to 4 digits (0.00 to 9.99) (W)LMonitor pulse width of WE2Fixed to 4 digits (0.00 to 9.99) (W)MMonitor pulse width of WE2Fixed to 4 digits (0.00 to 9.99) (W)KMonitor voltage of WE2Fixed to 4 digits (0.00 to 9.99) (W)MMonitor pulse width of WE2Fixed to 5 digits (00.00 to 9.99) (W)MMonitor pulse width of WE2Fixed to 5 digits (00.00 to 9.99) (W)MMonitor pulse width of WE2Fixed to 5 digits (00.00 to 99.99) (%)MMonitor pulse width of WE2Fixed to 3 digits (000 to 600) (ms)MMonitor pulse width of WE2Fixed to 3 digits (000 to 600) (ms)	
DMonitor time of WE1Fixed to 3 digits (000 to 030) (CYC)E*Monitor current of WE1Fixed to 4 digits (0.00 to 9.99) (kA)FMonitor voltage of WE1Fixed to 4 digits (0.00 to 9.99) (V)GMonitor power of WE1Fixed to 5 digits (00.00 to 99.99) (kW)HMonitor pulse width of WE1Fixed to 4 digits (00.0 to 99.99) (kW)IMonitor time of WE2Fixed to 3 digits (000 to 600) (ms)J*Monitor current of WE2Fixed to 4 digits (0.00 to 9.99) (kA)KMonitor voltage of WE2Fixed to 4 digits (0.00 to 9.99) (kA)KMonitor power of WE2Fixed to 4 digits (0.00 to 9.99) (kA)Monitor power of WE2Fixed to 4 digits (0.00 to 9.99) (kA)KMonitor power of WE2Fixed to 4 digits (0.00 to 9.99) (V)LMonitor power of WE2Fixed to 5 digits (00.00 to 99.99) (kW)MMonitor pulse width of WE2Fixed to 3 digits (00.00 to 99.99) (%)NMonitor pulse width of WE2Fixed to 3 digits (000 to 600) (ms)	
FMonitor voltage of WE1Fixed to 4 digits (0.00 to 9.99) (V)GMonitor power of WE1Fixed to 5 digits (00.00 to 99.99) (kW)HMonitor pulse width of WE1Fixed to 4 digits (00.0 to 99.9) (%)IMonitor time of WE2Fixed to 3 digits (000 to 600) (ms) Fixed to 3 digits (000 to 030) (CYC)J*Monitor current of WE2Fixed to 4 digits (0.00 to 9.99) (kA)KMonitor voltage of WE2Fixed to 4 digits (0.00 to 9.99) (kA)LMonitor pulse width of WE2Fixed to 5 digits (00.00 to 9.99) (kW)MMonitor pulse width of WE2Fixed to 5 digits (00.00 to 99.99) (kW)MMonitor pulse width of WE2Fixed to 4 digits (0.00 to 99.99) (%)NMonitor pulse width of WE2Fixed to 4 digits (00.00 to 99.99) (%)	
GMonitor power of WE1Fixed to 5 digits (00.00 to 99.99) (kW)HMonitor pulse width of WE1Fixed to 4 digits (00.0 to 99.9) (%)IMonitor time of WE2Fixed to 3 digits (000 to 600) (ms) Fixed to 3 digits (000 to 030) (CYC)J*Monitor current of WE2Fixed to 4 digits (0.00 to 9.99) (kA)KMonitor voltage of WE2Fixed to 4 digits (0.00 to 9.99) (V)LMonitor power of WE2Fixed to 5 digits (00.00 to 99.99) (V)Monitor pulse width of WE2Fixed to 4 digits (0.00 to 99.99) (W)MMonitor pulse width of WE2Fixed to 4 digits (00.00 to 99.99) (%)NMonitor time of WE3Fixed to 3 digits (000 to 600) (ms)	
HMonitor pulse width of WE1Fixed to 4 digits (00.0 to 99.9) (%)IMonitor time of WE2Fixed to 3 digits (000 to 600) (ms) Fixed to 3 digits (000 to 030) (CYC)J*Monitor current of WE2Fixed to 4 digits (0.00 to 9.99) (kA)KMonitor voltage of WE2Fixed to 4 digits (0.00 to 9.99) (V)LMonitor power of WE2Fixed to 5 digits (00.00 to 99.99) (W)MMonitor pulse width of WE2Fixed to 4 digits (0.00 to 99.99) (%)NMonitor pulse width of WE2Fixed to 4 digits (00.00 to 99.9) (%)	
IMonitor time of WE2Fixed to 3 digits (000 to 600) (ms) Fixed to 3 digits (000 to 030) (CYC)J*Monitor current of WE2Fixed to 4 digits (0.00 to 9.99) (kA)KMonitor voltage of WE2Fixed to 4 digits (0.00 to 9.99) (V)LMonitor power of WE2Fixed to 5 digits (00.00 to 99.99) (kW)MMonitor pulse width of WE2Fixed to 4 digits (00.0 to 99.99) (%)NMonitor time of WE3Fixed to 3 digits (000 to 600) (ms)	
IMonitor time of WE2Fixed to 3 digits (000 to 030) (CYC)J*Monitor current of WE2Fixed to 4 digits (0.00 to 9.99) (kA)KMonitor voltage of WE2Fixed to 4 digits (0.00 to 9.99) (V)LMonitor power of WE2Fixed to 5 digits (00.00 to 99.99) (kW)MMonitor pulse width of WE2Fixed to 4 digits (00.0 to 99.99) (%)NMonitor time of WE3Fixed to 3 digits (000 to 600) (ms)	
KMonitor voltage of WE2Fixed to 4 digits (0.00 to 9.99) (V)LMonitor power of WE2Fixed to 5 digits (00.00 to 99.99) (kW)MMonitor pulse width of WE2Fixed to 4 digits (00.0 to 99.9) (%)NMonitor time of WE3Fixed to 3 digits (000 to 600) (ms)	
LMonitor power of WE2Fixed to 5 digits (00.00 to 99.99) (kW)MMonitor pulse width of WE2Fixed to 4 digits (00.0 to 99.9) (%)NMonitor time of WE3Fixed to 3 digits (000 to 600) (ms)	
MMonitor pulse width of WE2Fixed to 4 digits (00.0 to 99.9) (%)NMonitor time of WE3Fixed to 3 digits (000 to 600) (ms)	
N Monitor time of WE3 Fixed to 3 digits (000 to 600) (ms)	
O* Monitor current of WE3 Fixed to 4 digits (0.00 to 9.99) (kA)	
P Monitor voltage of WE3 Fixed to 4 digits (0.00 to 9.99) (V)	
Q Monitor power of WE3 Fixed to 5 digits (00.00 to 99.99) (kW)	
R Monitor pulse width of WE3 Fixed to 4 digits (00.0 to 99.9) (%)	
S STEP No. of VALVE1 Fixed to 1 digit (1 to 9)	
T STEP COUNT of VALVE1 Fixed to 4 digits (0000 to 9999)	
U STEP No. of VALVE2 Fixed to 1 digit (1 to 9)	
V STEP COUNT of VALVE2 Fixed to 4 digits (0000 to 9999)	_
W WELD COUNT Fixed to 4 digits (0000 to 9999)	

* Fixed to 4 digits (00.0 to 99.9) (kA) for **IS-600A-00-01/00-02**.

2) Error Data

Data strings: !01000:E03,04,12,15,17[CR][LF] A B C D E F G

А	Device No.	Fixed to 2 digits (01 to 31)
B*1	Schedule No.	Fixed to 3 digits (001 to 255)
C*2	Error Code 1	Fixed to 2 digits (01 to 31)
D*2	Error Code 2	Fixed to 2 digits (01 to 31)
E* ²	Error Code 3	Fixed to 2 digits (01 to 31)
F* ²	Error Code 4	Fixed to 2 digits (01 to 31)
G*2	Error Code 5	Fixed to 2 digits (01 to 31)

*1 Common Schedule No. to error codes other than E06, E07, E18, and E19. (Schedule No. is fixed to "000")

*2 The number of Error Codes is of five max. In the case of only one error code, the error codes D to G are omitted. For Error Codes, see 13. (1) Fault Code List.

② Bi-directional Communication Mode

(When <--> is selected at COMM CONTROL in MODE SELECT Screen)

Example: Read all troubled data in the specified device, No. 01. (Schedule No. is "008" and Voltage error and Electric power error are occurring.)

Host	#	I D 1	1 D 2	R	S H 1	S H 2	S H 3	С	S C 2	C R		0	1	0	0	8		0	6	:	E18,E19			
IS-600A		0	1		0	0	0	0	6	 <u>.</u>	 !	1 D 1	 D 2	S H 1	S H 2	S H 3	s		S C 2		Data	C R	L F	


1)Schedule numbers, SH1, SH2 and SH3 are fixed to 000.

However, schedule numbers are sent from IS-600A when "E06: Current error", "E18: Voltage error", "E19: Electric power error" and "E07: Pulse width error" occurs.

2) Screen numbers, SC1 and SC2 are fixed to 06.

3) In no trouble, data of "00" returned.

Error Reset Code: # Device No. W Schedule No. S Screen No. Data Example: Resets the trouble of the specified device, No. 01.



11. External Communication Function


1) Schedule Nos, SH1, SH2 and SH3 are fixed to 000.

2) Screen Nos, SC1 and SC2 are fixed to 06.

3) "00" (no trouble) is returned as a confirmation data

Reading of Data Code: # Device No. R Schedule No. S Screen No. *

Example: Read all data of Screen No. "01" of Schedule No. "008" of the specified device No. 01.




1)SH1, SH2 and SH3 are schedule numbers.

Fixed to 3 digits (SH1=Hundred's place, SH2=Ten's place, SH3=One's place) However, screen 03, 05 and 06 are fixed to the schedule No. 000.


2)SC1 and SC2 are screen numbers.

Fixed to 2 digits (SC1=Ten's place, SC2=One's place)

3) For the data order for a schedule of each screen No., see (5) Data Code List.



Example: Write data for a schedule of Screen No "01" of Schedule No. "008" of the specified device No. 01.



1)SH1, SH2 and SH3 are schedule numbers.

Fixed to 3 digits (SH1=Hundred's place, SH2=Ten's place, SH3=One's place) However, screen 03, 05 and 06 are fixed to 000 of schedule No.

2)SC1 and SC2 are screen numbers.

Fixed to 2 digits (SC1=Ten's place, SC2=One's place)

(Note) Screen 04 and 06 (1) are read only and cannot be written.

3) For the data order for a schedule and the screen No., see (5) Data Code List.

- 4) The set data is returned as a confirmation data. When data which is outside the range is set, previous data is returned.
- 5)It takes about 2 seconds at most to save data into the flash memory (The **READY** lamp is turned off during saving). Be careful when writing continuously.

11. External Communication Function

(5) Data Code Table

① Screen 01 (SCHEDULE data) Specific data in accordance with Schedule No. (Schedule No.: 001 to 255)

ltem	Contents	Character String	Range
1	Control mode	n,	 0 to 5 0: Primary constant-current effective value control 1: Secondary constant-current effective value control 2: Secondary constant-power effective value control 3: Primary constant-current peak value control 4: Secondary constant-voltage effective value control 5: Constant-phase control
2	Unit of time *1	n,	m: ms C: CYC
3	SQD / Squeeze delay time	nnnn,	0000 to 9999 (ms mode) 0000 to 0999 (CYC mode)
4	SQZ / Squeeze time	nnnn,	0000 to 9999 (ms mode) 0000 to 0999 (CYC mode)
5	UP1 / Upslope 1 time	nnn,	000 to 400 (ms mode) 000 to 020 (CYC mode)
6	WELD1 / Weld 1 time	nnn,	000 to 600 (ms mode) 000 to 030 (CYC mode)
7	DOWN1 / Downslope 1 time	nnn,	000 to 400 (ms mode) 000 to 020 (CYC mode)
8	COOL1 / Cooling 1 time	nnn,	000 to 999(ms mode) 000 to 099(CYC mode)
9	UP2 / Upslope 2 time	nnn,	000 to 400 (ms mode) 000 to 020 (CYC mode)
10	WELD2 / Weld 2 time	nnn,	000 to 600 (ms mode) 000 to 030 (CYC mode)
11	DOWN2 / Downslope 2 time	nnn,	000 to 400 (ms mode) 000 to 020 (CYC mode)
12	COOL2 / Cooling 2 time	nnn,	000 to 999 (ms mode) 000 to 099 (CYC mode)
13	UP3 / Upslope 3 time	nnn,	000 to 400 (ms mode) 000 to 020 (CYC mode)
12	WELD3 / Weld 3 time	nnn,	000 to 600 (ms mode) 000 to 030 (CYC mode)
13	DOWN3 / Downslope 3 time	nnn,	000 to 400 (ms mode) 000 to 020 (CYC mode)
14	HOLD / Hold time	nnnn,	00000 to 20000 (ms mode) 00000 to 00999 (CYC mode)
15	OFF / Off time	nnnn,	0000 to 9990 (ms mode) *2 0000 to 0099 (CYC mode)
16	HEAT1	n.nn,	0.50 to 9.99 (kA, kW) * ³ 0.20 to 9.99 (V)
17	HEAT2	nn.n, n.nn,	10.0 to 99.9 (%) 0.50 to 9.99 * ³ 0.20 to 9.99 (V)
		nn.n,	10.0 to 99.9 (%)

Item	Contents	Character String	Range
18	HEAT3	n.nn,	0.50 to 9.99 (kA, kW) 0.20 to 9.99 (V)
		nn.n,	10.0 to 99.9 (%)
19	PULSATION	nn,	00 to 19
20	GAIN	n,	1 to 9
21	VALVE	n,	1 to 2
22	TURN RATIO	nnn.n,	001.0 to 199.9
23	WELD ON/OFF	n	0: OFF 1: ON

*1 The setting of ms/CYC cannot be changed. You can change it via Screen 05 (SYSTEM data).

*2 10-ms increment. The setting in 1ms is omitted.

*3 Character string is "nn.n," and Range is "00.0 to 20.0 (kA, kW)" for **IS-600A-00-01/00-02**.

② Screen 02 (MONITOR SET data) Specific data in accordance with Schedule No. (Schedule No.: 001 to 255)

Item	Contents	Character String	Range
1*	CURRENT HIGH of HEAT1 (upper limit)	n.nn,	0.00 to 9.99 (kA)
2*	CURRENT LOW of HEAT1 (lower limit)	n.nn,	0.00 to 9.99 (kA)
3	VOLT HIGH of HEAT1 (upper limit)	n.nn,	0.00 to 9.99 (V)
4	VOLT LOW of HEAT1 (lower limit)	n.nn,	0.00 to 9.99 (V)
5	POWER HIGH of HEAT1 (upper limit)	nn.nn,	00.00 to 99.99 (kW)
6	POWER LOW of HEAT1 (lower limit)	nn.nn,	00.00 to 99.99 (kW)
7	PULSE HIGH of HEAT1 (upper limit)	nnn,	010 to 100 (%)
8*	CURRENT HIGH of HEAT2 (upper limit)	n.nn,	0.00 to 9.99 (kA)
9*	CURRENT LOW of HEAT2 (lower limit)	n.nn,	0.00 to 9.99 (kA)
10	VOLT HIGH of HEAT2 (upper limit)	n.nn,	0.00 to 9.99 (V)
11	VOLT LOW of HEAT2 (lower limit)	n.nn,	0.00 to 9.99 (V)
12	POWER HIGH of HEAT2 (upper limit)	nn.nn,	00.00 to 99.99 (kW)
13	POWER LOW of HEAT2 (lower limit)	nn.nn,	00.00 to 99.99 (kW)
14	PULSE HIGH of HEAT2 (upper limit)	nnn,	010 to 100 (%)
15*	CURRENT HIGH of HEAT3 (upper limit)	n.nn,	0.00 to 9.99 (kA)
16*	CURRENT LOW of HEAT3 (lower limit)	n.nn,	0.00 to 9.99 (kA)
17	VOLT HIGH of HEAT3 (upper limit)	n.nn,	0.00 to 9.99 (V)
18	VOLT LOW of HEAT3 (lower limit)	n.nn,	0.00 to 9.99 (V)
19	POWER HIGH of HEAT3 (upper limit)	nn.nn,	00.00 to 99.99 (kW)
20	POWER LOW of HEAT3 (lower limit)	nn.nn,	00.00 to 99.99 (kW)
21	PULSE HIGH of HEAT3 (upper limit)	nnn	010 to 100 (%)

* Character string is "nn.n," and Range is "00.0 to 99.9 (kA)" for **IS-600A-00-01/00-02**.

ltem	Contents	Character String	Range
1	START ON STEP # of VALVE1	n,	1 to 9
2	STEP1 COUNT of VALVE1	nnnn,	0000 to 9999
3	STEP2 COUNT of VALVE1	nnnn,	0000 to 9999
4	STEP2 RATIO of VALVE1	nnn,	050 to 200 (%)
5	STEP3 COUNT of VALVE1	nnnn,	0000 to 9999
6	STEP3 RATIO of VALVE1	nnn,	050 to 200 (%)
7	STEP4 COUNT of VALVE1	nnnn,	0000 to 9999
8	STEP4 RATIO of VALVE1	nnn,	050 to 200 (%)
9	STEP5 COUNT of VALVE1	nnnn,	0000 to 9999
10	STEP5 RATIO of VALVE1	nnn,	050 to 200 (%)
11	STEP6 COUNT of VALVE1	nnnn,	0000 to 9999
12	STEP6 RATIO of VALVE1	nnn,	050 to 200 (%)
13	STEP7 COUNT of VALVE1	nnnn,	0000 to 9999
14	STEP7 RATIO of VALVE1	nnn,	050 to 200 (%)
15	STEP8 COUNT of VALVE1	nnnn,	0000 to 9999
16	STEP8 RATIO of VALVE1	nnn,	050 to 200 (%)
17	STEP9 COUNT of VALVE1	nnnn,	0000 to 9999
18	STEP9 RATIO of VALVE1	nnn,	050 to 200 (%)
19	START ON STEP # of VALVE2	n,	1 to 9
20	STEP1 COUNT of VALVE2	nnnn,	0000 to 9999
21	STEP2 COUNT of VALVE2	nnnn,	0000 to 9999
22	STEP2 RATIO of VALVE2	nnn,	050 to 200 (%)
23	STEP3 COUNT of VALVE2	nnnn,	0000 to 9999
24	STEP3 RATIO of VALVE2	nnn,	050 to 200 (%)
25	STEP4 COUNT of VALVE2	nnnn,	0000 to 9999
26	STEP4 RATIO of VALVE2	nnn,	050 to 200 (%)
27	STEP5 COUNT of VALVE2	nnnn,	0000 to 9999
28	STEP5 RATIO of VALVE2	nnn,	050 to 200 (%)
29	STEP6 COUNT of VALVE2	nnnn,	0000 to 9999
30	STEP6 RATIO of VALVE2	nnn,	050 to 200 (%)
31	STEP7 COUNT of VALVE2	nnnn,	0000 to 9999
32	STEP7 RATIO of VALVE2	nnn,	050 to 200 (%)
33	STEP8 COUNT of VALVE2	nnnn,	0000 to 9999
34	STEP8 RATIO of VALVE2	nnn,	050 to 200 (%)
35	STEP9 COUNT of VALVE2	nnnn,	0000 to 9999
36	STEP9 RATIO of VALVE2	nnn	050 to 200 (%)

③ Screen 03 (STEPPER data) Common data (Schedule I	No.: 000)
--	-----------

④ Screen 04 (MONITOR data) (Data reading only) Specific data in accordance with Schedule No. (Schedule No.: 001 to 255)

ltem	Contents	Character String	Range
1	Unit of time	n,	m: ms C: CYC
2	Monitor time of WELD1	nnn,	000 to 600 (ms mode) 000 to 030 (CYC mode)
3*	Monitor current of WELD1	n.nn,	0.00 to 9.99 (kA)
4	Monitor voltage of WELD1	n.nn,	0.00 to 9.99 (V)
5	Monitor power of WELD1	nn.nn,	00.00 to 99.99 (kW)
6	Monitor pulse width of WELD1	nn.n,	00.0 to 99.9 (%)
7	Monitor time of WELD2	nnn,	000 to 600 (ms mode) 000 to 030 (CYC mode)
8*	Monitor current of WELD2	n.nn,	0.00 to 9.99 (kA)
9	Monitor voltage of WELD2	n.nn,	0.00 to 9.99 (V)
10	Monitor power of WELD2	nn.nn,	00.00 to 99.99 (kW)
11	Monitor pulse width of WELD2	nn.n,	00.0 to 99.9 (%)
12	Monitor time of WELD3	nnn,	000 to 600 (ms mode) 000 to 030 (CYC mode)
13*	Monitor current of WELD3	n.nn,	0.00 to 9.99 (kA)
14	Monitor voltage of WELD3	n.nn,	0.00 to 9.99 (V)
15	Monitor power of WELD3	nn.nn,	00.00 to 99.99 (kW)
16	Monitor pulse width of WELD3	nn.n,	00.0 to 99.9 (%)
17	Step No. of VALVE1	n,	1 to 9
18	STEP COUNT of VALVE1	nnnn,	0000 to 9999
19	Step No. of VALVE2	n,	1 to 9
20	STEP COUNT of VALVE2	nnnn,	0000 to 9999
21	WELD COUNT	nnnn	0000 to 9999

* Character string is "nn.n," and Range is "00.0 to 99.9 (kA)" for **IS-600A-00-01/00-02**.

Screen 05 (SYSTEM data) Common data (Schedule No.: 000)

Item	Contents	Character String	Range
1 * ¹	WELDTRANS FREQUENCY	nnnn,	Transformer frequency (Hz)
2* ¹	POWER SOURCE FREQUENCY	nn,	50 or 60 (Hz)
3* ¹	Model name	nnnnnnn,	IS-600A_
4* ¹	ROM VERSION	Vnn-nnn,	V00-00A ~
5	DELAY START SET	nn,	01 to 20 (ms)
6	START SIGNAL MODE	n,	0: LATCHED 1: PULSED 2: MAINTAINED
7	END SIGNAL TIME	nnn,	010 to 200 (ms)
8	END SIGNAL MODE	n,	0, 1, 2
9	PARITY CHECK	n,	0: OFF 1: ON
10	STEPPER MODE	n,	0: OFF 1: ON
11	WELD COUNT	n,	0: OFF 1: ON

Item	Contents	Character String	Range
12	RE-WELD	n,	0: OFF 1: ON
13	WELD TIME	n,	0: ms 1: CYC
14	WELD COUNT	nnnn,	0000 to 9999
15	NO CURRENT TIME	nn,	01 to 99 (ms)
16* ²	NO CURRENT LEVEL	n.nn,	0.00 to 9.99 (kA)
17	NO VOLTAGE LEVEL	n.nn,	0.00 to 9.99 (V)
18	MONITOR FIRST TIME	nn,	00 to 15 (ms)
19	MONITOR SLOPE MODE	n,	0: EXCLUDE 1: INCLUDE
20	CURRENT MONITOR NUMBER	n,	1 to 3
21* ¹	PROGRAM PROTECT	n	0:OFF 1:ON

*1 Items inhibited from setting (When setting data, omit these items.)

*2 Character string is "nn.n," and Range is "00.0 to 20.0 (kA)" for **IS-600A-00-01/00-02**.

© Screen 06 (Error data) Common data (Schedule No.: 000)

• Error data confirmation (Data reading only)

ltem	Contents	Character String	Range
1	Error code 1	nnn,	E01 to E31
2	Error code 2	nnn,	E01 to E31
3	Error code 3	nnn,	E01 to E31
4	Error code 4	nnn,	E01 to E31
5	Error code 5	nnn	E01 to E31

The number of Error Codes is of five max. In the case of only one error code, the items 2 to 5 are omitted.

For Error Codes, see 13. (1) Fault Code List.


• Error reset (Data setting only)


ltem	Contents	Character String	Range
1	Error reset	nnn	E00

12. Outline Drawing

When the bracket removed

(Dimensions in mm)








12. Outline Drawing

■ When the bracket mounted (horizontal type)

(Dimensions in mm)








■ When the bracket mounted (vertical type)

(Dimensions in mm)



12. Outline Drawing

13. Troubleshooting

(1) Fault Code List

In the event of a problem with the Power Supply, the **MA-627A** displays the fault code and message.

In such cases, read this section carefully, then inspect the equipment and take the necessary countermeasures. If you have any questions, consult us or your distributor.

Fault code	Contents	Cause	Measures	
E-01 Setting data error		The welding schedule data is different from the programmed one.	 Check all the settings. If the data in memory is damaged, the following are possible causes: Generation of powerful power supply or electrostatic noise Abnormal supply voltage resulting, for example, from lightening or induced lightening Flash memory's rewrite limit exceeded If the error occurs again after initialization, the Power Supply needs repair. Contact us. 	
		When writing data in bi-directional communication mode at external communication, data which is out of the range is written or data format is wrong.	Check the write data.	
E-02	Start input error	Cable to input start signal is broken, and a parity check error is detected.	Check start signal input cable.	
E-03 Transformer thermostat error		Temperature of welding transformer rises and external thermostat input circuit opens.	Lower temperature of transformer. When using water-cooled transformer, properly adjust temperature and flow rate of cooling water.	
		External signal input power is not connected.	Check external input signal for proper connection.	
E-04	IGBT thermostat error	Internal temperature of equipment rises and thermostat for power transistor in power unit is open.	Check filter for clogging. (See 9. (1) .) Ensure that the duty cycle does not exceed the specified value. (See 10 . (3).)	
	Non-current error (Secondary or primary current is not detected)	Squeeze of welding electrode is not sufficient.	Adjust squeeze of welding electrode adequately.	
E-05		SQD or SQZ time is too short.	Check setting of SQD or SQZ time to determine whether it is too short. (Set SQD or SQZ time to a period longer than the stroke time of the electrode.)	
		NO CURRENT LEVEL is high.	Set a lower NO CURRENT LEVEL . (See 4. (8)(c) .)	
		Fuse inside the equipment is blown.	The fuse needs replacement. Contact us.	
		Other maker's transformer is used without connecting toroidal coil.	Connect toroidal coil, referring to 5. Connection Procedures.	

13. Troubleshooting

Fault code	Contents	Cause	Measures
E-06	Current error	Welding current is out of CURRENT setting range on MONITOR SET screen.	Check for stained welding electrode or loose cable connection.
E-07	Pulse width error	Pulse width of welding current is out of PULSE HIGH setting range on MONITOR SET screen.	Check workpiece and welding electrode.
E-08	Insufficient number of weld counts	Counted number of welds is less than WELD COUNT setting.	Add required number of welds to make up for insufficiency. (See 4 . (8)(a) .)
E-09	Step end	STEPPER COUNT has completed final step.	Dress or replace tip, then reset step. (See 6. (1)(2) .)
		HEAT setting P/S RATIO> 600However, in primary constant-current peak value control mode, 15 > HEAT setting P/S RATIO> 600UP SLOPE or DOWN SLOPE is longer than WELD.The WELD1, WELD2, and WELD3	
E-10	Schedule setting error	values are all "0." Although the current in the subsequent stage is lower than that in the previous stage or the currents are equal, Upslope time is set in the subsequent stage and COOL is not set between the previous stage and the subsequent stage. Example) WELD1 = 20 ms 3.0 kA WELD2 = 40 ms 2.0 kA	Correct each setting.
		WELD2 = 40 ms 2.0 kA COOL1 = 0 ms UP2 = 10 ms Although the current in the subsequent stage is higher than that in the previous stage or the currents are equal, Downslope time is set in the previous stage and COOL is not set between the previous stage and the subsequent stage. Example) WELD2 = 50 ms 3.0 kA WELD3 = 70 ms 4.0 kA COOL2 = 0 ms DOWN2 = 20 ms Although STEPPER MODE is set to ON, STEPPER COUNT of STEP number set for START ON STEP# are all "0."	

Fault code	Contents	Cause	Measures	
E-11	Increase ratio error	HEAT setting, including RATIO setting is larger than max. value of current, voltage, or power setting.	Correct each setting. (See 4. (9) .)	
E-12	Emergency stop	External emergency stop input circuit is open. Power supply for external input is not connected.	Rectify cause of emergency stop, and then close stop circuit. Check external input signal for proper connection.	
E-13	Overcurrent	Primary current above the limit is detected.	Check for welding transformer and welding electrode problems. Check that the toroidal coil or the voltage detecting cable is connected in the secondary control.	
E-15	Flow switch error	Cooling water flow in pipe to which flow switch is installed is low. Power supply for external input is not	Increase cooling water flow rate to meet specifications. Check external input signal for	
E-16	Schedule signal input error	connected. Schedule signal is not input when external start signal is input.	proper connection. Input schedule signal before start signal. (See 4. (7)(e) .)	
E-17	Input power supply error	Frequency of incoming power supply is not stable, and equipment cannot determine whether it is at 50 Hz or 60 Hz.	Check power consumption to determine whether it is used at the contract level.	
E-18	Voltage error	Secondary voltage is out of VOLT setting range on MONITOR SET screen.	Check for stained welding electrode	
E-19	Electric power error	Welding power is out of POWER setting range on MONITOR SET screen.	and low electrode force.	
E-20	Welding stop error	The current shutoff signal is input prior to the start signal.	Check interrupt input signal. (See 4. (7)(e).)	
E-21	No voltage error	No detection of the voltage across welding electrodes. NO VOLTAGE is high.	Make sure that the cable detecting the voltage across welding electrodes is connected. Set a lower NO VOLTAGE . (See 4. (8)(d).)	
E-22	24VDC overcurrent	Built-in 24 V DC power supply on the rear panel is shorted and overloaded.	Turn off the power and check the I/O connection on the rear panel.	
E-23	Setting data range error	There is a data outside the range in the welding schedule data.	 Check all the settings. If the data in memory is damaged, the following are possible causes: Generation of powerful power supply or electrostatic noise Abnormal supply voltage resulting, for example, from lightening or induced lightening Flash memory's rewrite limit exceeded If the error occurs again after initialization, the Power Supply needs repair. Contact us. 	
E-29	Monitored data error	Monitor data and count data stored into memory is damaged. Data is lost since the retention period days after the power id turned o the error occurs frequently, the Power Supply needs repair. Cor us.		

13. Troubleshooting

(2) When the Welding Does not Start Even if the Start Signal is Input

When the welding does not start even if the Start signal (2ND STAGE signal) is input, the following causes can be thought.

- READY does not light up.
- Start signal is shorter than DELAY START SET time setting.
- Start signal is input while the END signal is output.
- Start signal is input during communicating with MA-627A.

CAUTION					
2ND STAC	GE				
Ta: Data communication time at start		DELAY START	SET		
SQD				_	
SQZ		1		-	
WE1		<u> </u>		_	
		5			
HOLD					
END				(Note 2)	
Tb: MA-627A dat transmission			- Tb1		-
Tc: External com transmission					₩
		HEAT ((Note 4)	

(Note 1) When the next start signal is received while the monitor error is displayed on **MA-627A**, the CAUTION signal is turned OFF and the previous screen is displayed.

At this time, the data is transferred to **MA-627A** from the Power Supply. The start signal is not received while the data is transferred. (Ta: 31 ms max. in the figure above.)

When the monitor error is displayed, input the start signal more than (Ta + T) time.

 (Note 2) When the sequence ends, the END signal is output after HOLD. The Start signal is not received while the END signal is output. To make start takt faster, lower the output time of END signal. (Can be set in 10-ms increment. The minimum value is 10 ms.) (Note 3) When the MONITOR screen is displayed, the monitor data is transferred to **MA-627A** simultaneously with the END signal output (transmission time Tb1). The monitor data is not transferred when the screen other than MONITOR screen is displayed.

The next Start signal is not received while the monitor data is transferred. Also, on every screen, the data is transferred to **MA-627A** from the Power Supply to display the monitor error when the monitor data is beyond/below the upper/lower limit (data communication time Tb2).

To make takt faster, do not display the MONITOR screen or do not fall off the upper/lower judgment value.

The data transmission time Tb1 and Tb2 are shown in the table below.

	Monitor error does not occur	Monitor error occurs
MONITOR screen	Tb1: 160 ms max.	Tb1+Tb2+α: 249 ms max.
Screens other than MONITOR screen	0 ms	Tb2: 86 ms max.

(Note 4) When the RS-485/RS-232C external communication function is set to the single-directional communication mode (see 4. (7) MODE SELECT Screen), the monitor data is transferred to the host computer after the completion of welding (transmission time Tc1). Also, when the monitor value is outside the upper/lower limit on the MONITOR SET screen, the monitor error code is transferred to the host computer (transmission time Tc2). The Start signal is not received while during transmitting.

To make takt faster, set the external communication function to OFF. Sown below is the data transmission time Tc1 and Tc2 when the communication speed is 9600 bps. When the communication speed is 19200 bps or 38400 bps, the transmission time will be short.

Data transmission time when the communication speed is 9600 bps

Tc1	124 ms max.
Tc2	25 ms max.