

INVERTER WELDING POWER SUPPLY

**IPB-5000B** 

# OPERATION MANUAL

 **AMADA**<sup>®</sup>

Thank you for purchasing our product.

- For correct use, read this operation manual carefully.
- After reading, save it in a proper place where you can easily access to.

## Contents

---

<b>1. Special Precautions</b>	
(1) Safety Precautions .....	1-1
(2) Precautions for Handling .....	1-4
(3) On Disposal .....	1-4
(4) Warning Labels for Safety .....	1-5
(5) Function Difference Depending on Model .....	1-5
<b>2. Features</b> .....	2-1
<b>3. Packaging</b> .....	3-1
<b>4. Name and Functions of Each Section</b>	
(1) Front Panel .....	4-1
(2) Rear Panel .....	4-3
<b>5. Installation and Connection</b>	
(1) Installation .....	5-1
(2) Connection .....	5-2
<b>6. Description of Display Screens</b>	
(1) Operation Flow .....	6-1
(2) MENU Screen .....	6-2
(3) SCHEDULE Screen .....	6-2
(4) MONITOR Screen .....	6-6
(5) COMPARATOR Screen .....	6-8
(6) ENVELOPE Screen .....	6-9
(7) PRECHECK Screen .....	6-13
(8) CONTROL Screen .....	6-14
(9) STATUS Screen .....	6-16
① STATUS (1/2) Screen .....	6-16
② STATUS (2/2) Screen .....	6-18
③ ERROR SETTING Screen .....	6-20
④ MISC Screen .....	6-20
<b>7. Basic Operation</b> .....	7-1
<b>8. External Interface</b>	
(1) Connection Diagram for External Input/Output Signals .....	8-1
① When contacts on PLC are used as input signal .....	8-1
② When NPN transistor (sink type) on PLC is used as input signal .....	8-2
③ When PNP transistor (source type) on PLC is used as input signal .....	8-3
④ When solenoid valves are activated by the use of an external power supply .....	8-4
⑤ When solenoid valves are activated by the use of an internal power supply .....	8-4
(2) External Input/Output Signals .....	8-4
(3) Schedule No. and Schedule Select Terminals .....	8-8

**9. Timing Chart**

(1) Fundamental Sequence .....	9-1
(2) Determination of Weld Schedule .....	9-3
(3) Behavior of START SIG. HOLD .....	9-4
(4) Behavior of END SIG. TIME .....	9-5
(5) Behavior of SOL1 and SOL2 .....	9-6
(6) "Error" or "Caution" in PRECHECK .....	9-7
(7) At Occurrence of "Error" or "Caution" .....	9-8
(8) Behavior in TRANS SCAN MODE .....	9-9
① OFF Setting .....	9-9
② ON Setting .....	9-9
③ 1-5 Setting .....	9-10
④ 1-2 Setting .....	9-11
⑤ 1-3 Setting .....	9-12
⑥ 1-4 Setting .....	9-12
(9) Movement of Displacement Sensor .....	9-13

**10. External Communication Function**

(1) Introduction .....	10-1
(2) Data Transmission .....	10-1
(3) Configuration .....	10-2
① RS-485 .....	10-2
② RS-232C .....	10-3
(4) Protocol .....	10-4
① Single-directional Communication Mode .....	10-4
② Bi-directional Communication Mode .....	10-5
(5) Data Code Table .....	10-9
① Order Table of Schedule Data .....	10-9
② Order Table of Monitor Data (Most Recent Monitor Value) .....	10-11
③ Specified Code .....	10-12

**11. Specifications**

(1) Specifications .....	11-1
(2) Optional Items (Separately Sold) .....	11-6
① Input Cables <b>PK-01855-□□□</b> .....	11-6
② Output Cables <b>PK-01856-□□□</b> .....	11-6
③ [SENS] Cables <b>SK-05741</b> .....	11-7
④ Start Cables <b>A-03081</b> .....	11-7
⑤ Displacement Sensors .....	11-7
⑥ Displacement Sensor Conversion Cables .....	11-7

**12. Error Codes** ..... 12-1**13. Outline Drawing**

(1) IPB-5000B-00-00/01/03/04/07 .....	13-1
(2) IPB-5000B-00-02/05 .....	13-1
(3) Displacement Sensors .....	13-2
① <b>GS-1830A</b> Type, Ono Sokki .....	13-2
② <b>GS-1813A</b> Type, Ono Sokki .....	13-3
③ <b>LG200-110</b> Type, Mitutoyo .....	13-4
④ <b>LGK-110</b> Type, Mitutoyo (Discontinued) .....	13-5
⑤ <b>ST1278</b> Type, HEIDENHAIN .....	13-6

**14. Schedule Data Table**

(1) Weld SCHEDULE Setting..... 14-1  
(2) PRECHECK Setting ..... 14-8  
(3) COMPARATOR Setting..... 14-11  
(4) CONTROL Setting..... 14-18  
(5) STATUS Setting..... 14-25

**EU Declaration of Conformity**

# 1. Special Precautions

## (1) Safety Precautions



Before using, read "Safety Precautions" carefully to understand the correct method of use.

- These precautions are shown for safe use of our products and for prevention of damage or injury to operators or others. Be sure to read each of them, since all of them are important for safe operation.
- The meaning of the words and symbols is as follows.

 <b>DANGER</b>
Denotes operations and practices that may imminently result in serious injury or loss of life if not correctly followed.

 <b>WARNING</b>
Denotes operations and practices that may result in serious injury or loss of life if not correctly followed.

 <b>CAUTION</b>
Denotes operations and practices that may result in personal injury or damage to the equipment if not correctly followed.

	These symbols denote "prohibition". They are warnings about actions out of the scope of the warranty of the product.
	These symbols denote actions which operators must take.
	Each symbol with a triangle denotes that the content gives DANGER, WARNING or CAUTION to the operator.

 <b>DANGER</b>	
	<p><b>Do not touch the inside of the Power Supply unnecessarily.</b>                  Since very high voltages are charged to the inside of this Power Supply, it is very dangerous to touch it unnecessarily.                  Any person other than service personnel, or authorized representatives' personnel must not touch the inside.</p>
	<p><b>Never disassemble, repair or modify the Power Supply.</b>                  These actions can cause electric shock and fire.                  If any part needs to be checked or repaired, contact us or your distributor for help.</p>
	<p><b>Never burn, destroy, cut, crush or chemically decompose the Power Supply.</b>                  This product incorporates parts containing gallium arsenide (GaAs).</p>


**WARNING**

**Do not put your hands between the electrodes.**

When welding, keep your fingers and hands away from the electrodes.


**Do not touch any welded part or electrodes during welding and just after welding finished.**

The welded part of a workpiece, electrodes and arm are very hot. Do not touch them; otherwise you may be burnt.


**Ground the equipment.**

If the Power Supply is not grounded, you may get an electric shock when there is trouble, or when electricity leaks.


**Connect the specified cables securely.**

Cables of insufficient current capacities and loose connections can cause fire and electric shock.


**Do not damage the power cable and connecting cables.**

Do not tread on, twist or tense any cable. The power cable and connecting cables may be broken, and that can cause electric shock and fire. If any part needs to be repaired or replaced, consult us or your distributor.


**Do not use any damaged power cable, connecting cable and plug.**

That can cause electric shock, short circuits and fire. If any part needs to be repaired or replaced, consult us or your distributor.


**Stop the operation if any trouble occurs.**

Continuous operation after occurrence of a trouble such as burning smell, abnormal sound, abnormal heat, smoke, etc. can cause electric shock and fire. If such a trouble occurs, immediately consult us or your distributor.


**Persons with pacemakers must stay clear of the welding machine.**

A person who uses a pacemaker must not approach the welding machine or walk around the welding shop while the welding machine is in operation, without being permitted by his/her doctor. The welding machine generates a magnetic field and has effects on the operation of the pacemaker while it is turned on.


**Protective gear must be worn.**

Put on protective gear such as protective gloves, long-sleeve jacket, leather apron, etc. Surface flash and expulsion can burn the skin if they touch the skin.


**Wear protective glasses.**

If you look at the flash directly during welding, your eyes may be damaged. If any Surface flash and expulsion gets in your eye, you may lose your eyesight.



# CAUTION



**Apply the specified source voltage.**

Application of a voltage out of the specified range can cause fire and electric shock.



**Do not splash water on the equipment.**

Water splashed over the electric parts, can cause electric shock and short circuits.



**Use proper tools (wire strippers, pressure wire connectors, etc.) for termination of the connecting cables.**

Do not cut the conductor of wire. A flaw on it can cause fire and electric shock.



**Install the equipment on firm and level surface.**

If the equipment falls over or drops from an uneven surface, injury may result.



**Do not sit on or do not put things on it.**

Sitting on it, or putting things on it may cause malfunction.



**Keep combustible matter away from the welding machine.**

Surface flash and expulsion can ignite combustible matter. If it is impossible to remove all combustible matter, cover them with non-combustible material.



**Do not cover this equipment with a blanket, cloth, etc.**

If such a cover is used, it may be overheated and burn.



**Do not use this Power Supply for purposes other than welding.**

Use of this equipment in a manner other than specified can cause electric shock and fire.



**Use ear protectors.**

Loud noises can damage hearing.



**Keep a fire extinguisher nearby.**

Make sure there is a fire extinguisher in or near the welding shop in case of fire.



**Regularly inspect and maintain the equipment.**

Regular inspect and maintenance is essential to safe operation of the equipment. If you see any damage, make necessary before starting the operation.

## (2) Precautions for Handling


- When transporting or moving the Power Supply, do not lay it down. Also, handle the Power Supply with care so as not to make an impact such as drop on it.
- Install the Power Supply on a firm and level surface. If it is used inclined or on its side, it may have a malfunction.  
Also, provide 10 cm clearance to the intake and exhaust for improving the effect of heat release (Refer to **5. (1) Installation**).
- Do not install this Power Supply in the following places:
  - Where there is considerably damp (humidity is higher than 90%).
  - Where the ambient temperature is above 40°C or below 5°C.
  - Where there is nearby high noise source.
  - Where the Power Supply may be exposed to chemicals.
  - Where moisture may be condensed on the surface of the Power Supply.
  - Where there is considerable dirt.
  - Where the Power Supply may be subjected to vibration or impact.
  - Where the altitude is above 1000 meters.
- If the outside of the Power Supply is stained, wipe it with a dry cloth or a moistened cloth. If it is badly stained, use diluted neutral detergent or alcohol to clean it. Do not use paint thinner, benzene, etc., which can discolor or deform the parts.
- Do not put screws, coins, etc., in the Power Supply, as they may cause a malfunction.
- Operate the Power Supply according to the method described in this operation manual.
- Operate the switches and buttons carefully by hand. If they are operated roughly or with the tip of a screwdriver, a pen, etc. they may be broken.
- Operate the switches and buttons one at a time.  
If two or more of them are operated at a time, the Power Supply may have trouble or may be broken.
- The Power Supply is not equipped with auxiliary power such as an outlet for lighting.
- The cable to supply power, the welding head, the welding transformer, and cables for connecting among the welding head, the welding transformer and the Power Supply are separately needed to use the Power Supply.
- The I/O signal line to start the Power Supply is not attached. Prepare the crimp-on terminal and line for wiring to the terminal block.

## (3) On Disposal


This product incorporates parts containing gallium arsenide (GaAs). At the time of disposal, separate it from general industrial waste or domestic waste and carry out the disposal in accordance with applicable laws and regulations.

## (4) Warning Labels for Safety

The following warning labels are attached to the Power Supply for safe operation. The location of labels and the meaning of the symbols are as follows:



Location: the side surface of a plastic cover inside **IPB-5000B**  
 Meaning: **Danger**



Location: Output terminal cover inside **IPB-5000B**  
 Meaning: **Danger of Electrical Shock**

## (5) Function Difference Depending on Model

The function of “only for Model with Displacement Sensor” described in the operation manual is effective for the models equipped with Displacement Sensor as follows.

Other functions are effective for the Models with Sensor as same as the standard models.

Model	Welding Power	Sensor Equipped	CE Marking Compliance
<b>IPB-5000B</b>	<b>-00-00</b>	200 to 240V AC	×
	<b>-00-01</b>	380 to 480V AC	×
	<b>-00-02</b>	380 to 480V AC	×
	<b>-00-03</b>	200 to 240V AC	○
	<b>-00-04</b>	380 to 480V AC	○
	<b>-00-05</b>	380 to 480V AC	○
	<b>-00-07</b>	200 to 240V AC	×

○: Applicable    ×: Not Applicable

## 2. Features

The **IPB-5000B** is an inverter welding power supply designed for spot welding and fusing.

Because of a compact design, it is easy to move and install. In addition, the monitor function makes possible the judgment of defective or non-defective welding.

- Has a welding current monitoring function for the judgment of weld quality.
- The selection from four control methods of Constant-current control, Constant-voltage control, constant-current/constant-voltage combination control and constant-power control is applicable for realizing the stable weld quality.
- Has an interrupting function (**INTERRUPT**) to interrupt fusing current by externally inputting the displacement of an electrode, etc. for stable fusing.
- Weld current can be stopped when the displacement reaches the set value, because the displacement change between electrodes generated by fusion penetration etc. is measured (only for the model with a displacement sensor).
- As an inverter is used, the power factor is high and the power condition is stabilized.
- Because of the menu selection system, setting of various items can easily be done.
- With four protective functions, the operator can work at ease.
  - Over current detecting function
  - No-current / no-voltage detecting function
  - Thermostat fault detecting function
  - Self diagnostics
- The TFT LCD is employed. You can see monitor values of the welding current etc. clearly from any angle.

## 3. Packaging


### Shipping Kit List

Verify that contents of the container agree with the kit list.  
If you see any damage, please contact us.

Packaged Kit	Quantity
<b>IPB-5000B</b>	1
Operation Manual	1
Cable Clamp (Large) for fixing I/O Cable	2
Cable Clamp (Small) for fixing I/O Cable	3

## 4. Name and Functions of Each Section


### (1) Front Panel



- ① **Display Screen**  
Displays the information such as setting of a weld schedule, monitored values of weld current, etc.
- ② **POWER Lamp**  
Lights up when the power switch is turned on to supply the power to **IPB-5000B** and **IPB-5000B** works normally.
- ③ **START Lamp**  
Lights up while the start signal is input to make the sequence start.
- ④ **WELD Key with WELD Lamp**  
Use **WELD Key** if you want to make the sequence start without flowing the weld current.  
When **WELD Key** is pressed to extinguish **WELD Lamp**, then the weld current does not flow.

- ⑤ **CURSOR Key**  
Moves the cursor upward/downward or to the right/left on **Display Screen**.
- ⑥ **MENU Key**  
Press **MENU Key** to display **MENU Screen**.
- ⑦ **RESET Key**  
Press **RESET Key** to reset the display of a trouble after removing the cause of the trouble when the trouble display is shown on **Display Screen**.
- ⑧ **ENTER Key**  
Use **ENTER Key** to put in a set value or selected item.  
Move the cursor to each item to be changed and press **ENTER Key** item by item to complete the change.
- ⑨ **+ Key**  
Press **+ Key** to increase the value of a changed item.
- ⑩ **- Key**  
Press **- Key** to decrease the value of a changed item.

## (2) Rear Panel



- ① **Connecting Terminal Strip for External Input/Output Signal**  
Used for inputting the schedule signals, outputting trouble signals, etc.  
The size of screws is M3.5 for connection.
- ② **Breaker for Welding Power Input**  
Used to accept three-phase power supply for welding.  
The size of screws is M5 for connection.
- ③ **Lever for Welding Power Input Breaker**  
Pulling up the Lever supplies power; pushing down disconnects power supply.
- ④ **Welding Transformer I/O Signal Connector**  
Used for connecting [SENS] cable of our welding transformer.
- ⑤ **Terminal Block for Welding Power Output**  
Used for connecting to the input of welding transformer.  
The size of screws is M6 for connection.
- ⑥ **Displacement Sensor Connector**  
Used for connecting a displacement sensor (only for the model with displacement sensor).

⑦ **Communication Connector**

Used for communicating with Personal Computer (abbreviated as PC from now) through RS-232C or RS-485.

Before coupling with the connector, decide which mode is to be selected, RS-232C or RS-485 and confirm the communication mode. RS-232C is set at the factory shipment.

Mismatching of the communication mode setting at **IPB-5000B** with the mode at PC results in malfunction.


## 5. Installation and Connection

### (1) Installation


When planning for the installation, allow at least the figured clearance on each side from the wall, as referred to the figures below, for improving the effect of heat release.

Allow at least 10 cm or more from the end of the Wiring Outlet projected at the Output Terminal Cover in the rear portion of **IPB-5000B**.

As **IPB-5000B** should be air-cooled, do not install it in a closed area.



**(2) Connection**



Numerals of (1) to (8) in the above figure represent the order of connection procedures in the following pages.

- \* 1: All items are separately sold except **IPB-5000B**.
- \* 2: The Voltage Detecting Cable is used only for Constant Voltage Control, Constant Current/Constant Voltage Combination Control and Constant Power Control.
- \* 3: Communication Cable is used only for connecting Personal Computer (PC).
- \* 4: Displacement Sensor is used only for the model equipped with the Sensor.

**CAUTION**



Be sure to use **SK-05741** [SENS] cable when connecting **IPB-5000B** with Welding Transformer **IT\*-360\*6** or **IT\*-780\*6** (See **11.(2)③** for [SENS] cable).

**WARNING**



Be sure to ground the equipment.  
Be sure to install the Terminal Cover after wiring.



Be sure to install an earth leakage breaker of **40A rated current or more**.

**(1) Connecting Input Terminal Block of transformer.**

Connect the Output Cable from the Input Terminal Block of the welding transformer to the **Terminal block for Welding Power Output** (See **4.(2)⑤**) on the rear panel of **IPB-5000B**.

The ways of connecting the Input Terminal Block of Welding Transformer are different from each other, depending on the input voltage of **IPB-5000B**.

Connect in such way as ① below in the case of 200V System (200 to 240V) and as ② in 400V System (380 to 480V).



**CAUTION**



If the connection is done as the figure ① below in the case of **400V System**, it may damage **IPB-5000B** or Welding Transformer.

① **IPB-5000B-00-00** for use  
(**200V System** Power Supply)

② **IPB-5000B-00-01** for use  
(**400V System** Power Supply)



- (2) Connecting [SENS] Cable to transformer.**  
Connect [SENS] Cable from **Welding Transformer I/O Signal Connector** (See 4.(2)④) in the rear panel of **IPB-5000B** to Welding Transformer.
- (3) Connecting Start Cable**  
Connect Start Cable from **Terminal Strip for External Input/Output Signal** (See 4.(2)①) in the rear panel of **IPB-5000B** to Terminal Strip for Start Switch in Welding Head.
- (4) Connecting Voltage Detecting Cable**  
Connect the Voltage Detecting Cable in the case of using Constant Voltage Control, Constant Current/Constant Voltage Combination Control and Constant Power Control.
- (5) Connecting a power supply**  
Connect Input Cable from **Breaker for Welding Power Input** (See 4.(2)②) in the rear panel of **IPB-5000B** to Earth Leakage Breaker.  
Connect the earth cable to **PE** Terminal.
- (6) Connecting a necessary External I/O Signal Cable to Terminal Strip for External Input/Output Signal** (See 4.(2)①)  
Prepare cables for the connection, referring to 8. **External Interface**.

**(7) Connecting Communication Cable (only for PC connection)**

The communication with PC can be performed by the use of RS-232C and RS-485.

Before coupling with the connector, decide which mode is to be selected, RS-232C or RS-485 and confirm the communication mode (See **6.(9)ⓐ(c) COMM MODE** for the selection of RS-232C and RS-485).

Mismatching of the communication mode setting at **IPB-5000B** with the mode at PC results in malfunction.


RS-232C is set at the factory shipment.

See **10. External Communication Function** for details.

**(8) Connecting Displacement Sensor (only for model with Sensor)**

Install firmly Displacement Sensor not so as to rattle in reference to the figure below.

Install Displacement Sensor with insulated.




When using the function of detecting a workpiece, adjust the installation position of Sensor for the shaft of sensor so as to retract halfway in the condition before the electrode is forced (left-side figure above).

**ATTENTION**

As the figure (A) below, be sure to keep Displacement Sensor perpendicular to Displacement Detecting Plate.

If Displacement Sensor is slantingly installed like (B) or (C), the life of the sensor becomes shorter.




If Sensor is pressed beyond the range of measurement, it results in malfunction.

The measured value of displacement is minus (-) or plus (+).

When NORMAL is selected for DISPLACEMENT POLARITY in the MISC screen, the counted value is plus (+) in the direction of retraction of the movable part of Displacement Sensor and the value is minus (-) in the extension.


On the other hand, when REVERSE is selected, the counted value is minus (-) in the direction of retraction of the movable part of Displacement Sensor and the value is plus (+) in the extension.



## 6. Description of Display Screens

### (1) Operation Flow

An example of the operation for the use of Welding Power Supply is shown as follows:



## (2) MENU Screen

**Setting of Values**

Move the cursor (■) to the number or ON (or OFF) to be set or changed and press +/- key to complete such setting as input of a number or change of ON/OFF.

**IPB-5000B** has various functions, which are set in the respective screens. Press **MENU Key** in Front Panel to display **MENU screen**.

At the upper left of **MENU screen**, each function is displayed as a menu form. Move the cursor (■) to an item you desire; press **ENTER key** to go to the selected screen.

The numbers of (3) to (9) show the paragraph No. in the chapter

(3)	SCHEDULE	READY	SCH. # 001					
(4)	MONITOR							
(5)	COMPARATOR							
(6)	ENVELOPE							
(7)	PRECHECK							
(8)	CONTROL							
(9)	STATUS							
				WE1	COOL	WE2	HOLD	ms
				010.0	05.0	030.0	000	
				CURR	1.00	2.00	kA	
		VOLT	1.50	3.00	V			
		POWER	01.0	03.0	kW			


## (3) SCHEDULE Screen

Up to 127 weld schedules can be set on **IPB-5000B**. Those schedules are indicated as **SCHEDULE #1 to #127**. The screen is used to set the **SCHEDULE No.**, length of weld time, weld current and so on.

Move the cursor (■) to **SCHEDULE** and press **ENTER key** to display **SCHEDULE Screen** as follows.

The control method can be set for **WE1** and **WE2** respectively, and the waveform of a selected control method is displayed as follows. Also, if the waveforms selected for each **WE1** and **WE2** are different each other, two different waveforms also are displayed.

① Constant Current Control



As the following, each item of (a) to (f) is described.

(a) **SCH. #**

It denotes No. of weld **SCHEDULE**. 127 weld schedules as **SCHEDULE #1** to **#127** can be set on **IPB-5000B**.

(b) **Time**

Time period of each movement in welding is set at the dimension of ms. Refer to **9. Timing Chart** on the relation of each period.

<b>SQD</b> / Squeeze Delay Time	Period of time added to the Squeeze Time only once after start-up during repeated operation
<b>SQZ</b> / Squeeze Time	Period of time until proper squeeze is applied to workpiece
<b>WE1</b> / Weld 1 Time	The first weld time for which weld current is supplied
<b>COOL</b> / Cooling Time	Period during which weld current is suspended between <b>WE1</b> and <b>WE2</b>
<b>WE2</b> / Weld 2 Time	The second weld time for which weld current is supplied
<b>HOLD</b> / Hold Time	Period of time to hold workpiece after ceasing weld current

(c) **CURR** (Note

Indicates the value of current for control. Set it for **WE1** and **WE2** respectively.

(d) **VOLT** (Note

Indicates the value of voltage for control. Set it for **WE1** and **WE2** respectively.

(e) **POWER** (Note


Indicates the value of power for control. Set it for **WE1** and **WE2** respectively.

(f) **NEXT**


Displays **SCHEDULE (2/2) Screen**.

Note) Even if numbers are input at all the input boxes of control methods, **CURR**, **VOLT** and **POWER**, the numbers other than the selected control method do not work.

② Constant Voltage Control




③ Constant Current/Constant Voltage Combination Control



④ Constant Power Control



## ⑤ SCHEDULE (2/2) Screen



As the following, each item of (a) to (e) is described.

**(a) CONTROL**

Sets a control method for **WE1** and **WE2** respectively.

**CURR:** Constant Current Control

**VOLT:** Constant Voltage Control

**COMB:** Constant Current/Constant Voltage Combination Control

**POWER-H:** Constant Power Control (**HIGH** Range)

**POWER-L:** Constant Power Control (**LOW** Range)

**(b) UP SLOPE**

Set the upslope time (to increase the weld current gradually) (See 9. Timing Chart). Set it for **WE1** and **WE2** respectively.

**(c) DOWN SLOPE**

Set the downslope time (to decrease the weld current gradually) (See 9. Timing Chart). Set it for **WE1** and **WE2** respectively.

**(d) TRANS#**

Indicates the number of a transformer.

Works only at the time when Transformer Selector **MA-650A** is used.

**(e) PREV**

Displays **SCHEDULE (1/2) Screen**.


## (4) MONITOR Screen

In this screen, you can confirm the working condition during welding. The monitored data, that is, Current, Voltage, Power and Resistance in every schedule are displayed.


Current is indicated in yellow solid line, Voltage is cyan, Power is green and Resistance is magenta.

Move the cursor (■) to Function Key ((a) to (f)) to be selected and press **ENTER Key** to display the desired screen. Press one more time **ENTER Key** to erase the displayed data.

[When displaying data of two or less]



[When displaying data of three or more]



- (a) **CURR**  
The waveform of Current can be displayed.
- (b) **VOLT**  
The waveform of Voltage can be displayed.
- (c) **POWER**  
The waveform of Power can be displayed.

**(d) RESI**

The waveform of Resistance can be displayed.

**(e) SETUP**

The screen of SETUP can be displayed.

**(f) TOTAL COUNT**

The mode of a counter can be displayed. For details, see **(9)④(e) COUNTER**.

**(g) DISPLC**

The waveform of Displacement can be displayed.

(Only the model equipped with Displacement Sensor works. The waveform is upward displayed in the force-applying direction of Sensor and oppositely, downward in the force-releasing direction.)

**(h) Pulse Width Monitor**

The mean value of pulse widths of the supplied pulse current is displayed in the percentage to 100% of the pulse width at the full wave.


Use **Pulse Width Monitor** as an indication.

**(i) Weld Time**

The period during which weld current is supplied is displayed.

Note) **IPB-5000B** holds the monitored value of all schedules (only the latest one for waveform) while the power is on. When the power is turned off, all values are cleared.

**[SETUP Screen]**



**(a) CURRENT**

Selects **PEAK/RMS** of Current Value.

**(b) VOLTAGE**

Selects **PEAK/RMS** of Voltage Value.

**(c), (d)**

Selects the waveform to be displayed from 3 types.

**POWER:** Power Waveform

**RESISTANCE:** Resistance Waveform

**DISPLACEMENT:** Displacement Waveform (only for Sensor equipped)

**(e) BACK**

Returns to **MONITOR** Screen.

## (5) COMPARATOR Screen

Set the upper and lower criterion of Current, Voltage, Power and Resistance for judging “Good” or “No Good” weld. If the monitored value is inside the criterion, Good is determined. If it is outside, No Good is determined.

If the monitored value equals to the criterion, Good is determined.

If No Good is determined, an error signal of “NG” or “Caution” is output, so it can be used to activate an alarm buzzer, alarm lamp, and so on.

(a)

COMPARATOR		READY	SCH.#		001	
		WE1		WE2		
(b)	CURR	0.98	H 9.99	1.87	H 9.99	kA
			L 0.00		L 0.00	
			RMS			
(c)	VOLT	1.04	H 9.99	2.12	H 9.99	V
			L 0.00		L 0.00	
			RMS			
(d)	POWER	1.0	H 99.9	3.9	H 99.9	kW
			L 00.0		L 00.0	
(e)	RESIST	1.0	H 99.9	1.1	H 99.9	mΩ
			L 00.0		L 00.0	

### (a) SCH. #

Input the No. of **SCHEDULE** to monitor (Schedule to be set).

### (b) CURR

Set the upper limit (**H**) and lower limit (**L**) of the weld current for each of **WE1** and **WE2**. The setting range is 0.00 kA to 9.99 kA.

Switching between **PEAK** and **RMS** is possible. If the upper limit (**H**) is set to 9.99 kA and the lower (**L**) to 0.00 kA, no monitoring is done.

### (c) VOLT

Set the upper limit (**H**) and lower limit (**L**) of the weld voltage for each of **WE1** and **WE2**. The setting range is 0.00 V to 9.99 V.

Switching between **PEAK** and **RMS** is possible. If the upper limit (**H**) is set to 9.99 V and the lower (**L**) to 0.00 V, no monitoring is done.

### (d) POWER

Set the upper limit (**H**) and lower limit (**L**) of the weld power for each of **WE1** and **WE2**. When **POWER-H** is set for **CONTROL**, the setting range is 00.0 kW to 99.9 kW. If the upper limit (**H**) is set to 99.9 kW and the lower (**L**) to 00.0 kW, no monitoring is done. When **POWER-L** is set for **CONTROL**, the setting range is 0.00 kW to 9.99 kW. If the upper limit (**H**) is set to 9.99 kW and the lower (**L**) to 0.00 kW, no monitoring is done.

### (e) RESIST

Set the upper limit (**H**) and lower limit (**L**) of the weld resistance for each of **WE1** and **WE2**. The setting range is 00.0 mΩ to 99.9 mΩ. If the upper limit (**H**) is set to 99.9 mΩ and the lower (**L**) to 00.0 mΩ, no monitoring is done.

Note) **IPB-5000B** holds the monitored value of all schedules (only the latest one for waveform) while the power is on. When the power is turned off, all values are cleared.


## (6) ENVELOPE Screen

Here, the envelope waveform is prepared.

The function of Envelope is to draw a waveform (here, calling Envelope Waveform) having allowable criteria based on a standard waveform (an average actual weld waveform) and compare a monitored actual weld waveform with the Envelope Waveform in order to judge “Good” or “No Good” weld.

If the measured value is inside the Envelope Waveform, “Good” is determined. If it is outside, “No Good” is determined. If the monitored value equals to the Envelope Waveform value, “Good” is determined.

If No Good is determined, an error signal of “NG” or “Caution” is output, so it can be used to activate an alarm buzzer, alarm lamp, and so on.



### (a) SCH. #

Input No. of **SCHEDULE** to set the schedule.

### (b) TYPE

Indicates the type of selected standard waveforms, **CURR**, **VOLT**, **POWER**, **RESIST** and **DISPLC**. Only one standard waveform can be selected among the following 8 types of waveform.

When setting the envelope based on the standard waveform from the monitor, flow the current before setting.

Waveform	How to Select
Set Current Waveform	Press <b>NEW Button</b> , next press <b>SCH(C) Button</b> on the displayed screen. (From now on, the word of <b>Button</b> is omitted here.)
Set Voltage Waveform	<b>NEW</b> , next <b>SCH(V)</b>
Set Power Waveform	<b>NEW</b> , next <b>SCH(P)</b>
Monitored Current Waveform	<b>NEW</b> , next <b>MON</b> , next <b>CURR</b>
Monitored Voltage Waveform	<b>NEW</b> , next <b>MON</b> , next <b>VOLT</b>
Monitored Power Waveform	<b>NEW</b> , next <b>MON</b> , next <b>POWER</b>
Monitored Resistance Waveform	<b>NEW</b> , next <b>MON</b> , next <b>RESIST</b>
Monitored Displacement Waveform	<b>NEW</b> , next <b>MON</b> , next <b>DISPLC</b> (only for model with Displacement Sensor)

### (c) INTERVAL

Set the period of Envelope Waveform.

**(d) OFFSET**

Set the upper and lower limit of Envelope Waveform.

**(e) ON/OFF**

Set the activation or inactivation of the function.

**ON:** Envelope function works

**OFF:** Envelope function does not work

**(f) NEW**

Selects a standard waveform.

**(g) EDIT**

Changes **INTERVAL**, **OFFSET** or **ON/OFF** one another.

**(h) COPY**

Makes a copy of the data of Envelope Waveform.

Move the cursor (■) to **COPY Button** when **COPY Button** is displayed and press **ENTER Key** to show **PASTE Button**.


After changing **SCH. #** to be copied (source) into new **SCH. #** to be overwritten (destination), move the cursor (■) to **PASTE Button** and press **ENTER Key** to copy the data of Envelope Waveform.



**How to Draw Standard Waveform and ENVELOPE Waveform**

Here, the way how standard waveforms and ENVELOPE waveforms are drawn is described.

- ① Move the cursor (■) to **ENVELOPE** on **MENU Screen** (selecting) and press **ENTER Key**.




(The right-hand screen is described of Constant Current Control.)

The screen for drawing Envelope Waveform is prepared.


When modifying the existing waveforms, take steps ①, ⑤, ⑥, ⑦ and ⑧ (② to ④ is omitted).




- ② Select **NEW Button** and press **ENTER Key** to draw a standard waveform.




- ③ Select **MON Button** and press **ENTER Key** to draw a standard waveform from a monitored waveform.



- ④ Select **CURR Button** and press **ENTER Key** to draw the standard waveform of a current waveform. In the case of Voltage, Power or Resistance, select each button situated on the right side of **CURR button** and press **ENTER Key**.




- ⑤ Select **EDIT Button** and press **ENTER Key** to draw Envelope Waveform.



- ⑥ **INTERVAL** sets the time period from the beginning to end of Envelope waveform.  
**OFFSET** sets a plus (+) and minus (-) allowable value.  
 Concerning **ON/OFF**, **ON** should always be selected when using Envelope function. If **OFF** is selected, no Envelope function works.  
 After setting the above items, select **RETURN Button** and press **ENTER Key**.



- ⑦ Select **WRITE Button** and press **ENTER Key** to store the setting.



- ⑧ Here, in this step, Envelope Waveform has been set.

Envelope Waveform



When displaying the monitored screen, Envelope Waveform will appear.



**(7) PRECHECK Screen**

PRECHECK		READY	SCH. # 001
(a) —	TIME		01.0 ms
(b) —	VOLT		2.00 V
(c) —	COMP CURR	HIGH	5.00 kA
		LOW	0.50 kA
(d) —	CURR(MONITOR)		1.00 kA

Set the period of a weld time and a control voltage for Resistance PRECHECK in this screen.

The function of Resistance PRECHECK is to flow lower current in Constant Voltage Control method just before supplying the weld current and see if workpieces to be welded are correctly positioned by the use of the measured value of current then.

**(a) TIME**

Set a weld time. If the weld time equals to 0.0 ms, no PRECHECK is done.

**(b) VOLT**

Set a control voltage.

**(c) COMP CURR HIGH/LOW**

**HIGH:** Set the upper limit of current for PRECHECK.


**LOW:** Set the lower limit of current for PRECHECK.

**(d) CURR (MONITOR)**

Displays the monitored current at PRECHECK current supplying.

Note) **IPB-5000B** holds the monitored value of all schedules (only the latest one for waveform) while the power is on. When the power is turned off, all values are cleared.

**(8) CONTROL Screen**



Depict the screens of setting Weld Stop Function, Weld Time Comparator, etc.

**(a) INPUT**

Selects the type of Weld Stops.

**OFF:** External Input, **WE1** Stop Input and Interrupt Input are effective.

**DISPLC:** Weld Stop works at the set displacement value (only for Sensor equipped).

**CURR:** Weld Stop works at the set current value.

**VOLT:** Weld Stop works at the set voltage value.

**(b) CONDITION**

Input the value depending on the setting at (a).

**OFF:** Not displayed. **DISPLC:** Input the value of displacement.

**CURR:** Input current value. **VOLT:** Input voltage value.

**(c) HI**

Input the upper limit of Weld Time.

**(d) LOW**

Input the lower limit of Weld Time.

**(e) COMP**

Input the upper limit (**HI**)/ lower limit (**LOW**) of a final displacement.

(Works only for Model equipped with Displacement Sensor. When using the function of Displacement Sensor, the displacement from Weld Start to the end of **DELAY TIME** is measured to judge the upper and lower limit.)

**(f) DELAY TIME**

Sets **Delay Time**, the time period from Weld Stop to the time when a final displacement is measured (only for Sensor equipped). The setting range is from 0 to the time period of **HOLD TIME** (See **(3)ⓐ(b)**).

**(g) WORK DETECT**

Input the upper limit (**HI**) / lower limit (**LOW**) value at the time of detecting workpiece (only for Sensor equipped).

No detection of workpiece is done in the case that "0" is set to both the upper limit and lower limit.

For the detection of workpiece, the position of Sensor where the workpiece is set between electrodes is taken as the base point. The larger displacement without workpiece than the displacement with workpiece is detected to judge whether or not the workpiece is set.

**(h) MONITOR**

Displays the displacement at the time of detecting workpiece, the time of the end of squeeze time (only for Sensor equipped).

Note) **IPB-5000B** holds the monitored value of all schedules (only the latest one for waveform) while the power is on. When the power is turned off, all values are cleared.

## (9) STATUS Screen

Change the initial setting of **IPB-5000B** here in this screen.  
According to customer's preference, precise setting can be obtained.

### ① STATUS (1/2) Screen

STATUS (1/2)		READY
(a)	WELD TRANS	IT*360*6
(b)	WELD TIME	EXCLUDE SLOPE
(c)	START SIG. TIME	20 ms
(d)	START SIG. HOLD	NO HOLD
(e)	SCHEDULE#	EXT. (NP)
(f)	END SIG. TIME	100ms
(g)	MONITOR MODE	EXCLUDE SLOPE
(h)	CALCULATION MODE	NORMAL
		NEXT

#### (a) WELD TRANS

Set a transformer.

Select it between **IT\*-360\*6** and **IT\*-780\*6**.

Since **IT\*-142\*6** is used for adjustment, do not select it.

("\*" indicates any letter of the alphabet A to Z.)

#### (b) WELD TIME

Set whether or not upslope/downslope is included in **WELD TIME**.

**EXCLUDE SLOPE:** upslope/downslope is not included

**INCLUDE SLOPE:** upslope/downslope is included

#### (c) START SIG. TIME

Set a delay time defined as the time period which elapses from an input of Start Signal to a beginning of weld sequence.

The setting can eliminate the chattering movement of a start switch.

Select the set value among 20 ms, 10 ms, 5 ms and 1 ms.

If a chattering-proof switch can be used, shortest Delay Time can be obtained.

#### (d) START SIG. HOLD

A self-sustaining timing at starting can be selected.

**SQ HOLD:** Self-sustaining action works from the starting of squeeze sequence

**WE HOLD:** Self-sustaining action works from the starting of weld sequence

**NO HOLD:** NO self-sustaining action works. Input a start signal until the end of sequence.

**(e) SCHEDULE#**

Fixes the method of how to select a schedule.

**EXT. (NP):** Select a schedule by closing a schedule-selecting terminal on Rear Panel

**EXT. (P):** Select a schedule by closing a schedule-selecting terminal and a parity terminal on Rear Panel.

**PANEL:** Select a schedule on Front Panel.

Input a parity signal so that the total number of a closed schedule-selecting terminal and a closed parity terminal may be odd.

**(f) END SIG. TIME**

Set the time period during which End signal or GOOD signal is output.

**10/100ms:** Outputs End signal for 10 ms or 100 ms.

**HOLD:** Outputs End or GOOD signal for the period during which 2ND STAGE terminal is closed. But if it is closed for 10 ms or less, the signals are output for 10 ms. If it is longer than 10 ms, they are output for the closed period of 2ND STAGE terminal.

**(g) MONITOR MODE**

Set the mode of a displayed monitor value.

**EXCLUDE SLOPE:** Slope period not included.

**INCLUDE SLOPE:** Slope period also included.

**(h) CALCULATION MODE**

Set the way of calculating a monitored value.

**NORMAL:** Set **NORMAL** usually.

**FAST:** If the takt time is needed to shorten, the shorter calculation time is obtained when **FAST** is set.

## ② STATUS (2/2) Screen

STATUS (2/2) READY

(a) TRANS SCAN MODE OFF

(b) COMM CONTROL OFF

(c) COMM MODE RS-232C

(d) COMM UNIT# 00

(e) COMM SPEED 9600 bps

(f) NO CURR MONITOR START 01 ms

(g) PW MONITOR START 01 ms

(h) NG OUTPUT NORMALLY CLOSE

(i) READY OUTPUT WELD ON

ERROR MISC PREV

(j) (k) (l)

**(a) TRANS SCAN MODE**

Set the scan mode of transformers.

Does not work in Model with Displacement sensor.

**OFF:** No scan mode is used.

**ON:** A **SCHEDULE** is performed.

**1-2:** Consecutive 2 **SCHEDULE**'s are performed.

**1-3:** Consecutive 3 **SCHEDULE**'s are performed.

**1-4:** Consecutive 4 **SCHEDULE**'s are performed.

**1-5:** Consecutive 5 **SCHEDULE**'s are performed.

Select a scan mode of ON, 1-2, 1-3, 1-4 or 1-5 for setting each scan mode when the transformer selector **MA-650A** is connected.

Concerning the timing chart by settings, refer to **9.(8) Behavior in TRANS SCAN MODE**.

**(b) COMM CONTROL**

Selects a communication function.

**OFF:** No communication

**DATA OUTPUT:** One-way communication

**BI-DIRECTION:** Both-way communication

**(c) COMM MODE**

Selects a communication mode.

**RS-232C:** Communication by RS-232C

**RS-485:** Communication by RS-485

**(d) COMM UNIT#**

Input No. of an equipment (ID#).

The range is 00 to 31.

**(e) COMM SPEED**

Selects a communication speed.

**9600:** Communication at 9600 bps

**19200:** Communication at 19200 bps

**38400:** Communication at 38400 bps

**(f) NO CURR MONITOR START**

Set the starting time (Period for Neglect) of no-current supplying monitor.  
No-current supply is not detected during the Period for Neglect from the start of current supply.

**(g) PW MONITOR START**

Set the starting time (Neglect) of pulse width monitor.  
No pulse width monitor is performed during the Neglect period from the start of current supply.

**(h) NG OUTPUT**

Set the mode of NG terminal.

**NORMALLY CLOSE:** Open at the occurrence of NG.

**NORMALLY OPEN:** Closed at the occurrence of NG.

**(i) READY OUTPUT**

Select the mode of READY terminal.

**WELD ON:** Ready at Weld On

**POWER ON:** Ready at Power On

**(j) ERROR**

Displays ③ **ERROR SETTING** Screen.

**(k) MISC**

Displays ④ **MISC** Screen.

**(l) PREV**

Displays ① **STATUS (1/2)** Screen.

## ③ ERROR SETTING Screen



The signals output at the occurrence of an error (NG Signal/Caution Signal) can be set item by item.

**(a) OFF/ON**

**OFF:** NG Signal is output.

The input of Start Signal is not accepted at the occurrence of NG.


**ON:** Caution Signal is output.

The input of Start Signal is accepted even at the occurrence of Caution.

**(b) BACK**

Displays ② **STATUS (2/2)** Screen of the previous page.

④ MISC Screen



(a) **USER (1.00 – 9.99)**

It is for testing. It cannot be used.

(b) **MIN CURR**

Set the minimum current.

**NORMAL:** Settable from 10% of full scale.

**LOW:** Settable from 2.5% of full scale.

Note: You can set lower current in LOW mode, but note that it may exceed the range of the setting accuracy when the setting is 10% of full scale or less.

(c) **DISPLACEMENT SENSOR STEP**

Input the resolution of Displacement Sensor.

Ex.)

**GS-1830A, GS-1813A, LGK-110, LG200-110:** 1.0 μm

**ST1278:** 0.5 μm

(d) **DISPLACEMENT POLARITY**

Set the polarity of displacement.

**NORMAL:** Set the force-applying direction as plus.

**REVERSE:** Set the force-applying direction as minus.

(e) **COUNTER**

Set the mode of Counter.

**TOTAL:** Count-up (increment of +1) is done despite the result of the judgment in monitoring when the current is supplied.

Judgment in Monitor	Counting Manner
<b>GOOD</b>	Count-up
<b>CAUTION</b>	Count-up
<b>NG</b>	Count-up

**GOOD:** Count-up is done if the judgment is **GOOD** in current-supplied monitoring.

Judgment in Monitor	Counting Manner
<b>GOOD</b>	Count-up
<b>CAUTION</b>	No Count-up
<b>NG</b>	No Count-up

**WORK:** Count-up is not done if the judgment is **NG** in current-supplied monitoring.

Judgment in Monitor	Counting Manner
<b>GOOD</b>	<b>WELD</b> Counter counts-up. <b>WORK</b> Counter counts-up (increment of +1) when <b>WELD</b> Counter reached the set value.
<b>CAUTION</b>	<b>WELD</b> Counter counts-up. <b>WORK</b> Counter counts-up (increment of +1) when <b>WELD</b> Counter reached the set value.
<b>NG</b>	<b>WELD</b> Counter does not count-up. <b>WELD</b> Counter is reset to 0 (zero) when NG is reset. <b>WORK</b> Counter does not count-up.

Note: The period for retaining the memory of counted numbers is approximately 10 days since the day when a power supply is turned off at latest.

**(f) PRESET (TOTAL/GOOD)**

Input the preset value of **TOTAL/GOOD** Counter.

**(g) PRESET (WORK)**

Input the preset value of **WORK** Counter.

**(h) PRESET (WELD)**

Input the preset value of **WELD** Counter.

**(i) RESET**

Resets the count.

**(j) D-CHK**

Checks the operation of Displacement Sensor. The amount of displacement is shown on the right side of this button.

**(k) BACK**

Displays © **STATUS (2/2)** Screen of the previous page.

# 7. Basic Operation


The example of a basic operation is described, using a transformer **IT\*-780\*6** and a control method of **Constant Current Control**.

- (1) Connect correctly Welding Transformer **IT\*-780\*6** and peripheral equipments to **IPB-5000B**, referring to the connection way (**5. Installation and Connection**).
- (2) Turn on the Breaker.


**CAUTION**

Check that the display screen and lamps are turned on normally.


- (3) Press **MENU** key on Front Panel to display **MENU** Screen.  
Move the cursor (■) to **STATUS** and press **ENTER** Key.



- (4) **STATUS** Screen is displayed.  
Set the function. Move the cursor (■) to the desired item and press **+/-** key to select the function.  
Set **IT\*-780\*6** to **WELD TRANS**.



- (5) Press **MENU Key** on Front Panel to display **MENU Screen**.  
 Move the cursor ( ) to **SCHEDULE** and press **ENTER Key** to display **SCHEDULE Screen**.  
 Move the cursor ( ) to each place and set the values of the table below to each place by **+/- Key**.  
 Press **NEXT Button** to set the values of **UP SLOPE** and **DOWN SLOPE** in the following screen.




Item	Value	Item	Value
<b>SCH. #</b>	15	<b>UP SLOPE at WE1</b>	2 ms
<b>SQD</b>	0 ms	<b>UP SLOPE at WE2</b>	2 ms
<b>SQZ</b>	400 ms	<b>DOWN SLOPE at WE1</b>	5 ms
<b>WE1</b>	20 ms	<b>DOWN SLOPE at WE2</b>	5 ms
<b>COOL</b>	2 ms	<b>CURR at WE1</b>	1 kA
<b>WE2</b>	20 ms	<b>CURR at WE2</b>	2 kA
<b>HOLD</b>	10 ms		


- (6) For the test of welding, press **MENU Key** on Front Panel, select **MONITOR** and press **ENTER Key**. **MONITOR Screen** is displayed.



- (7) Press **WELD Key** on Front Panel to light up **WELD Lamp** (LED).




- (8) Set ON (Closed circuit) to **WELD ON/OFF** on **Connecting Terminal Strip for External Input/Output Signal** at Rear Panel.  
Make sure that the letter of **READY** on the upper right of Screen is green-lighted.



- (9) Set ON (Closed circuit) to **SCH1, SCH2, SCH4** and **SCH8** on **Connecting Terminal Strip for External Input/Output Signal** at Rear Panel for setting **SCH. #015**.

- (10) Set ON (Closed circuit) to **2ND STAGE Start Input** to begin testing the weld.  
The squeeze signal is output, and then the weld head begins to squeeze for the weld.

As the figure on the right is displayed, check that the weld schedule is correctly set.



## ! WARNING



When confirming the operation, check that **SQZ Time** (Squeeze Time) is sufficient.  
If weld current flows before the welding electrode force becomes sufficient, spatters are produced.


# 8. External Interface

## (1) Connection Diagram for External Input/Output Signals


**CAUTION**

Use the shielded for the external input/output signals and connect the shielded line to the COM terminal (6, 15, 18, 22, or 34).


① When contacts on PLC are used as input signal




② When NPN transistor (sink type) on PLC is used as input signal




③ When PNP transistor (source type) on PLC is used as input signal



④ When solenoid valves are activated by the use of an external power supply



⑤ When solenoid valves are activated by the use of an internal power supply



## (2) External Input/Output Signals

The contact input method is described as follows:

Pin No.	Description
1	24V DC Output Terminal. When contacts or NPN transistor (sink type) on PLC is used as an input signal (for start or selecting Schedule, etc.), connect Pin 1 to Pin 2. Note: Do not use Pin 1 other than for connecting to Pin 2 and Pin 3 or connecting to Pin 31 to activate a solenoid valve. If so, it may result in a trouble.
2	When contacts or NPN transistor (sink type) on PLC is used as an input signal (for start or selecting Schedule, etc.), connect Pin 2 to Pin 1. When PNP transistor (source type) on PLC is used as an input signal (for start or selecting Schedule, etc.), connect Pin 2 to COM Terminal on PLC.
3	Normally, connect Pin 3 to Pin 1. When opening Pin 3, a trouble display "Operation Stop" comes out and the operation stops. When the sequence is required to stop on the way while employing the start in a self-sustaining manner, open this Pin.
4	1ST STAGE Input Terminal. Closing of this Pin makes SOL1 Terminal of Pin 32 close. As the current-supplying sequence does not start, the adjustment or check of a squeeze location can be done. When closing 2ND STAGE Terminal at this location, the weld at the optimum squeeze location can be obtained.

Pin No.	Description
5	2ND STAGE Input Terminal. Closing the Pin makes the sequence start. When the sequence works, SOL2 Terminal on Pin 33 is closed.
6	COM Terminal. Internally connected to GND Chassis.
7 to 13	Schedule Input Terminal. 7 = Schedule 1, 8 = Schedule 2, 9 = Schedule 4, 10 = Schedule 8, 11 = Schedule 16, 12 = Schedule 32, 13 = Schedule 64, When the select method of Schedule is External Schedule Select Method, they work. The sum of Schedule No. of closed Pins is corresponding to the selected Schedule No. (Refer to (3) <b>Schedule No. and Schedule Select Terminal.</b> )
14	Parity Input or WE1 STOP Input Terminal. The setting of <b>SCHEDULE#</b> in <b>6.(9)⓪STATUS (1/2) Screen</b> allows the function to be switched. <u>When <b>EXT. (P)</b> is selected in <b>SCHEDULE#</b>,</u> Parity Input Terminal. This Pin makes it possible to detect a trouble caused by the breaking of a Schedule Select Signal wire. Select Pins so that the sum of the numbers of closed Schedule Select Signal wires and a Parity Signal wire may always be odd. (Refer to (3) <b>Schedule No. and Schedule Select Terminal.</b> ) <u>When <b>EXT. (NP)</b> or <b>PANEL</b> is selected in <b>SCHEDULE#</b>,</u> The function is changed in dependence on the selection of <b>WELD STOP (INPUT)</b> at <b>6.(8) CONTROL Screen</b> . * In the case of <b>OFF</b> selected at <b>INPUT</b> , It is WE1 Stop Input Terminal. When this Pin is closed while the sequence works at WE1 ( <b>W1</b> ), the sequence skips to COOL ( <b>CO</b> ). * In the case of <b>DISPLC**</b> , <b>CURR</b> and <b>VOLT</b> selected at <b>INPUT</b> , This terminal does not work. ** (only for Displacement Sensor equipped)
15	COM Terminal. Internally connected to GND Chassis.
16	Weld ON/OFF Input Terminal. Closed circuit is for Weld ON and Open circuit for Weld OFF. As weld current does not flow even in the activated sequence if the Pin is open, it can be used at starting for trial. Note: When the Pin is open in the process of sequence (including the End signal and the screen display time), the monitor value is not displayed. Except in an emergency, open the Pin after the End signal and the screen display time are complete (see <b>9.(1) Fundamental Sequence</b> ).
17	Error and Caution Reset Input Terminal. When the Pin is closed after eliminating a cause of NG or Caution, a display of NG or Caution is reset.
18	COM Terminal. Internally connected to GND Chassis.
19	Count Reset Input Terminal. Close the Pin when resetting a counter.

Pin No.	Description
20	<p>Interrupt Input Terminal. The function is changed in dependence on the selection of <b>WELD STOP (INPUT)</b> at <b>6.(8)CONTROL Screen</b>.</p> <p>* In the case of <b>OFF</b> selected at <b>INPUT</b>, When this Pin is closed while the sequence works at WE1 (<b>W1</b>), COOL (<b>CO</b>) and WE2 (<b>W2</b>), the sequence skips to HOLD.</p> <p>* In the case of <b>DISPLC**</b>, <b>CURR</b> and <b>VOLT</b> selected at <b>INPUT</b>, This terminal does not work.</p> <p>** (Only for Displacement Sensor equipped)</p>
21	<p>Program Protection Input Terminal. If the Pin is closed, the condition of settings cannot be changed. In order to make the settings effect, once turn off the power supply.</p>
22	<p>COM Terminal. Internally connected to GND Chassis.</p>
23	<p>GOOD Signal Output Terminal. If it is determined that the measured value is inside the range set in MONITOR Screen after a weld sequence has ended, the Pin keeps closed for the certain period. The period of closing can be selected among <b>HOLD</b>, 10 ms and 100 ms. The rated capacity of a contact is 24V DC 20 mA (Semi-conductor switch used).</p>
24	<p>NG Signal Output Terminal. The signal is output when the measured value goes out of the range set in COMPARATOR, PRECHECK and ENVELOPE Screen after a weld sequence has ended or when a trouble occurs in an operation. (An error output signal, NG or Caution can be switched at the setting in <b>6.(9)@ERROR SETTING Screen</b>.) The operation stays stopped at the occurrence of an error until the reset signal is input. The output manner can be selected at the setting of <b>NG OUTPUT</b> in <b>6.(9)@STATUS (2/2) Screen</b>.</p> <p><b><u>NORMALLY CLOSE</u></b> The Pin is closed with the power turned on, but becomes open with an error occurring.</p> <p><b><u>NORMALLY OPEN</u></b> The Pin is closed with an error occurring.</p> <p>The rated capacity of a contact is 24V DC 20 mA (Semi-conductor switch used).</p>
25	<p>END Signal Output Terminal. After the sequence has ended, the Pin is closed for the certain period. The period of closing can be set to <b>HOLD</b>, 10 ms or 100 ms. The signal also is output when the sequence is made operate in the condition of WELD OFF. The rated capacity of a contact is 24V DC 20 mA (Semi-conductor switch used).</p>
26	<p>CAUTION Signal Output Terminal. When ON is set at <b>ERROR SETTING Screen</b>, NG Signal can be switched to Caution Signal. The Pin is closed after the weld sequence has ended. Even if Caution Signal is generated, the welding operation can be continued. Input a reset signal or start signal for releasing Caution Signal. The rated capacity of a contact is 24V DC 20 mA (Semi-conductor switch used).</p>

Pin No.	Description
27	COUNT-UP Output Terminal. The Pin is closed when COUNT-UP reaches the set pre-set count value. Input Count Reset Signal for releasing the output of COUNT-UP. The rated capacity of a contact is 24V DC 20 mA (Semi-conductor switch used).
28	READY Output Terminal. The output manner can be selected at the setting of <b>READY OUTPUT</b> in <b>6.(9)@STATUS (2/2)</b> Screen. <b>WELD ON</b> Closed at the time when weld current is ready for being supplied. Open at WELD OFF or in the occurrence of NG. <b>POWER ON</b> Closed in the occasion when the power supply of <b>IPB-5000B</b> is turned on. The rated capacity of a contact is 24V DC 20 mA (Semi-conductor switch used).
29	COMMON Terminal for Output. Shared commonly for GOOD, NG, END, CAUTION, COUNT UP and READY.
30	COMMON Terminal for Output. Shared commonly for GOOD, NG, END, CAUTION, COUNT UP and READY.
31	POWER Input Terminal for activating a solenoid valve. Input the power of 120V AC, 24V AC/DC. Note: When an external power supply is used, prepare the power supply protected by a fuse.
32	Solenoid Valve 1 Output Terminal. Closed at inputting of 1ST STAGE. The rated capacity of a contact is 120V AC, 24V AC/DC 0.5 A (Semi-conductor switch used). Prepare a solenoid valve with the current capacity of 0.5 A or less.
33	Solenoid Valve 2 Output Terminal. Closed when the sequence works. The rated capacity of a contact is 120V AC, 24V AC/DC 0.5 A (Semi-conductor switch used). Prepare a solenoid valve with the current capacity of 0.5 A or less.
34	COM Terminal for Solenoid Valve. Used for activating a solenoid valve by the use of an internal power supply. Internally connected to GND Chassis.
35	Preparatory Input Terminal. (Do not connect here. If it is connected without instruction, it may be damaged.)
36	Preparatory Input Terminal. (Do not connect here. If it is connected without instruction, it may be damaged.)
37	Preparatory Output Terminal. (Do not connect here. If it is connected without instruction, it may be damaged.)
38	Preparatory Output Terminal. (Do not connect here. If it is connected without instruction, it may be damaged.)
39	Preparatory Output Terminal. (Do not connect here. If it is connected without instruction, it may be damaged.)




Schedule No.: SCHEDULE#		●: Closed					Blank: Open	
SCHEDULE#	SCH 1	SCH 2	SCH 4	SCH 8	SCH16	SCH32	SCH64	PARITY
44			●	●		●		
45	●		●	●		●		●
46		●	●	●		●		●
47	●	●	●	●		●		
48					●	●		●
49	●				●	●		
50		●			●	●		
51	●	●			●	●		●
52			●		●	●		
53	●		●		●	●		●
54		●	●		●	●		●
55	●	●	●		●	●		
56				●	●	●		
57	●			●	●	●		●
58		●		●	●	●		●
59	●	●		●	●	●		
60			●	●	●	●		●
61	●		●	●	●	●		
62		●	●	●	●	●		
63	●	●	●	●	●	●		●
64							●	
65	●						●	●
66		●					●	●
67	●	●					●	
68			●				●	●
69	●		●				●	
70		●	●				●	
71	●	●	●				●	●
72				●			●	●
73	●			●			●	
74		●		●			●	
75	●	●		●			●	●
76			●	●			●	
77	●		●	●			●	●
78		●	●	●			●	●
79	●	●	●	●			●	
80					●		●	●
81	●				●		●	
82		●			●		●	
83	●	●			●		●	●
84			●		●		●	
85	●		●		●		●	●
86		●	●		●		●	●
87	●	●	●		●		●	
88				●	●		●	

Schedule No.: SCHEDULE#		●: Closed					Blank: Open	
SCHEDULE#	SCH 1	SCH 2	SCH 4	SCH 8	SCH16	SCH32	SCH64	PARITY
89	●			●	●		●	●
90		●		●	●		●	●
91	●	●		●	●		●	
92			●	●	●		●	●
93	●		●	●	●		●	
94		●	●	●	●		●	
95	●	●	●	●	●		●	●
96						●	●	●
97	●					●	●	
98		●				●	●	
99	●	●				●	●	●
100			●			●	●	
101	●		●			●	●	●
102		●	●			●	●	●
103	●	●	●			●	●	
104				●		●	●	
105	●			●		●	●	●
106		●		●		●	●	●
107	●	●		●		●	●	
108			●	●		●	●	●
109	●		●	●		●	●	
110		●	●	●		●	●	
111	●	●	●	●		●	●	●
112					●	●	●	
113	●				●	●	●	●
114		●			●	●	●	●
115	●	●			●	●	●	
116			●		●	●	●	●
117	●		●		●	●	●	
118		●	●		●	●	●	
119	●	●	●		●	●	●	●
120				●	●	●	●	●
121	●			●	●	●	●	
122		●		●	●	●	●	
123	●	●		●	●	●	●	●
124			●	●	●	●	●	
125	●		●	●	●	●	●	●
126		●	●	●	●	●	●	●
127	●	●	●	●	●	●	●	

# 9. Timing Chart

## (1) Fundamental Sequence



Symbol:

- |                               |                                    |
|-------------------------------|------------------------------------|
| SQD: Squeeze Delay Time       | SQZ: Squeeze Time                  |
| RC: Resistance Pre-check Time | CP: Resistance Judgment Time (1ms) |
| U1: Upslope 1 Time            | W1: 1st Weld Time                  |
| D1: Downslope 1 Time          | CO: Cool Time                      |
| U2: Upslope 2 Time            | W2: 2nd Weld Time                  |
| D2: Downslope 2 Time          | HO: Hold Time                      |

**a:** Sum of the period set at **START SIG. TIME** and the period for preparing the supply of weld current (0.4 ms max.)

**b:** Monitored Value Computing Time

Changes in dependence on Monitor Value Calculation Mode (**CALCULATION MODE** at **6.(9)①STATUS(1/2)Screen**) and Communication Setting (**COMM CONTROL** and **COMM SPEED** at **6.(9)②STATUS(2/2)Screen**).

① In the case of **OFF** or **BI-DIRECTION** at **COMM CONTROL**,

Calculation Mode Setting ( <b>CALCULATION MODE</b> )	
<b>NORMAL</b>	<b>FAST</b>
205 ms Max.	155 ms Max.

- ② In the case of **DATA OUTPUT** at **COMM CONTROL**, Communication data output time is included.

Communication Speed Setting ( <b>COMM SPEED</b> )	Calculation Mode Setting ( <b>CALCULATION MODE</b> )	
	<b>NORMAL</b>	<b>FAST</b>
<b>9600bps</b>	330 ms Max.	280 ms Max.
<b>19200bps</b>	275 ms Max.	225 ms Max.
<b>38400bps</b>	245 ms Max.	195 ms Max.

**c: Screen Display Time and Start Signal Standby Time**

- ① **Screen Display Time**

Screen Display Time is the period required from the end of END Signal Output for screen displaying.

It is 355 ms Max. However, it changes in accordance with the type of screens as follows.

Display Screen	Period
SCHEDULE	205 ms Max.
MONITOR (The next coming signal makes the screen display cancelled in MONITOR Screen.)	0 ms
COMPARATOR	220 ms Max.
ENVELOPE	355 ms Max.
PRECHECK	60 ms Max.
CONTROL	55 ms Max.
STATUS	0 ms

Note) If the takt time is needed to shorten, display the MONITOR or STATUS screen.

- ② **Start Signal Standby Time**


It is the period necessary for opening Start Input Signal.

After Screen Display Time elapsed, it is required to open Start Input for 10ms or more.

**d: CAUTION Output** is switched to OFF at the coming input of Start Signal.

## (2) Determination of Weld Schedule

Weld Schedule is determined after Chattering Prevention Time, “**START SIG. TIME**” elapses from the input of Start Signal.




In the above figure (A), as SCH 1 and SCH 8 are set to ON, weld is performed at Schedule #9.

In (B), as only SCH 8 is set to ON, weld is at Schedule #8. As SCH 16 and 32 are set to OFF at the timing of determining Schedule, they are invalid.

### (3) Behavior of START SIG. HOLD

- \* **NO HOLD** Setting: If Start Signal is made open during the period from SQD to W2, a weld sequence is broken off on the way and results in **E13: CYCLE ERROR**. Even if Start Signal is made open during HO, the weld sequence goes to an end.
- \* **WE HOLD** Setting: After a beginning of W1, a weld sequence goes to an end even if Start Signal is made open.
- \* **SQ HOLD** Setting: After Start Signal is accepted, a weld sequence goes to an end even if Start Signal is made open.




Symbol:

SQD: Squeeze Delay Time	SQZ: Squeeze Time
RC: Resistance Pre-check Time	CP: Resistance Judgment Time (1 ms)
U1: Upslope 1 Time	W1: 1st Weld Time
D1: Downslope 1 Time	CO: Cool Time
U2: Upslope 2 Time	W2: 2nd Weld Time
D2: Downslope 2 Time	HO: Hold Time

- a:** Closed circuit is required until the termination of W2.
- b:** Closed circuit is required until the termination of SQZ.
- c:** Closed circuit is required until the beginning of SQZ.

### (4) Behavior of END SIG. TIME

- \* **HOLD:** When **2ND STAGE** Signal is closed for 10ms or less, **END** or **GOOD** Signal is output for 10ms.  
When **2ND STAGE** Signal is closed for the longer period than 10ms, **END** or **GOOD** Signal is output for the closed period.
- \* **10ms, 100ms:** **END** or **GOOD** Signal is output for the set period regardless of the condition of **2ND STAGE** Signal.



Symbol:

- |                               |                                     |
|-------------------------------|-------------------------------------|
| SQD: Squeeze Delay Time       | SQZ: Squeeze Time                   |
| RC: Resistance Pre-check Time | CP: Resistance Judgment Time (1 ms) |
| U1: Upslope 1 Time            | W1: 1st Weld Time                   |
| D1: Downslope 1 Time          | CO: Cool Time                       |
| U2: Upslope 2 Time            | W2: 2nd Weld Time                   |
| D2: Downslope 2 Time          | HO: Hold Time                       |


- a:** During the set period (100 ms), **END** or **GOOD** Signal is output regardless of the condition of **2ND STAGE** Input.
- b:** When the period of **2ND STAGE** Input is 10 ms or less, **END** or **GOOD** Signal is output for 10 ms.  
When the period of **2ND STAGE** Input is longer than 10 ms. **END** or **GOOD** Signal is output until **2ND STAGE** Input is open.

## (5) Behavior of SOL1 and SOL2

**SOL1** Output works by the Input of **1ST STAGE**. When **1ST STAGE** Input is open, **SOL1** Output also becomes open if it is before the start of a weld sequence. After the start of a sequence, even if **1ST STAGE** Input is open, **SOL1** Output keeps closed until the sequence comes to an end.

When using **SOL1**, **1ST STAGE** Input allows **SOL1** to adjust a squeeze location. After inputting **1ST STAGE**, weld current can be supplied by **2ND STAGE** Input. **SOL1** becomes opened with **SOL2** output after the end of HO in spite of the input condition of **1ST STAGE**.

**SOL2** output works by the Input of **2ND STAGE** and is closed from SQD to HO.




Symbol:

SQD: Squeeze Delay Time	SQZ: Squeeze Time
RC: Resistance Pre-check Time	CP: Resistance Judgment Time (1 ms)
U1: Upslope 1 Time	W1: 1st Weld Time
D1: Downslope 1 Time	CO: Cool Time
U2: Upslope 2 Time	W2: 2nd Weld Time
D2: Downslope 2 Time	HO: Hold Time

- a: When **1ST STAGE** Input is open before the start of a weld sequence, **SOL1** Output also becomes open.
- b: Once the sequence is started, **SOL1** Output keeps closed until HO is completed even if **1ST STAGE** Input is made open.
- c: **START SIG. TIME**, the period set for prevention of chattering.

## (6) "Error" or "Caution" in PRECHECK


An example of weld sequence is shown, representing that a current goes out of the range between the upper and lower limit set in **PRECHECK Screen** with an error signal, "NG" or "Caution" generated in the use of PRECHECK Current Supply function.



(END Output is not produced.)

## (7) At Occurrence of “Error” or “Caution”

A sample weld sequence is shown, which represents the occasion where **NG** or **CAUTION** is produced while current is supplied.



(END Output is not produced.)

Note) Reset an error at least a second after an error is displayed.  
If an error is reset immediately, the display may not disappear.

## (8) Behavior in TRANS SCAN MODE

### ① OFF Setting

It is a setting of the case where Transformer Selector **MA-650A** is not used.  
The behavior is the same as the one in **(1) Fundamental Sequence**.


Those settings mentioned below in ② through ⑥ are the ones of the case where Transformer Selector **MA-650A** is used.

### ② ON Setting

The weld current is supplied through the transformer set at the item of Transformer No. (**TR#**) in **SCHEDULE Screen**.

Supposing that **SCHEDULE No.** is 2 (**SCH2**) and Transformer No. is 3 (**TR#3**), the timing chart where the supply of weld current is started is shown as follows.

ON Setting in Transformer Selector



a: Transformer Changeover Time (10 ms)

b: Time period for computing a monitored value

See **b: Time period for computing a monitored value** at **9.(1) Fundamental Sequence**.

Because Transformer 3 (**TR#3**) is set for **SCHEDULE #2 (SCH2)**, weld current is supplied through the Transformer connected to Transformer 3 in Transformer Selector **MA-650A**.

③ 1-5 Setting


Firstly, weld current is supplied on the first selected **SCHEDULE No. (N)**, then on the next **SCHEDULE No. (N+1)**, and then on the consecutive **SCHEDULE Nos. N+2, N+3, N+4** in turn.

In this occasion, weld current is supplied through the transformer selected at Transformer No. (**TR#**) in each **SCHEDULE Screen**.

That is to say, in the case that the supply of weld current is started in the condition of SCHEDULE No.2 selected, firstly weld current is supplied on SCHEDULE No.2, then SCHEDULE No.3, SCHEDULE No.4, SCHEDULE No.5, lastly on SCHEDULE No.6.

For example, Supposing that **SCHEDULE No.** is 2 (**SCH2**) and Transformer No. is 1 (**TR#1**), similarly **SCH3-TR#4**, **SCH4-TR#5**, **SCH5-TR#2**, **SCH6-TR#3**, the timing chart where the supply of weld current is started is shown as follows.

1-5 Setting in Transformer Selector



As Transformer 1 (**TR#1**) is set for the first SCHEDULE No.2 (**SCH2**), weld current is firstly supplied through the transformer connected to Transformer 1 of Transformer Selector **MA-650A**, and then through Transformer 4, Transformer 5, Transformer 2 and Transformer 3 in turn. The Squeeze Delay Time (**SQD**) is added in the first weld current only. In the example above, it is added in **SCH2** only.

**a:** Monitored Value Computing Time and Transformer Changeover Time

It is the sum of **b:** Monitored Value Computing Time plus Transformer Changeover Time, 10 ms.

**b:** Monitored Value Computing Time

Changes in dependence on Monitor Value Calculation Mode (**CALCULATION MODE** at **6.(9)@STATUS (1/2) Screen**), Communication Setting (**COMM CONTROL** and **COMM SPEED** at **6.(9)@STATUS (2/2) Screen**) and the type of screens as the following page.

1) In the case of **OFF** or **BI-DIRECTION** at **COMM CONTROL**,

Display Screen	CALCULATION MODE	
	NORMAL	FAST
SCHEDULE	360 ms	310 ms
MONITOR	205 ms	155 ms
COMPARATOR	380 ms	330 ms
ENVELOPE	515 ms	465 ms
PRECHECK	220 ms	170 ms
CONTROL	215 ms	165 ms
STATUS	205 ms	155 ms

Note)  
The values at the tables show maximum ones.

2) In the case of **DATA OUTPUT** at **COMM CONTROL**,

COMM SPEED	Display Screen	CALCULATION MODE	
		NORMAL	FAST
9600bps	SCHEDULE	485 ms	435 ms
	MONITOR	330 ms	280 ms
	COMPARATOR	505 ms	455 ms
	ENVELOPE	640 ms	590 ms
	PRECHECK	345 ms	295 ms
	CONTROL	340 ms	290 ms
	STATUS	330 ms	280 ms
19200bps	SCHEDULE	430 ms	380 ms
	MONITOR	275 ms	225 ms
	COMPARATOR	450 ms	400 ms
	ENVELOPE	585 ms	535 ms
	PRECHECK	290 ms	240 ms
	CONTROL	285 ms	235 ms
	STATUS	275 ms	225 ms
38400bps	SCHEDULE	400 ms	350 ms
	MONITOR	245 ms	195 ms
	COMPARATOR	420 ms	370 ms
	ENVELOPE	555 ms	505 ms
	PRECHECK	260 ms	210 ms
	CONTROL	255 ms	205 ms
	STATUS	245 ms	195 ms

Note)  
The values at the tables show maximum ones.

④ 1-2 Setting

As same as in ③ 1-5 Setting, weld current is supplied on the consecutive 2 **SCHEDULE No.'s** in turn.

Weld current is supplied through the transformer selected at Transformer No. (**TR#**) in each **SCHEDULE Screen**.

**⑤ 1-3 Setting**

Similarly in the following part, weld current is supplied on the consecutive 3 **SCHEDULE No.'s**.

Weld current is supplied through the transformer selected at Transformer No. (**TR#**) in each **SCHEDULE Screen**.

The Squeeze Delay Time (**SQD**) is added in the first weld current only.

**⑥ 1-4 Setting**

Weld current is supplied on the consecutive 4 **SCHEDULE No.'s**.

Weld current is supplied through the transformer selected at Transformer No. (**TR#**) in each **SCHEDULE Screen**.

The Squeeze Delay Time (**SQD**) is added in the first weld current only.

**NG/CAUTION during Weld Current Supplied**

When the errors of Upper Limit (**H**) and Lower Limit (**L**) of the weld current, voltage, power and resistance are set as the setting of NG, the equipment stops by the NG Signal at the occurrence of the errors. When the errors of them are set as the setting of CAUTION, the CAUTION Signal is generated after completing all the supply of weld current.

Concerning the errors of CAUTION when the count-up of a counter has reached the preset counter value, the CAUTION Signal is generated after completing all the supply of weld current.


Concerning NG/CAUTION in other judgment, the equipment stops at the occurrence of NG/CAUTION.

Note) The monitor is not redisplayed when the weld current is not supplied in the schedule (the weld time is 0 ms).

Also, the next welding starts, redisplaying the monitor is interrupted.

Therefore, when the last schedule of transformer changeover is set not to supply the weld current, the previous monitor is remained displayed.

## (9) Movement of Displacement Sensor



Symbol:

SQD: Squeeze Delay Time

WD: Work Detecting Time (0.4 ms Max.)

CP : Resistance Judgment Time (1 ms)

CO : Cool Time

HO: Hold Time

SQZ: Squeeze Time

RC: Resistance Pre-check Time

W1: 1st Weld Time

W2: 2nd Weld Time

### a: Work Detection

When the range of work detection is set to the work detection (**WORK DETECT** at **6.(8) CONTROL Screen**), the work detection is done after the end of SQZ. If the range of work detection is set to  $\pm 00.00$  mm, no work detection is done. Work detection Time is of 0.4 ms Max.

### b: 1st Weld Stop (W1)

When the displacement weld stop (DISPLC) is set to 1st Weld Stop to set the displacement (**WE1 DINPUT** at **6.(8) CONTROL Screen**) and the displacement sensor arrives at the set displacement (**e** at the above figure), 1st Weld is stopped to make the sequence move to the next cool time (CO).

### c: 2nd Weld Stop (W2)

When the displacement weld stop (DISPLC) is set to 2nd Weld Stop to set the displacement (**WE1 DINPUT** at **6.(8) CONTROL Screen**) and the displacement sensor arrives at the set displacement (**f** at the above figure), 2nd Weld is stopped to make the sequence move to the next hold time (HO).

### d: Delay Time

When the value of Delay Time is set to DELAY TIME (**DELAY TIME** at **6.(8) CONTROL Screen**), the displacement (**g** at the above figure) after the delay time elapses is measured.

# 10. External Communication Function

## (1) Introduction


**IPB-5000B** can be used to set schedules from an externally-connected personal computer (abbreviated as PC) or to read monitored data and several kinds of status data.

## (2) Data Transmission

Item	Content
Transmission Mode	Select either of the followings at <b>STATUS Screen</b> : * RS-485, Asynchronous, Half-Duplex * RS-232C
Transmission Rate	Select either of the followings at <b>STATUS Screen</b> : 9600, 19200, 38400 bps
Data Format	Start bit: 1, Data bit: 8, Stop bit: 1, Parity bit: Even
Character Code	Output in ASCII code LF Code: [LF] 0AH, Space Code: [SP] 32H CR Code: [CR] 0DH
Checksum Data	None
Connector	D-Sub 9 pins Pin Position In RS-485, 5: SG, 6: RS+, 9: RS- In RS-232C, 2: RXD, 3: TXD, 5: SG


### (3) Configuration

#### ① RS-485





- Note 1: When controlling two or more Lasers with one host computer, register the device No. (**COMM UNIT#**) for each device. Set the device No. at **STATUS Screen** (See 6.(9)②(d)).
- Note 2: Do not assign one number to more than one device. If one number is assigned to more than one device, data collision and inappropriate system operations may result.
- Note 3: The RS-232C/RS-485 conversion adapter is not included in the accessories. It is required to prepare the adapter at customer's side.

#### Connection of RS-485



For pin numbers without instructions  
Do not connect anything.

② RS-232C



Only a device can be connected.

For pin numbers without instructions  
Do not connect anything.

## (4) Protocol

### ① Single-directional Communication Mode

(When **DATA OUTPUT** is selected at **COMM CONTROL** in **STATUS Screen**)

#### 1) Monitor Data

Data strings: !01001:1.49,1.51,0.51,0.55,0.7,0.3,2.01,2.03,0.61,  
                   A B C D E F G H I J K  
0.55,1.2,0.3,+01.250,010.0,010.0,-00.300 [CR] [LF]  
                   L M N O P Q R

A	Device No.	Fixed to 2 digits (00 to 31)
B	Schedule No.	Fixed to 3 digits (001 to 127)
C	Monitor Current of <b>WE1 (RMS)</b>	Fixed to 4 digits (0.00 to 6.00) (kA)
D	Monitor Current of <b>WE1 (PEAK)</b>	Fixed to 4 digits (0.00 to 6.00) (kA)
E	Monitor Voltage of <b>WE1 (RMS)</b>	Fixed to 4 digits (0.00 to 9.99) (V)
F	Monitor Voltage of <b>WE1 (PEAK)</b>	Fixed to 4 digits (0.00 to 9.99) (V)
G	Monitor Power of <b>WE1</b>	Fixed to 4 digits (0.0 to 20.0) (kW) ( <b>CURR, VOLT, COMB, POWER-H</b> Control) <sup>(NB1)</sup>
		Fixed to 4 digits (0.00 to 9.99) (kW) ( <b>POWER-L</b> Control)
H	Monitor Resistance of <b>WE1</b>	Fixed to 4 digits (0.0 to 99.9) (mΩ) <sup>(NB1)</sup>
I	Monitor Current of <b>WE2 (RMS)</b>	Fixed to 4 digits (0.00 to 6.00) (kA)
J	Monitor Current of <b>WE2 (PEAK)</b>	Fixed to 4 digits (0.00 to 6.00) (kA)
K	Monitor Voltage of <b>WE2 (RMS)</b>	Fixed to 4 digits (0.00 to 9.99) (V)
L	Monitor Voltage of <b>WE2 (PEAK)</b>	Fixed to 4 digits (0.00 to 9.99) (V)
M	Monitor Power of <b>WE2</b>	Fixed to 4 digits (0.0 to 20.0) (kW) ( <b>CURR, VOLT, COMB, POWER-H</b> Control) <sup>(NB1)</sup>
		Fixed to 4 digits (0.00 to 9.99) (kW) ( <b>POWER-L</b> Control)
N	Monitor Resistance of <b>WE2</b>	Fixed to 4 digits (0.0 to 99.9) (mΩ) <sup>(NB1)</sup>
O	Final Displacement	Fixed to 7 digits (-29.999 to +29.999) (mm)
P	Weld Time of <b>WE1</b>	Fixed to 5 digits (000.0 to 500.0) (ms)
Q	Weld Time of <b>WE2</b>	Fixed to 5 digits (000.0 to 500.0) (ms)
R	Displacement at detecting Workpiece	Fixed to 7 digits (-29.999 to +29.999) (mm)

NB1: The range between 0.0 and 9.9 is output as [SP]0.0 and [SP]9.9.

**2) Error Data**

Data strings: !01001:E01,02,03,05,07[CR][LF]  
                   A B    C D E F G

A	Device No.	Fixed to 2 digits (00 to 31)
B	Schedule No.	Fixed to 3 digits (001 to 127) <sup>(NB1)</sup>
C	Error Code 1	Fixed to 2 digits (01 to 31)
D	Error Code 2	Fixed to 2 digits (01 to 31)
E	Error Code 3	Fixed to 2 digits (01 to 31)
F	Error Code 4	Fixed to 2 digits (01 to 31)
G	Error Code 5	Fixed to 2 digits (01 to 31)

The number of Error Codes is of five Max. In the case of only one error code, the error codes D to G are omitted.

NB1: When a setting for consecutive weldings is selected in TANS SCAN MODE, the schedule number of the last occurred error is sent.

**② Bi-directional Communication Mode**

(When **BI-DIRECTION** is selected at **COMM CONTROL** in **STATUS Screen**)

Description of Symbols

- ID1, ID2: Shows Device No.  
                   Fixed to 2 digits (ID1=Ten's place, ID2=One's place)
- SH1, SH2, SH3: Shows Schedule No.  
                   Fixed to 3 digits (SH1=Hundred's place, SH2=Ten's place, SH3=One's place)
- CD1, CD2, CD3: Shows Specified Code.  
                   CD1-----Alphabet Classified Symbol  
                   CD2, CD3----Code Classified Number  
                   (See **(5)③Specified Code** for details of codes.)

No.	Description of Command	Code
1	Inquiry about Model and ROM Version	# Device No. I
	<p>Example: Read model of Device No. 1 and ROM Version                      From Host PC to <b>IPB-5000B</b>  <u><b># ID1 ID2 I CR LF</b></u>                      (# 0 1 I CR LF)                      From <b>IPB-5000B</b> to Host PC  <u><b>! ID1 ID2 : IPB-5000B , ROM Version CR LF</b></u>                      (! 0 1 : IPB-5000B , ROM Version CR LF)</p> <p>Note) When "*" is set for both ID1 and ID2, all connected devices respond. In the case that all devices respond, the time-lag of response is 100 ms multiplied by ID No. (Device No.).</p>	

No.	Description of Command	Code
2	Reading of Schedule Data	# Device No. R Schedule No. *
	<p>Example: Read all data of Schedule No. 8 in Device No. 01.                      From Host PC to <b>IPB-5000B</b>  <u><b># ID1 ID2 R SH1 SH2 SH3 * CR LF</b></u>                      (# 0 1 R 0 0 8 * CR LF)                      From <b>IPB-5000B</b> to Host PC  <u><b>! ID1 ID2 SH1 SH2 SH3 : Data String CR LF</b></u>                      (! 0 1 0 0 8 : Data String CR LF)</p> <p>Note) When Schedule No. (<b>SH1, SH2, SH3</b>) is “000”, the basic set conditions are read.                      See <b>(5)ⓄOrder Table of Schedule Data</b> for the data order of a Schedule.</p>	
3	Setting of Schedule Data	# Device No. W Schedule No. : Data
	<p>Example: Set data on Schedule No. 8 in Device No. 01.                      From Host PC to <b>IPB-5000B</b>  <u><b># ID1 ID2 W SH1 SH2 SH3 : Data String CR LF</b></u>                      (# 0 1 W 0 0 8 : Data String CR LF)                      From <b>IPB-5000B</b> to Host PC  <u><b>! ID1 ID2 SH1 SH2 SH3 : Data String CR LF</b></u>                      (! 0 1 0 0 8 : Data String CR LF)</p> <p>Note) * Regarding the number of digits and location of the decimal point in each data, each data is required to follow Data Code Table and be separated with “,”.                      * See <b>(5)ⓄOrder Table of Schedule Data</b> for the data order of a Schedule.                      * When Schedule No. is “000”, the basic set conditions are set.                      * The set data is returned as confirmation from <b>IPB-5000B</b>. When data outside the range is set, the last data before setting is exactly returned.</p>	
4	Reading of Specified Item	# Device No. R Schedule No. Specified Code
	<p>Example: Read 2nd. Weld Time (23 ms) on Schedule No. 31 in Device No. 01.                      From Host PC to <b>IPB-5000B</b>  <u><b># ID1 ID2 R SH1 SH2 SH3 CD1 CD2 CD3 CR LF</b></u>                      (# 0 1 R 0 3 1 T 0 7 CR LF)                      From <b>IPB-5000B</b> to Host PC  <u><b>! ID1 ID2 SH1 SH2 SH3 : Data CR LF</b></u>                      (! 0 1 0 3 1 T 0 7 : 0 2 3 . 0 m s CR LF)</p> <p>Note) See <b>(5)ⓄSpecified Code</b> for Specified Code and Data.</p>	

No.	Description of Command	Code
5	Setting of Specified Data  Example: Set the current of 1st. Weld Time on Schedule No. 31 in Device No. 01 to 3.2 kA. From Host PC to <b>IPB-5000B</b> <u><b># ID1 ID2 W SH1 SH2 SH3 CD1 CD2 CD3 : Data CR LF</b></u> (# 0 1 W 0 3 1 H 0 1 : 3 . 2 0 k A CR LF) From <b>IPB-5000B</b> to Host PC <u><b>! ID1 ID2 SH1 SH2 SH3 : Data CR LF</b></u> (! 0 1 0 3 1 H 0 1 : 3 . 2 0 k A CR LF) Note) * See <b>(5)③Specified Code</b> for Specified Code and Data. * Regarding the number of digits and location of the decimal point in each data, each data is required to follow Data Code Table. * The set data is returned as confirmation from <b>IPB-5000B</b> . When data outside the range is set, the last data before setting is exactly returned.	# Device No. W Schedule No. Specified Code : Data
6	Reading of Initial Setting  Example: Read model of Transformer <b>IT*-360*6</b> (Data is 01) at Initial Setting ( <b>6.(9) STATUS Screen</b> ) in Device No. 01. From Host PC to <b>IPB-5000B</b> <u><b># ID1 ID2 R CD1 CD2 CD3 CR LF</b></u> (# 0 1 R P 4 0 CR LF) From <b>IPB-5000B</b> to Host PC <u><b>! ID1 ID2 CD1 CD2 CD3 : Data CR LF</b></u> (! 0 1 P 4 0 : 0 1 CR LF) Note) See <b>(5)③Specified Code</b> for Specified Code and Data.	# Device No. R Specified Code
7	Setting of Initial Setting Condition  Example: Set the time period during which Weld End Signal Time is output to 100 ms (Data is 01) at Initial Setting ( <b>6.(9) STATUS Screen</b> ) in Device No. 01. From Host PC to <b>IPB-5000B</b> <u><b># ID1 ID2 W CD1 CD2 CD3 : Data CR LF</b></u> (# 0 1 W P 0 3 : 0 1 CR LF) From <b>IPB-5000B</b> to Host PC <u><b>! ID1 ID2 CD1 CD2 CD3 : Data CR LF</b></u> (! 0 1 P 0 3 : 0 1 CR LF) Note) * See <b>(5)③Specified Code</b> for Specified Code and Data. * Regarding the number of digits and location of the decimal point in each data, each data is required to follow Data Code Table. * The set data is returned as confirmation from <b>IPB-5000B</b> . When data outside the range is set, the last data before setting is exactly returned.	# Device No. W Specified Code : Data

No.	Description of Command	Code
8	Reading of monitor data in specified range  Example: Read monitor data from No. 0001 to 0017 in Device No. 01. From Host PC to <b>IPB-5000B</b> <u><b># ID1 ID2 ? Start No. – End No. CR LF</b></u> (# 0 1 ? 0 0 0 1 - 0 0 1 7 CR LF) From <b>IPB-5000B</b> to Host PC <u><b>! ID1 ID2 Start No. – End No., Data CR LF</b></u> (! 0 1 0 0 0 1 - 0 0 1 7 , Data String CR LF) Note) See (5)②Order Table of Monitor Data for Start No. and End No.	# Device No. ? Specifying of Range
9	Reading of Trouble  Example: Read all troubled items (Error Codes, E02 E05) in Device No. 01. From Host PC to <b>IPB-5000B</b> <u><b># ID1 ID2 R CD1 CD2 CD3 CR LF</b></u> (# 0 1 R E 9 9 CR LF) From <b>IPB-5000B</b> to Host PC <u><b>! ID1 ID2 SH1 SH2 SH3 : Data CR LF</b></u> (! 0 1 E 9 9 : E 0 2 , E 0 5 CR LF) Note) All error codes are read (Each error code is separated with “,”). In no trouble, data of “00” is returned. (! 0 1 E 9 9 : 0 0 CR LF)	# Device No. R E99
10	Error Reset  Example: Release troubles in Device No. 01. From Host PC to <b>IPB-5000B</b> <u><b># ID1 ID2 R E 0 0 CR LF</b></u> (# 0 1 R E 0 0 CR LF) From <b>IPB-5000B</b> to Host PC <u><b>! ID1 ID2 E 0 0 : 0 0 CR LF</b></u> (! 0 1 E 0 0 : 0 0 CR LF)	# Device No. R E00

**(5) Data Code Table****① Order Table of Schedule Data**

1) Specific Data in accordance with Schedule No. (Schedule No.: 001 to 127)

Order	Character String	Item	Range of Setting	Increment/Decrement	
1	nnnn,	Squeeze Time	0000 to 9999	1ms	
2	nnn.n,	Upslope 1 Time <sup>(NB1)</sup>	000.0 to 500.0	0.2ms	
3	nnn.n,	1st. Weld Time <sup>(NB1)</sup>	000.0 to 500.0	0.2ms	
4	nnn.n,	Downslope 1 Time <sup>(NB1)</sup>	00.0 to 500.0	0.2ms	
5	nn.n,	Cool Time <sup>(NB1)</sup>	00.0 to 99.8	0.2ms	
6	nnn.n,	Upslope 2 Time <sup>(NB1)</sup>	000.0 to 500.0	0.2ms	
7	nnn.n,	2nd. Weld Time <sup>(NB1)</sup>	000.0 to 500.0	0.2ms	
8	nnn.n,	Downslope 2 Time <sup>(NB1)</sup>	000.0 to 500.0	0.2ms	
9	nnn,	Hold Time	000 to 999	1ms	
10	n.nn,	WE1 Current Setting	MIN CURR: NORMAL	0.40 to 6.00	0.01kA
			MIN CURR: LOW	0.10 to 6.00	
11	n.nn,	WE2 Current Setting	MIN CURR: NORMAL	0.40 to 6.00	0.01kA
			MIN CURR: LOW	0.10 to 6.00	
12	n.nn,	WE1 Voltage Setting	0.30 to 9.99	0.01V	
13	n.nn,	WE2 Voltage Setting	0.30 to 9.99	0.01V	
14	nn.n,	WE1 Power Setting	CONTROL: POWER-H	00.2 to 20.0	0.1kW
			CONTROL: POWER-L	0.10 to 9.99	0.01kW
15	nn.n,	WE2 Power Setting	CONTROL: POWER-H	00.2 to 20.0	0.1kW
			CONTROL: POWER-L	0.10 to 9.99	0.01kW
16	n,	Transformer No.	1 to 5	----	
17	nn,	Control Method in WE1	00 to 04 <sup>(NB2)</sup>	----	
18	nn,	Control Method in WE2			
19	nnnn	Squeeze Delay Time	0000 to 9999	1ms	

NB1: You can select whether or not Upslope Time and Downslope Time are included in Weld Time. If they are not included, the total time of Upslope Time, Weld Time and Downslope is up to 500 ms.

NB2: 00: CURR, 01: VOLT, 02: COMB, 03: POWER (**POWER-H**), 04: POWER (**POWER-L**)

## 2) Common Data

Order	Character String	Item	Contents
1	nn,	Selection of Welding Transformer	01: IT*-360*6 02: IT*-780*6
2	nn,	Weld Time	00: Slope Time Excluded 01: Slope Time Included
3	nn,	Selection of Start-up Condition Stabilizing Time	00: 1ms      01: 5ms 02: 10ms     03: 20ms
4	nn,	Selection of Start-up Input Signal Type	00: No Self-sustaining 01: Self-sustaining from Weld Time 02: Self-sustaining from Squeeze Time
5	nn,	Schedule Select Method	00: Closed Circuit of Schedule Select Terminal (No Parity) 01: Closed Circuit of Schedule Select Terminal (Parity Valid) 02: Select on Front Panel
6	nn,	End Signal Output Time	00: 10ms      01: 100ms 02: While Start Signal Output
7	nn,	Monitor Mode	00: Slope Time Excluded 01: Slope Time Included
8	nn,	Transformer Scan Mode	00: OFF      01: ON 02: 1-2      03: 1-3 04: 1-4      05: 1-5
9	nn,	No-current Monitor Neglect Time	00 to 10 (ms)
10	nn,	Pulse Width Monitor Neglect Time	00 to 10 (ms)
11	nn,	NG Output Mode	00: Open Circuit at NG 01: Closed Circuit at NG
12	nn,	READY Output Mode Setting	00: ON at Weld ON 01: ON at Power ON
13	nn,	Monitor Value Calculation Mode	00: High Rate Sampling 01: Low Rate Sampling, Faster Takt Time
14	nn,	Minimum Current	00: Settable from 10% of full scale. 01: Settable from 2.5% of full scale.
15	nn	Displacement polarity	00: Set the force-applying direction as plus. 01: Set the force-applying direction as minus.

## ② Order Table of Monitor Data (Most Recent Monitor Value)

Order	Output Data (n=0 to 9)	Contents	
0001	n.nn,	WE1 Monitor Current (Peak Value)	
0002	n.nn,	WE2 Monitor Current (Peak Value)	
0003	n.nn,	WE1 Monitor Voltage (Peak Value)	
0004	n.nn,	WE2 Monitor Voltage (Peak Value)	
0005	nn.n, <sup>(NB1)</sup>	WE1 Monitor Power	<b>POWER-H</b> Constant Power Control
	n.nn,		<b>POWER-L</b> Constant Power Control
0006	nn.n, <sup>(NB1)</sup>	WE2 Monitor Power	<b>POWER-H</b> Constant Power Control
	n.nn,		<b>POWER-L</b> Constant Power Control
0007	nn.n, <sup>(NB1)</sup>	WE1 Monitor Resistance	
0008	nn.n, <sup>(NB1)</sup>	WE2 Monitor Resistance	
0009	n.nn,	Precheck Monitor Current	
0010	n.nn,	WE1 Monitor Current (RMS Value)	
0011	n.nn,	WE2 Monitor Current (RMS Value)	
0012	n.nn,	WE1 Monitor Voltage (RMS Value)	
0013	n.nn,	WE2 Monitor Voltage (RMS Value)	
0014	+/-nn.nnn,	Final Displacement	
0015	nnn.n,	W1 Weld Time	
0016	nnn.n,	W2 Weld Time	
0017	+/-nn.nnn	Displacement at detecting Workpiece	

NB1: The range between 0.0 and 9.9 is output as [SP]0.0 and [SP]9.9.

③ Specified Code

1) Specifying of Weld Sequence (T)

Dimension of “ms” is added to each data.

Specified Code	Item	Range of Setting	Increment/Decrement
T00	Squeeze Delay Time	0000ms to 999ms	1ms
T01	Squeeze Time	0000ms to 999ms	1ms
T02	Upslope 1 Time	000.0ms to 500.0ms	0.2ms
T03	1st. Weld Time	000.0ms to 500.0ms	0.2ms
T04	Downslope 1 Time	000.0ms to 500.0ms	0.2ms
T05	Cool Time	00.0ms to 99.8ms	0.2ms
T06	Upslope 2 Time	000.0ms to 500.0ms	0.2ms
T07	2nd. Weld Time	000.0ms to 500.0ms	0.2ms
T08	Downslope 2 Time	000.0ms to 500.0ms	0.2ms
T13	Hold Time	000ms to 999ms	1ms
T15	Precheck Weld Time	00.0ms to 10.0ms	0.2ms

2) Setting of Control Current, Voltage and Power (H)

Specified Code	Item	Range of Setting	Increment/Decrement
H01	WE1 Current Setting	NORMAL 0.40kA to 4.00kA (IT*-360*6) 0.60kA to 6.00kA (IT*-780*6) Bracket ( ) shows Transformer.	0.01kA
		LOW 0.10kA to 4.00kA (IT*-360*6) 0.15kA to 6.00kA (IT*-780*6)	0.01kA
H02	WE2 Current Setting	NORMAL 0.40kA to 4.00kA (IT*-360*6) 0.60kA to 6.00kA (IT*-780*6)	0.01kA
		LOW 0.10kA to 4.00kA (IT*-360*6) 0.15kA to 6.00kA (IT*-780*6)	0.01kA
H04	WE1 Voltage Setting	0.30V to 9.99V	0.01V
H05	WE2 Voltage Setting	0.30V to 9.99V	0.01V
H06	WE1 Power Setting	00.2kW to 20.0kW (POWER-H)	0.1kW
		0.10kW to 9.99kW (POWER-L)	0.01kW
H07	WE2 Power Setting	00.2kW to 20.0kW (POWER-H)	0.1kW
		0.10kW to 9.99kW (POWER-L)	0.01kW
H21	Precheck Voltage Setting	0.00V to 9.99V	0.01V
H50	Transformer Number	1 to 5	1

3) Setting of Monitor Upper/Lower Limit (N)

Specified Code	Item	Range of Setting	Increment/Decrement	
N00	WE1 Monitor Current Upper Limit	0.00kA to 9.99kA	0.01kA	
N01	WE1 Monitor Current Lower Limit	0.00kA to 9.99kA	0.01kA	
N02	WE2 Monitor Current Upper Limit	0.00kA to 9.99kA	0.01kA	
N03	WE2 Monitor Current Lower Limit	0.00kA to 9.99kA	0.01kA	
N06	WE1 Monitor Voltage Upper Limit	0.00V to 9.99V	0.01V	
N07	WE1 Monitor Voltage Lower Limit	0.00V to 9.99V	0.01V	
N08	WE2 Monitor Voltage Upper Limit	0.00V to 9.99V	0.01V	
N09	WE2 Monitor Voltage Lower Limit	0.00V to 9.99V	0.01V	
N12	WE1 Monitor Power Upper Limit	<b>POWER-H</b> <sup>(NB1)</sup>	00.0kW to 99.9kW	0.1kW
		<b>POWER-L</b> <sup>(NB1)</sup>	0.00kW to 9.99kW	0.01kW
N13	WE1 Monitor Power Lower Limit	<b>POWER-H</b>	00.0kW to 99.9kW	0.1kW
		<b>POWER-L</b>	0.00kW to 9.99kW	0.01kW
N14	WE2 Monitor Power Upper Limit	<b>POWER-H</b>	00.0kW to 99.9kW	0.1kW
		<b>POWER-L</b>	0.00kW to 9.99kW	0.01kW
N15	WE2 Monitor Power Lower Limit	<b>POWER-H</b>	00.0kW to 99.9kW	0.1kW
		<b>POWER-L</b>	0.00kW to 9.99kW	0.01kW
N24	WE1 Monitor Resistance Upper Limit	00.0m* to 99.9m*	0.1m* <sup>(NB2)</sup>	
N25	WE1 Monitor Resistance Lower Limit	00.0m* to 99.9m*	0.1m*	
N26	WE2 Monitor Resistance Upper Limit	00.0m* to 99.9m*	0.1m*	
N27	WE2 Monitor Resistance Lower Limit	00.0m* to 99.9m*	0.1m*	
N36	Final Displacement Upper Limit	-29.999 to +29.999mm	0.001mm	
N37	Final Displacement Lower Limit	-29.999 to +29.999mm	0.001mm	
N42	Resistance Precheck Monitor Current Upper Limit	0.00kA to 9.99kA	0.01kA	
N43	Resistance Precheck Monitor Current Lower Limit	0.00kA to 9.99kA	0.01kA	
N65	WE1 Weld Time Upper Limit	000.0ms to 500.0ms	0.1ms	
N66	WE1 Weld Time Lower Limit	000.0ms to 500.0ms	0.1ms	
N67	WE2 Weld Time Upper Limit	000.0ms to 500.0ms	0.1ms	
N68	WE2 Weld Time Lower Limit	000.0ms to 500.0ms	0.1ms	
N70	Setting of Current RMS/PEAK	0:RMS/1:PEAK	--	
N72	Setting of Voltage RMS/PEAK	0:RMS/1:PEAK	--	
N73	Displacement Delay Time	0 to 999ms		
N74	Workpiece Detect Upper Limit	-29.999 to +29.999mm	0.001mm	
N75	Workpiece Detect Lower Limit			

NB1: **POWER-H**, **POWER-L** indicates Constant Power Control.

NB2: The symbol "\*" means Ω.

4) Reading of Monitor Judgment Results (J)

The function to save judging results is not equipped. Read them after each welding.

Specified Code	Item	Contents
J00	Judgment Result of Current Upper/Lower Limit	Judgment Result Data: 'N' means OK. 'L' means Lower Limit NG. 'H' means Upper Limit NG.
J03	Judgment Result of Voltage Upper/Lower Limit	
J06	Judgment Result of Power Upper/Lower Limit	
J12	Judgment Result of Resistance Upper/Lower Limit	
J18	Judgment Result of Final Displacement	
J55	Judgment Result of Weld Time	
J21	Judgment Result of Precheck Current	Judgment of Weld Workpiece Setting Status in Precheck: 'N' means OK. 'E' means NG.
J56	Judgment Result of Work Detection	
J99	Judgment Result (Batch Output)	Batch output of monitor judgment result

• Batch Output of Monitor Judgment Result (Specified code: J99)

Order	Output Data	Contents
1	n, <sup>(NB1)</sup>	Judgment Result of Current Upper/Lower Limit
2	n, <sup>(NB1)</sup>	Judgment Result of Voltage Upper/Lower Limit
3	n, <sup>(NB1)</sup>	Judgment Result of Power Upper/Lower Limit
4	n, <sup>(NB1)</sup>	Judgment Result of Resistance Upper/Lower Limit
5	n, <sup>(NB2)</sup>	Judgment Result of Precheck Current
6	n, <sup>(NB1)</sup>	Judgment Result of Final Displacement
7	n, <sup>(NB1)</sup>	Judgment Result of Weld Time
8	n <sup>(NB2)</sup>	Judgment Result of Work Detection

NB1: Judgment Result Data: 'N' means OK, 'L' means Lower Limit NG, and 'H' means Upper Limit NG.

NB2: Judgment Result Data: 'N' means OK, and 'E' means NG.

5) Reading of Monitored Value (M)

The function to save judging results is not equipped. Read them after each welding.

Specified Code	Item	Contents (n=0 to 9)
M00	WE1 Monitor Current (PEAK Value)	n.nnkA
M01	WE2 Monitor Current (PEAK Value)	n.nnkA
M03	WE1 Monitor Voltage (PEAK Value)	n.nnV
M04	WE2 Monitor Voltage (PEAK Value)	n.nnV
M06	WE1 Monitor Power ( <b>POWER-H</b> ) <sup>(NB2)</sup>	nn.nkW <sup>(NB1)</sup>
	WE1 Monitor Power ( <b>POWER-L</b> ) <sup>(NB2)</sup>	n.nnkW
M07	WE2 Monitor Power ( <b>POWER-H</b> ) <sup>(NB2)</sup>	nn.nkW <sup>(NB1)</sup>
	WE2 Monitor Power ( <b>POWER-L</b> ) <sup>(NB2)</sup>	n.nnkW
M12	WE1 Monitor Resistance	nn.nm* <sup>(NB1)</sup> <sup>(NB3)</sup>
M13	WE2 Monitor Resistance	nn.nm* <sup>(NB1)</sup> <sup>(NB3)</sup>
M18	Final Displacement	+/-nn.nnnmm
M21	Precheck Monitor Current	n.nnkA
M23	WE1 Weld Time	nnn.nms
M24	WE2 Weld Time	nnn.nms
M30	WE1 Monitor Current (RMS Value)	n.nnkA
M31	WE2 Monitor Current (RMS Value)	n.nnkA
M32	WE1 Monitor Voltage (RMS Value)	n.nnV
M33	WE2 Monitor Voltage (RMS Value)	n.nnV
M65	Work Detecting Displacement	+/-nn.nnnmm
M99	Monitor Value (Batch Output)	Batch output of monitor value

NB1: The range between 0.0 and 9.9 is output as [SP]0.0 and [SP]9.9.

NB2: **POWER-H**, **POWER-L** indicates Constant Power Control.

NB3: The symbol "\*" means Ω.

- Batch Output of Monitor Value (Specified code: M99)

Order	Output Data (n=0 to 9)	Contents
1	n.nn,	WE1 Monitor Current (PEAK Value)
2	n.nn,	WE2 Monitor Current (PEAK Value)
3	n.nn,	WE1 Monitor Voltage (PEAK Value)
4	n.nn,	WE2 Monitor Voltage (PEAK Value)
5	nn.n, <sup>(NB1)</sup>	WE1 Monitor Power (POWER-H Constant Power Control)
	n.nn,	WE1 Monitor Power (POWER-L Constant Power Control)
6	nn.n, <sup>(NB1)</sup>	WE2 Monitor Power (POWER-H Constant Power Control)
	n.nn,	WE2 Monitor Power (POWER-L Constant Power Control)
7	nn.n, <sup>(NB1)</sup>	WE1 Monitor Resistance
8	nn.n, <sup>(NB1)</sup>	WE2 Monitor Resistance

Order	Output Data (n=0 to 9)	Contents
9	n.nn,	Precheck Monitor Current
10	n.nn,	WE1 Monitor Current (RMS Value)
11	n.nn,	WE2 Monitor Current (RMS Value)
12	n.nn,	WE1 Monitor Voltage (RMS Value)
13	n.nn,	WE2 Monitor Voltage (RMS Value)
14	±nn.nnn,	Final Displacement
15	nnn.n,	WE1 Weld Time
16	nnn.n,	WE2 Weld Time
17	±nn.nnn	Work Detecting Displacement

NB1: The range between 0.0 and 9.9 is output as [SP]0.0 and [SP]9.9.

6) Reading of Items relating with Envelope (V)

Specified Code	Item	Contents
V00	Envelope Type	0: Current, 1: Voltage, 2: Power, 3: Resistance, 4: Displacement
V01	Interval Start Time	nnnnnms
V02	Interval End Time	nnnnnms
V03	Offset Upper Limit (+)	n.nnkA/n.nnV/nn.nkW/nn.nm*/ nn.nnnmm <sup>(NB1)</sup>
V04	Offset Lower Limit (-)	n.nnkA/n.nnV/nn.nkW/nn.nm*/ nn.nnnmm <sup>(NB1)</sup>
V05	Envelope ON/OFF	0 : OFF, 1 : ON

NB1: The symbol “\*” means Ω.

7) Setting of Items relating with Counter (C)

Specified Code	Item	Contents
C00	Reading of Displayed Counter	
C14	Counter Mode	0: TOTAL, 1: GOOD, 2: WORK
C05	Preset (TOTAL/GOOD)	000000 to 999999
C06	Preset (WORK)	000000 to 999999
C07	Preset (WELD)	00 to 99
C11	Counter Reset (All Counters)	
C12	Resolution of Displacement Sensor	00.1 to 10.0um

8) Setting of Initial Setting Condition (P)

Specified Code	Item	Contents
P01	Schedule Select Method	00: Closed Circuit of Schedule Select Terminal (No Parity) 01: Closed Circuit of Schedule Select Terminal (Parity Valid) 02: Select on Front Panel
P02	Start Signal Stabilizing Time (Delay Time)	00: 1ms    01: 5ms 02: 10ms   03: 20ms
P03	End Signal Output Time	00: 10ms   01: 100ms 02: While Start Signal Output
P04	Self-sustaining Time at Starting	00: No Self-sustaining 01: Self-sustaining from Weld Time 02: Self-sustaining from Squeeze Time
P10	Weld ON/OFF	00: Weld OFF 01: Weld ON
P40	Weld Transformer	00: IT*-142*6 (Do not select) 01: IT*-360*6   02: IT*-780*6
P41	Monitor Value Display Mode	00: Slope Time Excluded 01: Slope Time Includes
P43	Transformer Scan Mode	00: OFF    01: ON    02: 1-2 03: 1-3    04: 1-4    05: 1-5
P45	No-current Monitor Start Time	00 to 10 (Dimension "ms" Eliminated)
P46	Pulse Width Monitor Start Time	00 to 10 (Dimension "ms" Eliminated)
P47	NG Terminal Mode Setting	00: Open Circuit at NG 01: Closed Circuit at NG
P48	READY Output Mode Setting	00: ON at Weld ON 01: ON at Power ON
P49	Monitor Value Calculation Method	00: Normal 01: Fast
P52	Weld Time	00: Slope Time Excluded 01: Slope Time Included
P60	Minimum Current	00: Settable from 10% of full scale. 01: Settable from 2.5% of full scale.
P61	Displacement polarity	00: Set the force-applying direction as plus. 01: Set the force-applying direction as minus.

9) Reading of Error and Error Reset (E)

Specified Code	Item
E00	Error Reset
E99	Error Reading



See **12. Error Codes** for details of Codes E01 to E25.

10) Control (Q)

Specified Code	Item	Contents
Q00	W1 Control Mode	00: Constant Current 01: Constant Voltage 02: COMBI
Q01	W2 Control Mode	03: Constant Power ( <b>POWER-H</b> ) 04: Constant Power ( <b>POWER-L</b> )
Q02	Selection of W1 Weld Stop Input	00: OFF 01: Displacement
Q03	Selection of W2 Weld Stop Input	02: Current 03: Voltage
Q04	W1 Weld Stop Condition	n.nnkA n.nnV
Q05	W2 Weld Stop Condition	+/-nn.nnnmm

# 11. Specifications

## (1) Specifications

Items	Common Specification in IPB-5000B
<b>Weld Current Control Method</b>	(1) Constant Current Control: Controls so that weld current can be the set current (2) Constant Voltage Control: Controls so that the voltage detected at V sensing cord connected across electrodes can be the set voltage (3) Constant Current/Constant Voltage Combination Control: Either of both methods in which the value arrives at set value more quickly is prioritized while both Constant Current and Constant Voltage Control method work simultaneously (4) Constant Power Control: Controls so that power value can be the set power
<b>Rated Capacity</b>	17.4kVA (IT*-780*6 in use)
<b>Schedule Select Numbers</b>	127 Schedules (1 to 127), Selected by External Signal or on Panel
<b>Timer Setting Range</b>	<p>Squeeze Delay Time (SQD): 0000 to 9999ms (1ms each*)                      * "each" represents Increment or Decrement.</p> <p>Squeeze Time (SQZ): 0000 to 9999ms (1ms ea.)                      PRECHECK Current (RC): 00.0 to 10.0ms (0.2ms ea.)                      PRECHECK Judgment (CP): 1ms (Fixed)</p> <p>Upslope 1 (U1): 000.0 to 500.0ms (0.2ms ea.)                      Weld Time 1 (W1): 000.0 to 500.0ms (0.2ms ea.)                      Downslope 1 (D1): 000.0 to 500.0ms (0.2ms ea.)                      Cool Time (CO): 00.0 to 99.8ms (0.2ms ea.)                      Upslope 2 (U2): 000.0 to 500.0ms (0.2ms ea.)                      Weld Time 2 (W2): 000.0 to 500.0ms (0.2ms ea.)                      Downslope 2 (D2): 000.0 to 500.0ms (0.2ms ea.)                      Hold Time (HO): 000 to 999ms (1ms ea.)</p> <p>When Upslope and Downslope are included in Weld Time.</p>  <p>When Upslope and Downslope are not included in Weld Time.                      (The total time of Upslope Time, Weld Time and Downslope is up to 500ms.)</p> 

Items	Common Specification in IPB-5000B													
<b>Current Setting Range</b>	<table border="1" data-bbox="604 291 1396 515"> <thead> <tr> <th>Maximum current setting</th> <th>Transformer</th> <th>Setting range</th> </tr> </thead> <tbody> <tr> <td rowspan="2">NORMAL (From 10 to 100% of Transformer maximum current)</td> <td>IT*-360*6</td> <td>0.40 to 4.00kA</td> </tr> <tr> <td>IT*-780*6</td> <td>0.60 to 6.00kA</td> </tr> <tr> <td rowspan="2">LOW (From 2.5 to 100% of Transformer maximum current)</td> <td>IT*-360*6</td> <td>0.10 to 4.00kA</td> </tr> <tr> <td>IT*-780*6</td> <td>0.15 to 6.00kA</td> </tr> </tbody> </table> <p>The maximum current available for welding depends on the load such as the welding head used. When you use a general welding head, the approximate maximum current is 3000A for IT*-360*6 and 4000A for IT*-780*6. Also, in LOW mode, the set current may not flow when the current less than 400A for IT*-360*6 or 600A for IT*-780*6 is set.</p>	Maximum current setting	Transformer	Setting range	NORMAL (From 10 to 100% of Transformer maximum current)	IT*-360*6	0.40 to 4.00kA	IT*-780*6	0.60 to 6.00kA	LOW (From 2.5 to 100% of Transformer maximum current)	IT*-360*6	0.10 to 4.00kA	IT*-780*6	0.15 to 6.00kA
Maximum current setting	Transformer	Setting range												
NORMAL (From 10 to 100% of Transformer maximum current)	IT*-360*6	0.40 to 4.00kA												
	IT*-780*6	0.60 to 6.00kA												
LOW (From 2.5 to 100% of Transformer maximum current)	IT*-360*6	0.10 to 4.00kA												
	IT*-780*6	0.15 to 6.00kA												
<b>Voltage Setting Range</b>	0.30 to 9.99V													
<b>Power Setting Range</b>	00.2 to 20.0kW ( <b>POWER-H</b> ) 0.10 to 9.99kW ( <b>POWER-L</b> ) * <b>POWER-H, POWER-L</b> indicates Constant Power Control.													
<b>Monitor</b>	IPB-5000B holds the monitored value of all schedules (only the latest one for waveform) while the power is on. When the power is turned off, all values are cleared.													
<b>Resistance PRE-CHECK Function</b>	Weld Time Setting Range: 00.0 to 10.0ms (0.2ms ea.) Voltage Setting Range: 0.30 to 9.99V (0.01V ea.) Current Upper/Lower Limit: 0.00 to 9.99kA (0.01kA ea.)													
<b>Monitor Upper/Lower Limit Setting Range</b>	Current: 0.00 to 9.99kA (0.01kA ea.) Voltage: 0.00 to 9.99V (0.01V ea.) Power ( <b>POWER-H</b> )*: 00.0 to 20.0kW (0.1kW ea.) ( <b>POWER-L</b> )*: 0.00 to 9.99kW (0.01kW ea.) Resistance: 00.0 to 99.9mΩ (0.1mΩ ea.) Weld Time: 000.0 to 500.0ms (0.2ms ea.) * <b>POWER-H, POWER-L</b> indicates Constant Power Control.													
<b>Envelope</b>	Upper/Lower Limit setting is possible for the only one waveform selected among Current, Voltage, Power and Resistance.													
<b>Weld Stop</b>	When WE1 or WE2 reaches the designated value of Current or Voltage, WE1 moves to CO and WE2, to HO. Setting Range of Weld Stop Current Value IT*-360*6: 0.40 to 4.00kA IT*-780*6: 0.60 to 6.00kA Setting Range of Weld Stop Voltage Value : 0.30 to 9.99V													

Items	Common Specification in IPB-5000B
<b>Counter</b>	<p>Set at <b>COUNTER</b>. Count-up Output is produced when the counting arrives at Pre-set value for each mode.</p> <p>(1) <b>TOTAL</b> (Total Counter Mode) Every time the weld current is supplied, Count-up (+1 increment) is performed regardless of a judgment result. Counter Pre-set Setting Range: 000000 to 999999</p> <p>(2) <b>GOOD</b> (Good Product Counter Mode) Every time GOOD is judged, Count-up is performed Counter Pre-set Setting Range: 000000 to 999999</p> <p>(3) <b>WORK</b> (Production Counter Mode) Every time the counting arrives at the set value of Weld Counter, WORK Count is counted- up (+1 increment). When the monitored value is judged as No Good, Count-up is not performed. WELD Counter Pre-set Setting Range: 00 to 99 WORK Counter Pre-set Setting Range: 000000 to 999999</p> <p>Note: The period for retaining the memory of counted numbers is approximately 10 days since the day when a power supply is turned off at latest.</p>
<b>Start Signal Stabilizing Period</b>	<p>Set at <b>START SIG. TIME</b>. Weld Sequence is started after finding the set value of 1, 5, 10 or 20ms and the Start Signal.</p>
<b>Self-sustaining Method</b>	<p>Set at <b>START SIG. HOLD</b>.</p> <p><b>NO HOLD</b>: No self-sustaining action <b>WE HOLD</b>: Self-sustaining action works from the start of current supply <b>SQ HOLD</b>: Self-sustaining action works from the start of SQD</p>
<b>Schedule Select Method</b>	<p>Set at <b>SCHEDULE#</b>.</p> <p><b>EXT. (NP)</b>: Selected by the use of binary data <b>EXT. (P)</b>: Selected by binary data with odd-numbered parity <b>PANEL</b>: Selected on Panel</p>
<b>Period for outputting END or GOOD Signal</b>	<p>Set at <b>END SIG. TIME</b>. Output for 10ms, 100ms or the period during which Start Signal is input (Note: if it is input 10ms or less, END or GOOD Signal is output for 10ms.). <b>HOLD</b>: Output for period during which Start Signal is input <b>10ms</b>: Output for 10ms <b>100ms</b>: Output for 100ms</p>
<b>Monitor Computing Range</b>	<p>Set at <b>MONITOR MODE</b>.</p> <p><b>EXCLUDE SLOPE</b>: Computing a monitored value excluding Slope Period <b>INCLUDE SLOPE</b>: Computing a monitored value including Slope Period</p>
<b>PARITY/WE1STOP Input Selection</b>	<p>Set at <b>SCHEDULE#</b>.</p> <p><b>EXT. (P)</b>: Parity Input at External Input Terminal Pin 14 <b>EXT. (NP) or PANEL</b>: WELD1 Stop Input at External Input Terminal Pin 14</p>

Items	Common Specification in IPB-5000B
<b>Starting Time of detecting No Current or No Voltage</b>	Set at <b>NO CURR MONITOR START</b> . 00 to 10ms (Starts to detect No Current or Voltage after the set period)
<b>Pulse Monitoring Start Time</b>	Set at <b>PW MONITOR START</b> . 00 to 10ms (Starts the pulse monitoring after the set period)
<b>NG Output Setting</b>	Set at <b>NG OUTPUT</b> . <b>NORMALLY CLOSE:</b> Closed with Power Supply turned on and open with NG generated <b>NORMALLY OPEN:</b> Closed with NG generated
<b>READY Output Setting</b>	Set at <b>READY OUTPUT</b> . <b>WELD ON:</b> Closed with Weld Current Supply ready <b>POWER ON:</b> Closed with <b>IPB-5000B</b> turned on
<b>Accuracy of Constant Current</b>	+/-3%, Full Scale (Designated Condition / Fixed Load) at the case of setting and monitoring
<b>Accuracy of Constant Voltage</b>	+/-3%, Full Scale (Designated Condition / Fixed Load) at the case of setting and monitoring
<b>Duty Cycle</b>	See the duty cycle graph in the operation manual for the welding transformer in use <b>IT*-360*6</b> or <b>IT*-780*6</b> .
<b>Operation Environment</b>	Temperature: 5 to 40°C Humidity: 90% or less (No condensation) Altitude: 1000 meters or lower  Caution: Use this product in the environment without conductive dust. If conductive dust enters in the product, this may result in a failure, electric shock, or fire. When using this product in this environment, make contact with us.
<b>Storage Environment</b>	Temperature -10°–55°C and dew condensation not allowed
<b>Heat-Resistant Class</b>	E
<b>Case Protection</b>	IP20

	<b>IPB-5000B-00-00/03/07</b>	<b>IPB-5000B-00-01/02/04/05</b>
<b>Weld Power Supply</b>	Three-phase, 200 to 240 V AC ±10% (50 Hz / 60 Hz) (Voltage cannot be selected. Fixed to a customer-specified voltage in factory shipment.)	Three-phase, 380 to 480 V AC ±10% (50 Hz / 60 Hz) (Voltage cannot be selected. Fixed to a customer-specified voltage in factory shipment.)

	<b>IPB-5000B-00-00/01/03/04/07</b>	<b>IPB-5000B-00-02/05</b>
<b>Outline dimensions (mm)</b>	269 (H) x 172 (W) x 470 (D) (No projections included)	349 (H) x 172 (W) x 470 (D) (No projections included)
<b>Mass (kg)</b>	15	19

<b>IPB-5000B-00-03/04/05</b>	
<b>Displacement Measurement Range</b>	30.000mm Max.
<b>Displacement Measurement Accuracy</b>	+/-15 $\mu$ m
<b>Displacement Sensor (Option)</b>	<b>GS-1830A</b> manufactured by Ono Sokki Co. Ltd. <b>GS-1813A</b> manufactured by Ono Sokki Co. Ltd. <b>LGK-110*</b> manufactured by Mitutoyo Corp. (Discontinued) <b>LG200-110*</b> manufactured by Mitutoyo Corp. <b>ST1278*</b> manufactured by HEIDENHAIN * An optional conversion cable is necessary.
<b>Displacement Monitor Setting Range</b>	Upper/Lower Limit Setting Range of Final Displacement: -29.999mm to +29.999mm (0.001mm ea.) Delay Time: 0 to 999ms
<b>Workpiece Detection</b>	At the end of Squeeze, the displacement is checked to confirm whether or not a workpiece is set. Upper/Lower Limit Setting Range of workpiece detection: -29.999mm to +29.999mm (0.001mm ea.)
<b>Weld Stop</b>	When WE1 or WE2 reaches the designated value of Displacement, WE1 moves to CO and WE2, to HO. Displacement Setting Range of Weld Stop: -29.999mm to +29.999mm (0.001mm ea.)
<b>Envelope</b>	Possible to set Upper/Lower Limit Setting to Displacement waveform

**(2) Optional Items (Separately Sold)**

① **Input Cables PK-01855-□□□**

If a customer procures the cable by oneself, prepare it in accordance with the following right-hand specifications.

Type	Branch No.	Length (m)
Standard	-002	2
	-005	5
	-010	10
	-015	15
	-020	20

Specifications of Standard Cable	
Rated Voltage	600V AC min.
Section Area	8 mm <sup>2</sup> min.
No. of Cores	4
Cable Dia.	25 mm max.

Type	Branch No.	Length (m)
CE Marking Compliant	-102	2
	-105	5
	-110	10
	-115	15
	-120	20

Specifications of CE Marking Compliant Cable	
Rated Voltage	500V AC min.
Section Area	10 mm <sup>2</sup> min.
No. of Cores	4
Cable Dia.	25 mm max.
Compliance Standard	Conductor: VDE0812/0281 Insulation: VDE0250/0281

② **Output Cables PK-01856-□□□**

If a customer procures the cable by oneself, prepare it in accordance with the following right-hand specifications.

Type	Branch No.	Length (m)
Standard	-002	2
	-005	5
	-010	10

Specifications of Standard Cable	
Rated Voltage	600V AC min.
Section Area	8 mm <sup>2</sup> min.
No. of Cores	3
Cable Dia.	25 mm max.

Type	Branch No.	Length (m)
CE Marking Compliant	-102	2
	-105	5
	-110	10

Specifications of CE Marking Compliant Cable	
Rated Voltage	750V AC min.
Section Area	10 mm <sup>2</sup> min.
No. of Cores	3
Cable Dia.	25 mm max.
Compliance Standard	Conductor: VDE0812/0281 Insulation: VDE0250/0281

## ③ [SENS] Cables SK-05741

Item	Branch No.	Length (m)
[SENS] Cable SK-05741	-002	2
	-005	5
	-010	10

## ④ Start Cables A-03081

Item	Branch No.	Length (m)
Start Cable A-03081	-001	1
	-002	3

## ⑤ Displacement Sensors

Item	Manufacturer
GS-1830A	ONO SOKKI Co. Ltd.
GS-1813A	
LGK-110	Mitutoyo Corp. (Discontinued)
LG200-110	Mitutoyo Corp.
ST1278	HEIDENHAIN

## ⑥ Displacement Sensor Conversion Cables

Item	Application
A-06037-001	LGK-110 (Mitutoyo)
SK-1213278	LG200-110 (Mitutoyo)
A-06037-002	ST1278 (HEIDENHAIN)

## 12. Error Codes

If the Power Supply has a trouble, the screen displays the error code and message.

Error Code	Message	Cause	Corrective Action
E-01	SYSTEM ERROR	Error has been detected on control system of <b>IPB-5000B</b> .	Once turn off power and turn on again. If <b>E-01 SYSTEM ERROR</b> is displayed again, repair is required. Contact us.
E-02	MEMORY ERROR	Schedule data stored in memory are broken down.	<p>Check all set data. The following is assumed to cause the data stored in memory to be corrupted.</p> <ul style="list-style-type: none"> <li>* Strong power noise or electrostatic noise</li> <li>* Abnormal voltage of power supply due to thunderbolt or lightning conduction</li> <li>* Exceed in writing count limit of flash memory</li> </ul> <p>It is required to write down set values for a later use and also convenient in case of data corruption. (Use attached Schedule Data Table.) When turning power on along with <b>MENU</b> key pressed, the memory is initialized and all data return to values on the factory shipment after displaying the message of "Initializing.....Please wait a moment". Re-set the values on record. It takes approximately 10 seconds to initialize the memory. Do not turn off power for the period.</p> <p>If <b>E-02 MEMORY ERROR</b> is displayed again, repair is required. Contact us.</p>
E-03	OVER HEAT	Temperature rises inside <b>IPB-5000B</b> and thermostat for power element inside power unit is open.	<ul style="list-style-type: none"> <li>*Check whether or not duty cycle exceeds the specific value. Observe the value.</li> <li>*Stop the operation and, after cooling the Equipment, reset the error.</li> </ul>
E-04	OVER HEAT (TRANS)	Temperature of weld transformer rises and thermostat is open inside weld transformer.	<ul style="list-style-type: none"> <li>*Check connection of [SENS] Cable.</li> <li>*Check whether or not duty cycle exceeds the specific value. Observe the value.</li> <li>*Stop the operation and, after cooling the Equipment, reset the error.</li> </ul>
E-05	OVER CURRENT	Actual weld current is greater than set value.	Check whether or not weld transformer and electrodes are normal.
E-06	POWER SUPPLY ERROR	Error has been detected on three-phase weld power supply.	Check input connection of three-phase weld power supply.

Error Code	Contents	Cause	Corrective Action
E-07	ABORT	Short-circuit wire is cut between Pin 1 and Pin 3 <b>STOP</b> on rear panel.	Connect Pin 1 to Pin 3 on rear terminal strip.
E-08	NO CURRENT	Weld current is not flowing. Or measured value of weld current is 3% or less of current range.	*Check the pressing force, electrode contact and wire connection of weld head. *Check the setting of <b>SQZ</b> . Set longer <b>SQZ</b> period than period of electrode moving. *At <b>NO CURR MONITOR START</b> in STATUS Screen, start time of checking "No Current" can be set. It is possible to stop the detection of "No Current" at the start of current flow by that setting.
E-09	NO VOLTAGE	Voltage across electrodes is 0.2V or less. Or voltage detecting cable is not connected.	*Check connection and location of voltage detecting cable. *Check the pressing force, electrode contact and wire connection of weld head. *At <b>NO CURR MONITOR START</b> in STATUS Screen, start time of checking "No Current" can be set. It is possible to stop the detection of "No Current" at the start of current flow by that setting.  This error does not happen when <b>CURR</b> is set at <b>CONTROL</b> setting in STATUS Screen.
E-11	PARITY ERROR	Sum of numbers of closed Schedule Select Signal wires and a Parity Signal wire is not odd.	Select and close Parity Signal so that the sum of the numbers of closed Schedule Select Signal wires and a Parity Signal wire can be odd. This error happens only when <b>EXP. (P)</b> is set at <b>SCHEDULE#</b> setting in STATUS Screen.
E-12	INTERRUPT ERROR	Signals of Pin 20, <b>W. INTERRUPT</b> and Pin 14, <b>PARITY(WE1STOP)</b> at terminal strip on rear panel are closed at weld starting.	Check input of <b>W. INTERRUPT</b> and <b>PARITY(WE1STOP)</b> .
E-13	CYCLE ERROR	Pin 5, <b>2ND STAGE</b> has been open on rear panel while weld sequence operates.	Close Pin 5, <b>2ND STAGE</b> until <b>WE2</b> in weld sequence goes to an end. This error happens only when <b>NO HOLD</b> is set at <b>START SIG. HOLD</b> setting in STATUS Screen.
E-14	COUNT MEMORY ERROR	Count Data stored in memory are damaged.	Memory was erased because period for retaining memory of count data elapsed over specified period. The period for retaining the memory of count data is approximately 10 days since the day when a power supply is turned off at latest.

<b>Error Code</b>	<b>Contents</b>	<b>Cause</b>	<b>Corrective Action</b>
<b>E-15</b>	PRECHECK ERROR	Current is out of range <b>between upper limit and lower limit</b> set PRECHECK Screen when PRECHECK Current Supply is used.	*Check weld pickup (contamination) of electrodes, contact of electrodes and workpieces. *Check range set at PRECHECK Screen.
<b>E-16</b>	CURR ERROR (HIGH)	Measured weld current is out of upper limit set at COMPARATOR Screen.	*Check workpieces, welder and welding power supply voltage. *Check range set at COMPARATOR Screen.
<b>E-17</b>	CURR ERROR (LOW)	Measured weld current is out of lower limit set at COMPARATOR Screen.	*Check workpieces, welder and welding power supply voltage. *Check range set at COMPARATOR Screen.
<b>E-18</b>	VOLT ERROR (HIGH)	Measured voltage across electrodes is out of upper limit set at COMPARATOR Screen.	*Check workpieces, welder and welding power supply voltage. *Check range set at COMPARATOR Screen.
<b>E-19</b>	VOLT ERROR (LOW)	Measured voltage across electrodes is out of lower limit set at COMPARATOR Screen.	*Check workpieces, welder and welding power supply voltage. *Check range set at COMPARATOR Screen.
<b>E-20</b>	RESIST ERROR (HIGH)	Measured resistance across electrodes is out of upper limit set at COMPARATOR Screen.	*Check workpieces, welder and welding power supply voltage. *Check range set at COMPARATOR Screen.
<b>E-21</b>	RESIST ERROR (LOW)	Measured resistance across electrodes is out of lower limit set at COMPARATOR Screen.	*Check workpieces, welder and welding power supply voltage. *Check range set at COMPARATOR Screen.
<b>E-22</b>	POWER ERROR (HIGH)	Measured weld power is out of upper limit set at COMPARATOR Screen.	*Check workpieces, welder and welding power supply voltage. *Check range set at COMPARATOR Screen.
<b>E-23</b>	POWER ERROR (LOW)	Measured weld power is out of lower limit set at COMPARATOR Screen.	*Check workpieces, welder and welding power supply voltage. *Check range set at COMPARATOR Screen.
<b>E-24</b>	COUNT UP	Counting has arrived at set pre-set count value.	Re-set counter.
<b>E-25</b>	OVER CURRENT (24VDC)	Internal 24VDC power supply output at terminal strip on rear panel is overloaded.	Turn off power and check connection at I/O terminal strip on rear panel.

Error Code	Contents	Cause	Corrective Action
E-26	DISPLACEMENT ERROR (HIGH)	Measured displacement is out of upper limit set at CONTROL Screen.	*Check workpieces, welder and welding power supply voltage. *Check range set at CONTROL Screen.
E-27	DISPLACEMENT ERROR (LOW)	Measured displacement is out of lower limit set at CONTROL Screen.	*Check workpieces, welder and welding power supply voltage. *Check range set at CONTROL Screen.
E-28	WELD TIME ERROR (HIGH)	Measured weld time is out of upper limit set at CONTROL Screen.	*Check workpieces, welder and welding power supply voltage. *Check weld stop setting in CONTROL Screen and weld stop input in external interface. *Check range set at CONTROL Screen.
E-29	WELD TIME ERROR (LOW)	Measured weld time is out of lower limit set at CONTROL Screen.	*Check workpieces, welder and welding power supply voltage. *Check weld stop setting in CONTROL Screen and weld stop input in external interface. *Check range set at CONTROL Screen.
E-30	WORK DETECT ERROR	Measured displacement at end of squeeze is out of range between lower and upper limit set at CONTROL Screen.	*Check workpieces setting and positioning. *Check range set at CONTROL Screen.


### CAUTION

If the monitor value is not displayed, the WELD ON/OFF input terminal may be open in the process of sequence (including the screen display time. See **9.(1) Fundamental Sequence**).

# 13. Outline Drawing


## (1) IPB-5000B-00-00/01/03/04/07

(Dimensions in mm)




## (2) IPB-5000B-00-02/05

(Dimensions in mm)




(3) Displacement Sensors


① GS-1830A Type, Ono Sokki




② GS-1813A Type, Ono Sokki




③ LG200-110 Type, Mitutoyo



⊕ LGK-110 Type, Mitutoyo (Discontinued)



© ST1278 Type, HEIDENHAIN



# 14. Schedule Data Table

## (1) Weld SCHEDULE Setting

ITEM SCH #	SQD	SQZ	WE1	COOL	WE2	HOLD	CURR		VOLT		POWER		CONTROL		UP SLOPE		DOWN SLOPE		TRANS #		
							WE1	WE2	WE1	WE2	WE1	WE2	WE1	WE2	WE1	WE2	WE1	WE2			
SCH1																					
SCH2																					
SCH3																					
SCH4																					
SCH5																					
SCH6																					
SCH7																					
SCH8																					
SCH9																					
SCH10																					
SCH11																					
SCH12																					
SCH13																					
SCH14																					
SCH15																					
SCH16																					
SCH17																					
SCH18																					

ITEM SCH #	SQD	SQZ	WE1	COOL	WE2	HOLD	CURR		VOLT		POWER		CONTROL		UP SLOPE		DOWN SLOPE		TRANS #
							WE1	WE2	WE1	WE2	WE1	WE2	WE1	WE2	WE1	WE2	WE1	WE2	
SCH19																			
SCH20																			
SCH21																			
SCH22																			
SCH23																			
SCH24																			
SCH25																			
SCH26																			
SCH27																			
SCH28																			
SCH29																			
SCH30																			
SCH31																			
SCH32																			
SCH33																			
SCH34																			
SCH35																			
SCH36																			

14. Schedule Data Table

ITEM SCH #	SQD	SQZ	WE1	COOL	WE2	HOLD	CURR		VOLT		POWER		CONTROL		UP SLOPE		DOWN SLOPE		TRANS #	
							WE1	WE2	WE1	WE2	WE1	WE2	WE1	WE2	WE1	WE2	WE1	WE2		
SCH37																				
SCH38																				
SCH39																				
SCH40																				
SCH41																				
SCH42																				
SCH43																				
SCH44																				
SCH45																				
SCH46																				
SCH47																				
SCH48																				
SCH49																				
SCH50																				
SCH51																				
SCH52																				
SCH53																				
SCH54																				

14. Schedule Data Table

ITEM SCH #	SQD	SQZ	WE1	COOL	WE2	HOLD	CURR		VOLT		POWER		CONTROL		UP SLOPE		DOWN SLOPE		TRANS #		
							WE1	WE2	WE1	WE2	WE1	WE2	WE1	WE2	WE1	WE2	WE1	WE2		WE1	WE2
SCH55																					
SCH56																					
SCH57																					
SCH58																					
SCH59																					
SCH60																					
SCH61																					
SCH62																					
SCH63																					
SCH64																					
SCH65																					
SCH66																					
SCH67																					
SCH68																					
SCH69																					
SCH70																					
SCH71																					
SCH72																					

14. Schedule Data Table

ITEM SCH #	SQD	SQZ	WE1	COOL	WE2	HOLD	CURR		VOLT		POWER		CONTROL		UP SLOPE		DOWN SLOPE		TRANS #		
							WE1	WE2	WE1	WE2	WE1	WE2	WE1	WE2	WE1	WE2	WE1	WE2		WE1	WE2
SCH73																					
SCH74																					
SCH75																					
SCH76																					
SCH77																					
SCH78																					
SCH79																					
SCH80																					
SCH81																					
SCH82																					
SCH83																					
SCH84																					
SCH85																					
SCH86																					
SCH87																					
SCH88																					
SCH89																					
SCH90																					

14. Schedule Data Table

ITEM SCH #	SQD	SQZ	WE1	COOL	WE2	HOLD	CURR		VOLT		POWER		CONTROL		UP SLOPE		DOWN SLOPE		TRANS #	
							WE1	WE2	WE1	WE2	WE1	WE2	WE1	WE2	WE1	WE2	WE1	WE2		
SCH91																				
SCH92																				
SCH93																				
SCH94																				
SCH95																				
SCH96																				
SCH97																				
SCH98																				
SCH99																				
SCH100																				
SCH101																				
SCH102																				
SCH103																				
SCH104																				
SCH105																				
SCH106																				
SCH107																				
SCH108																				

14. Schedule Data Table

ITEM SCH #	SQD	SQZ	WE1	COOL	WE2	HOLD	CURR		VOLT		POWER		CONTROL		UP SLOPE		DOWN SLOPE		TRANS #		
							WE1	WE2	WE1	WE2	WE1	WE2	WE1	WE2	WE1	WE2	WE1	WE2		WE1	WE2
SCH109																					
SCH110																					
SCH111																					
SCH112																					
SCH113																					
SCH114																					
SCH115																					
SCH116																					
SCH117																					
SCH118																					
SCH119																					
SCH120																					
SCH121																					
SCH122																					
SCH123																					
SCH124																					
SCH125																					
SCH126																					
SCH127																					

14. Schedule Data Table

**(2) PRECHECK Setting**

ITEM SCH#	TIME	VOLT	COMP CURR	
			HI	LO
SCH1				
SCH2				
SCH3				
SCH4				
SCH5				
SCH6				
SCH7				
SCH8				
SCH9				
SCH10				
SCH11				
SCH12				
SCH13				
SCH14				
SCH15				
SCH16				
SCH17				
SCH18				
SCH19				
SCH20				
SCH21				
SCH22				
SCH23				
SCH24				
SCH25				
SCH26				
SCH27				

ITEM SCH#	TIME	VOLT	COMP CURR	
			HI	LO
SCH28				
SCH29				
SCH30				
SCH31				
SCH32				
SCH33				
SCH34				
SCH35				
SCH36				
SCH37				
SCH38				
SCH39				
SCH40				
SCH41				
SCH42				
SCH43				
SCH44				
SCH45				
SCH46				
SCH47				
SCH48				
SCH49				
SCH50				
SCH51				
SCH52				
SCH53				
SCH54				

ITEM SCH#	TIME	VOLT	COMP CURR	
			HI	LO
SCH55				
SCH56				
SCH57				
SCH58				
SCH59				
SCH60				
SCH61				
SCH62				
SCH63				
SCH64				
SCH65				
SCH66				
SCH67				
SCH68				
SCH69				
SCH70				
SCH71				
SCH72				
SCH73				
SCH74				
SCH75				
SCH76				
SCH77				
SCH78				
SCH79				
SCH80				
SCH81				
SCH82				
SCH83				

ITEM SCH#	TIME	VOLT	COMP CURR	
			HI	LO
SCH84				
SCH85				
SCH86				
SCH87				
SCH88				
SCH89				
SCH90				
SCH91				
SCH92				
SCH93				
SCH94				
SCH95				
SCH96				
SCH97				
SCH98				
SCH99				
SCH100				
SCH101				
SCH102				
SCH103				
SCH104				
SCH105				
SCH106				
SCH107				
SCH108				
SCH109				
SCH110				
SCH111				
SCH112				

ITEM SCH#	TIME	VOLT	COMP CURR	
			HI	LO
SCH113				
SCH114				
SCH115				
SCH116				
SCH117				
SCH118				
SCH119				
SCH120				

ITEM SCH#	TIME	VOLT	COMP CURR	
			HI	LO
SCH121				
SCH122				
SCH123				
SCH124				
SCH125				
SCH126				
SCH127				

**(3) COMPARATOR Setting**

ITEM	CURR						VOLT						POWER						RESIST					
	WE1			WE2			WE1			WE2			WE1			WE2			WE1			WE2		
	HI	LO		HI	LO		HI	LO		HI	LO		HI	LO		HI	LO		HI	LO		HI	LO	
SCH #			RMS/ PEAK			RMS/ PEAK			HI			LO			HI			LO			HI			LO
SCH1																								
SCH2																								
SCH3																								
SCH4																								
SCH5																								
SCH6																								
SCH7																								
SCH8																								
SCH9																								
SCH10																								
SCH11																								
SCH12																								
SCH13																								
SCH14																								
SCH15																								
SCH16																								
SCH17																								
SCH18																								

ITEM SCH #	CURR						VOLT						POWER						RESIST					
	WE1			WE2			WE1			WE2			WE1			WE2			WE1			WE2		
	HI	LO		HI	LO		HI	LO		HI	LO		HI	LO		HI	LO		HI	LO		HI	LO	
SCH19																								
SCH20																								
SCH21																								
SCH22																								
SCH23																								
SCH24																								
SCH25																								
SCH26																								
SCH27																								
SCH28																								
SCH29																								
SCH30																								
SCH31																								
SCH32																								
SCH33																								
SCH34																								
SCH35																								
SCH36																								

ITEM SCH #	CURR						VOLT						POWER						RESIST						
	WE1			WE2			WE1			WE2			WE1			WE2			WE1			WE2			
	HI	LO		HI	LO		HI	LO		HI	LO		HI	LO		HI	LO		HI	LO		HI	LO		
SCH37																									
SCH38																									
SCH39																									
SCH40																									
SCH41																									
SCH42																									
SCH43																									
SCH44																									
SCH45																									
SCH46																									
SCH47																									
SCH48																									
SCH49																									
SCH50																									
SCH51																									
SCH52																									
SCH53																									
SCH54																									

ITEM SCH #	CURR						VOLT						POWER						RESIST					
	WE1			WE2			WE1			WE2			WE1			WE2			WE1			WE2		
	HI	LO		HI	LO		HI	LO		HI	LO		HI	LO		HI	LO		HI	LO		HI	LO	
SCH55																								
SCH56																								
SCH57																								
SCH58																								
SCH59																								
SCH60																								
SCH61																								
SCH62																								
SCH63																								
SCH64																								
SCH65																								
SCH66																								
SCH67																								
SCH68																								
SCH69																								
SCH70																								
SCH71																								
SCH72																								

ITEM SCH #	CURR						VOLT						POWER						RESIST						
	WE1			WE2			WE1			WE2			WE1			WE2			WE1			WE2			
	HI	LO		HI	LO		HI	LO		HI	LO		HI	LO		HI	LO		HI	LO		HI	LO		
SCH73																									
SCH74																									
SCH75																									
SCH76																									
SCH77																									
SCH78																									
SCH79																									
SCH80																									
SCH81																									
SCH82																									
SCH83																									
SCH84																									
SCH85																									
SCH86																									
SCH87																									
SCH88																									
SCH89																									
SCH90																									

ITEM SCH #	CURR						VOLT						POWER						RESIST						
	WE1			WE2			WE1			WE2			WE1			WE2			WE1			WE2			
	HI	LO		HI	LO		HI	LO		HI	LO		HI	LO		HI	LO		HI	LO		HI	LO		
	RMS/ PEAK						RMS/ PEAK						RMS/ PEAK						RMS/ PEAK						
SCH91																									
SCH92																									
SCH93																									
SCH94																									
SCH95																									
SCH96																									
SCH97																									
SCH98																									
SCH99																									
SCH100																									
SCH101																									
SCH102																									
SCH103																									
SCH104																									
SCH105																									
SCH106																									
SCH107																									
SCH108																									

ITEM	CURR						VOLT						POWER						RESIST					
	WE1			WE2			WE1			WE2			WE1			WE2			WE1			WE2		
	HI	LO		HI	LO		HI	LO		HI	LO		HI	LO		HI	LO		HI	LO		HI	LO	
SCH #																								
SCH109																								
SCH110																								
SCH111																								
SCH112																								
SCH113																								
SCH114																								
SCH115																								
SCH116																								
SCH117																								
SCH118																								
SCH119																								
SCH120																								
SCH121																								
SCH122																								
SCH123																								
SCH124																								
SCH125																								
SCH126																								
SCH127																								

14. Schedule Data Table

**(4) CONTROL Setting**

\*\* Only for model with displacement sensor (Option)

ITEM	WELD STOP						WELD TIME						DISPLACEMENT **								
	INPUT			CONDITION			WE1			WE2			COMP			DELAY TIME			WORK DETECT		
	WE1	WE2	WE1	WE1	WE2	WE2	HI	LO	HI	LO	HI	LO	HI	LO	HI	LO	HI	LO	HI	LO	
SCH #																					
SCH1																					
SCH2																					
SCH3																					
SCH4																					
SCH5																					
SCH6																					
SCH7																					
SCH8																					
SCH9																					
SCH10																					
SCH11																					
SCH12																					
SCH13																					
SCH14																					
SCH15																					
SCH16																					
SCH17																					
SCH18																					

\*\* Only for model with displacement sensor (Option)

ITEM	WELD STOP						WELD TIME						DISPLACEMENT **							
	INPUT			CONDITION			WE1		WE2		LO		HI		COMP		DELAY TIME		WORK DETECT	
	WE1	WE2	WE1	WE2	WE1	WE2	HI	LO	HI	LO	HI	LO	HI	LO	HI	LO	HI	LO		
SCH19																				
SCH20																				
SCH21																				
SCH22																				
SCH23																				
SCH24																				
SCH25																				
SCH26																				
SCH27																				
SCH28																				
SCH29																				
SCH30																				
SCH31																				
SCH32																				
SCH33																				
SCH34																				
SCH35																				
SCH36																				

\*\* Only for model with displacement sensor (Option)

ITEM	WELD STOP						WELD TIME						DISPLACEMENT **							
	INPUT			CONDITION			WE1		WE2		LO		HI		COMP		DELAY TIME		WORK DETECT	
	WE1	WE2	WE1	WE2	WE1	WE2	HI	LO	HI	LO	HI	LO	HI	LO	HI	LO	HI	LO		
SCH #																				
SCH37																				
SCH38																				
SCH39																				
SCH40																				
SCH41																				
SCH42																				
SCH43																				
SCH44																				
SCH45																				
SCH46																				
SCH47																				
SCH48																				
SCH49																				
SCH50																				
SCH51																				
SCH52																				
SCH53																				
SCH54																				

\*\* Only for model with displacement sensor (Option)

ITEM	WELD STOP						WELD TIME						DISPLACEMENT **									
	INPUT			CONDITION			WE1		WE2		LO		HI		COMP		DELAY TIME		WORK DETECT			
	WE1	WE2	WE1	WE1	WE2	WE2	HI	LO	HI	LO	HI	LO	HI	LO	HI	LO	HI	LO	HI	LO		
SCH55																						
SCH56																						
SCH57																						
SCH58																						
SCH59																						
SCH60																						
SCH61																						
SCH62																						
SCH63																						
SCH64																						
SCH65																						
SCH66																						
SCH67																						
SCH68																						
SCH69																						
SCH70																						
SCH71																						
SCH72																						

\*\* Only for model with displacement sensor (Option)

ITEM	WELD STOP						WELD TIME						DISPLACEMENT **							
	INPUT			CONDITION			WE1		WE2		LO		HI		COMP		DELAY TIME		WORK DETECT	
	WE1	WE2	WE1	WE2	WE1	WE2	HI	LO	HI	LO	HI	LO	HI	LO	HI	LO	HI	LO		
SCH #																				
SCH73																				
SCH74																				
SCH75																				
SCH76																				
SCH77																				
SCH78																				
SCH79																				
SCH80																				
SCH81																				
SCH82																				
SCH83																				
SCH84																				
SCH85																				
SCH86																				
SCH87																				
SCH88																				
SCH89																				
SCH90																				

\*\* Only for model with displacement sensor (Option)

ITEM	WELD STOP						WELD TIME						DISPLACEMENT **								
	INPUT			CONDITION			WE1		WE2		LO		HI		COMP		DELAY TIME		WORK DETECT		
	WE1	WE2	WE1	WE2	WE1	WE2	HI	LO	HI	LO	HI	LO	HI	LO	HI	LO	HI	LO	HI	LO	
SCH #																					
SCH91																					
SCH92																					
SCH93																					
SCH94																					
SCH95																					
SCH96																					
SCH97																					
SCH98																					
SCH99																					
SCH100																					
SCH101																					
SCH102																					
SCH103																					
SCH104																					
SCH105																					
SCH106																					
SCH107																					
SCH108																					

\*\* Only for model with displacement sensor (Option)

ITEM	WELD STOP			WELD TIME			DISPLACEMENT **							
	INPUT		CONDITION		WE1		WE2		COMP		DELAY TIME		WORK DETECT	
SCH #	WE1	WE2	WE1	WE2	HI	LO	HI	LO	HI	LO	HI	LO	HI	LO
SCH109														
SCH110														
SCH111														
SCH112														
SCH113														
SCH114														
SCH115														
SCH116														
SCH117														
SCH118														
SCH119														
SCH120														
SCH121														
SCH122														
SCH123														
SCH124														
SCH125														
SCH126														
SCH127														

**(5) STATUS Setting****STATUS**

WELD TRANS	
WELD TIME	
START SIG.TIME	
START SIG.HOLD	
SCHEDULE#	
END SIG.TIME	
MONITOR MODE	
CALCULATION MODE	
TRANS SCAN MODE	
COMM CONTROL	
COMM MODE	
COMM UNIT#	
COMM SPEED	
NO CURR MONITOR START	
PW MONITOR START	
NG OUTPUT	
READY OUTPUT	

**ERROR SETTING**

E08 :NO CURRENT	
E09 :NO VOLTAGE	
E16/E17:OUT LIMIT OF CURR	
E18/E19:OUT LIMIT OF VOLT	
E20/E21:OUT LIMIT OF POWER	
E22/E23:OUT LIMIT OF RESIST	
E26/E27:OUT LIMIT OF DISPLC	
E28/E29:OUT LIMIT OF TIME	
E15/E30:WORK CHECK ERROR	

**MISC**

TRANS USER1	
DISPLACEMENT SENSOR STEP COUNTER	
PRESET (TOTAL/GOOD)	
PRESET (WORK)	
PRESET (WELD)	