

Laser Scanning System for Welding

GWM-STD/SHG/STD2-000

OPERATION MANUAL

- Scanner Head -



About This Documentation

Thank you for purchasing our GWM-STD/SHG/STD2-000 Laser Scanning System for Welding.

Please read this manual carefully to ensure correct use of the product. Keep the manual handy after reading for future reference.

1. Organization

This document for the GWM-STD/SHG/STD2-000 Laser Scanning System for Welding describes installation, maintenance and system specifications. For instructions for welding control using the SWDraw2 application, refer to the manual for SWDraw2.

The documentation comprises the following sections:

- **Scanner Controller**
Describes the part names, installation, maintenance, and specifications of the scanner controller.
- **Scanner Head**
Describes the part names, installation, maintenance, and specifications of the scanner head.
- **Warranty**
- **Address List**

2. Note

- Microsoft and Windows are either registered trademarks or trademarks of Microsoft Corporation in the United States and other countries.
- Company and product names in this manual are trademarks or registered trademarks of their respective owners.
- Unauthorized reproduction of this manual in whole or part is prohibited.
- The contents of this manual are subject to change without notice.
- Every effort has been made to ensure the accuracy of this information. If you come across oversights or errors, please notify your dealer.
- Be sure to read the user's manuals for any equipment used in conjunction with the system (e.g., documentation for computer systems).

3. Symbols Used in this Manual

 CAUTION	Indicates instructions that must be followed to prevent hardware or software damage or operating errors.
 ATTENTION	Indicates additional information on a particular topic.

Menus, icons, buttons, windows, tabs	Enclosed in brackets. Example: Click the [OK] button.
Keyboard keys	Enclosed in angle brackets. Example: Press the <Tab> key.
References	Enclosed in quotes. Example: Refer to "Chapter 8-3.2 Changing Passwords" (page 5).

Contents

About This Documentation	1
1 Organization	1
2 Note	1
3 Symbols Used in this Manual	2
Chapter 1 Special Precautions	4
1 Safety Precautions	4
2 Operating Precautions	7
3 For Disposal	8
Chapter 2 Features	9
Chapter 3 System Configuration	10
1 Overall Configuration	10
2 Name and Functions of Each Section	11
Chapter 4 Installation	13
1 Unpacking	13
2 Installation	14
3 Connections	15
Chapter 5 Specifications	16
1 Basic Specifications	16
2 Lens Unit Lineup	17
3 Machining Parameters	19
4 Parameter Setting Ranges for Various Lenses	21
Chapter 6 Outline Drawing	24
1 Scanner Alone	24
2 Scanner Head Unit	25
Chapter 7 Inspection and Parts Replacement	35
1 Before Inspection and Parts Replacement	35
2 Parts Replacement	35
3 Protective Glass Inspection and Replacement	36

Chapter 1

Special Precautions

1. Safety Precautions

Read these Safety Precautions thoroughly before use to ensure correct use of the system.

- The precaution points indicated here are intended to ensure safe operation of the system and prevent hazards or injury to users and other personnel.
They are important details relating to safety and must be read carefully.
- The indications have the following meanings.

 DANGER	Indicates that incorrect operation risks death or serious injury to personnel.
 WARNING	Indicates that incorrect operation may result in death or serious injury to personnel.
 CAUTION	Indicates that incorrect operation may result in injury to personnel or damage to property.

Indicates prohibited actions and warns of actions not covered by the product warranty.	
	
Indicates actions that must be performed by users.	
	
The triangular symbol indicates details that supplement DANGER, WARNING, or CAUTION points.	
	

DANGER



Never dismantle, repair, or modify the system. Doing so may result in electric shock or fire.

Otherwise there is a risk of electric shock or fire. Do not attempt maintenance other than that described in the Operation Manual.



Do not look into or touch the beam.

Direct and scattered laser light is dangerous. Looking directly at the laser source risks blindness.



Never burn, destroy, cut, crush or chemically decompose the system.

This product incorporates parts containing gallium arsenide (GaAs).

WARNING



Wear protective goggles.

Protective goggles must always be worn when using the system.

Care must be taken even when wearing protective goggles, as looking directly at the laser source through protective goggles risks blindness. Protective goggles attenuate the laser beam, but does not block it.



Never subject parts of the body to laser radiation.

Otherwise there is a risk of burn injuries.



Do not damage power or connector cables.

Do not crush, twist, or pull cables. Damaged cables may result in electric shock, short-circuiting, or fire.

Contact your dealer or us if repair or replacement is necessary.



Connect securely using the specified cables.

Using cables with inadequate capacity or improper connections may result in fire or electric shock.



Connect optical fibers securely.

Improper connection may result in burn injuries or fire.



Stop using the system if a problem arises.

If a problem occurs such as a burning smell, abnormal noise, overheating, or smoke emission, continuing to use the system may result in electric shock or fire.

Contact your dealer or us immediately.



Use a stopper.

Laser radiation is hazardous to personnel. When operating the laser during maintenance work, use a stopper (light-absorbing/scattering body capable of withstanding high temperatures) to prevent laser emission beyond the stopper.



WARNING



Wear protective work clothing.

Wear protective clothing such as gloves, long-sleeved clothing, and a leather apron. Spatter will cause burn injuries if it lands on the skin.



CAUTION



Keep away from water.

Subjecting electrical components to water may result in electric shock or short-circuiting.



Install in a firm location.

Otherwise there is a risk of injury if the system topples or falls from the installation location.



Keep away from flammable materials.

Otherwise there is a risk of fire if spatter created during laser emission lands on flammable materials. If flammable materials cannot be removed from the vicinity, they must be covered with a non-flammable cover.



Provide fire extinguishers.

Fire extinguishers must be provided in the welding work area in case of fire.



Inspect and maintain the system periodically.

Inspect and maintain the system periodically, repairing damaged parts and components before use.



Do not point the laser beam at flammable materials.

Do not point the laser beam at flammable or combustible materials. Otherwise there is a risk of fire.



Keep connector plugs clean and insert fully.

There is a risk of overheating and fire if dust is allowed to accumulate or if plugs are not fully inserted.



Hold the plug body when inserting or removing.

There is a risk of damage to the cable and electric shock or fire if the cable is pulled to unplug.



Do not cover with blankets or sheets.

Do not cover the system with blankets or sheets while in use. Otherwise there is a risk of over-heating and fire.

2. Operating Precautions

- (1) When scanning highly reflective materials (such as gold, silver, copper, or aluminum), be sure to contact us.

Depending on use conditions, the inside of the scanner head may be burnt.

- (2) A person knowledgeable about laser radiation and laser systems should be appointed as a laser safety manager.

The laser safety manager should be responsible for managing the system key switches, providing safety instruction to laser operators, and supervising operations.

- (3) Areas in which lasers are used must be partitioned from other areas by enclosing with fences.

These areas should be managed by a supervisor and marked with signs to prevent entry by unauthorized personnel.

- (4) The system should be used in an ambient temperature range of 5°C to 35°C and humidity 80% RH or lower with no sudden temperature fluctuations. Avoid using the system in the following locations.

- Locations with dust or oil mist present
- Locations subject to vibration or impact
- Locations in which chemicals are used
- Locations subject to high noise
- Locations susceptible to condensation
- Locations with high concentrations of CO₂, NO_x, or SO_x (The ion-exchange resin life may be reduced by exposure to CO₂ concentrations of 0.1% or more.)

- (5) There is a risk of condensation forming on the lens surface and debris adhering if the ambient temperature changes suddenly such as when turning on the heating in cold conditions. Avoid sudden temperature fluctuations. There is a likelihood that condensation has formed if the output decreases during initial operation. Stop using the system immediately, and check the lens surface if there is a likelihood of condensation.

- (6) The exterior of the system should be wiped clean using a soft or moist cloth. If the exterior is particularly dirty, wipe clean using diluted detergent or alcohol.

- (7) Do not drop foreign objects such as screws inside the system, as this may result in failure of the system.

- (8) Operate the system as described in the attached Operation Manual.

- (9) Do not turn off the power switch of the scanner controller while a computer is connected to the scanner controller.

- (10) If a computer is connected, it will continue to access the memory card for about 15 seconds after going offline. During this time, do not turn off the power switch of the scanner controller.

- (11) If a computer is connected, never disconnect the USB cable before turning off the power switch of the scanner controller.

- (12) For more consistent scanning allow the unit to warm up for about 10 to 30 minutes after turning it on. The warmup time varies depending on the temperature and workpiece material.
- (13) Use only memory cards purchased from us. If commercial cards are used, the unit may not function normally.
- (14) Before inserting or removing memory cards, always turn off the power switch of the scanner controller. If the power switch of the scanner controller is on when cards are inserted or removed, data may be lost or the memory card may become unusable.
- (15) Back up memory card data regularly. If the memory card data becomes corrupted, it may prevent normal scanned or the equipment may not start.
- (16) The number of times memory cards are inserted or removed depends on the manufacturer's nominal number of times (10000 times).
- (17) When a supervisor or operator enters the area where the laser is used, protective measures not to exceed the MPE* level must be taken.

* MPE: The maximum level of permissible exposure of the eyes or skin to laser beams. Abbreviation of Maximum Permissible Exposure.

* For other information on managing laser equipment or the MPE level, refer to the following standards.

IEC Standards IEC60825-1 "Safety of laser products Part1: Equipment Classifications, requirements and use's guide"

[Warning/Caution label details]



GWM-STD/STD2-000



GWM-SHG

3. For Disposal

This product incorporates parts containing gallium arsenide (GaAs). At the time of disposal, separate it from general industrial waste or domestic waste and carry out the disposal in accordance with applicable laws and regulations.

Chapter 2

Features


This product is a high-precision laser scanning system for welding which is used in the emitter for laser light sent via optical fiber from the laser welder and combined with a scanner controller.

Also, the digital scanner improves scanner performance such as reduction of temperature drift, precision of repetition position, and scanning speed.

Chapter 3


System Configuration

1. Overall Configuration




2. Name and Functions of Each Section

2.1. Rear



- (1) Head I/F connector
For connection to the HEAD1 to 3 I/F connector of the scanner controller using the head control external cable.
- (2) Scanner connector
For connection to the SCANNER1 to 3 connector of the scanner controller using the scanner cable.
- (3) Collimator lens unit connecting port
For connection to the collimator lens unit.
- (4) f θ lens connecting port
For connection to f θ lens.


2.2. Top



- (1) LED (Yellow)
Lights up when the LD or HV of the laser welder is ON.

(2) LED (Green)

Lights up when the shutter of the laser welder is open.



Chapter 4

Installation

1. Unpacking

1.1. Lifting and Transporting Container

  CAUTION	When moving the container, use a cart or ensure at least two people carry it.
---	---

	Dimension	Mass (including contents)
Container for scanner head and accessories	Approx. 420 (H) x 350 (W) x 370 (D) mm	See "Chapter 6-2. Scanner Head Unit" (page 25) .

1.2. Checking the Contents of Container

Verify that contents of the container agree with the following list.


The components marked with * are built in the unit.

Component	Quantity
Scanner head	1
f θ lens *	1
Collimator lens unit *	1

2. Installation

2.1. Installation Requirements

Refer to the following figure when installing the scanner head. Install the scanner head in a well-ventilated location. Because scanning may produce dust and particulates, we recommend installing a dust collector.



Required Clearance and Mass Support

A. Clearance on top	At least 300 mm
B. Clearance on right side	At least 300 mm
C. Clearance on left side	At least 300 mm
D. Clearance in front	At least 300 mm
E. Clearance in back	At least 300 mm
F. Mass	See "Chapter 6-2. Scanner Head Unit" (page 25) .
G. Work distance	See "Chapter 5-3. Machining Parameters" (page 19) .

 CAUTION		The optical fiber has its minimum bending radius. Refer to the operation manual for the laser welder connected to install the scanner head so as not to bend the optical fiber beyond its minimum bending radius.
--	---	---

 CAUTION		When moving the scanner head, support the head on right and left to avoid touching the lens. Do not hold the fiber or other cables.
--	---	---

Keep the following points in mind when installing the scanner head.

- (1) The work distance is the distance from the outermost surface of the lens' protective glass to the focal position. Depending on differences in scanning conditions and from device to device, the work distance may result in slight variations. Make sure the scanner head is installed to permit adjustment in the range of ± 10 mm relative to these values.

- (2) Install the scanner head so that you can adjust and maintain level after installation.

- (3) For the scanner head mounting platform, use a sheet of metal at least 10 mm thick.

- (4) Protect the mounting platform from vibrations.

Vibrations of 0.1 G or less during operations are generally acceptable, but even lesser vibrations under certain conditions may affect or distort scanning or lead to damage.

- (5) Keep the mounting platform separate from conveyor lines or other equipment to prevent vibration and impact.

- (6) When using two opposing scanner heads, install them so that the laser of neither head is aimed at the other head.

A laser directed at parts within the other scanner head may burn the unit interior.

- (7) When scanning highly reflective materials (such as gold, silver, copper, aluminum, steel, or stainless steel), make sure the focal distance is correct.

Putting workpieces in a position other than the lens focal position may cause the laser to reflect from the workpiece, burning the inside of the scanner head.

- (8) Install the scanner head so that the laser is not aimed at the ceiling.

This precaution is intended to protect users from looking directly into laser output unit and to facilitate maintenance.

3. Connections

- (1) Avoid bundling connecting cables or remote control cables with other power cables.

The resulting electromagnetic noise may cause malfunctions.

- (2) When connecting optical fibers, take care to avoid soiling or damaging the ends of the fiber.

Retain the caps originally attached to the scanner head and optical fiber in a safe location for future use. You will need them again if the optical fiber is removed.

- (3) The software driver must be installed before connecting a computer to the scanner controller. Refer to the manual for SWDraw2 for instructions on installing the driver.

- (4) In case of an optional CCD camera attached, a dedicated power supply, cables and a cross-line generator are coming with it.

1. Basic Specifications

Item		Specifications
Corresponding wavelength		GWM-STD/STD2-000: 1060 to 1100 nm, 650 nm (Guide beam) GWM-SHG: 532 nm, 1064 nm, 650 nm (Guide beam)
Maximum allowable laser power		1000 W
Ambient temperature		5°C to 35°C (with no condensation or freeze) Note: Contact us when using in ambient temperature below 5°C.
Ambient humidity		80% RH or lower (with no condensation or freeze)
Temperature during storage		-10°C to 55°C (with no condensation or freeze)
Humidity during storage		80% RH or lower (with no condensation or freeze)
Vibration during transport (with packaged)		1.0 G or less (horizontal), 2.0 G or less (vertical)
Impact during transport (with packaged)		10.0 G or less (horizontal), 20.0 G or less (vertical)
Dust, Oil mist		IP50
Electromagnetic compatibility standards	Immunity	Complied with the following: IEC61000-4-2 (Electro-static immunity: Contact discharge±6kV, Aerial discharge±8kV) IEC61000-4-3 (Radiated field: 10V/m 80-1000MHz) IEC61000-4-4 (Fast transient burst noise: Power supply±2kV, Transmission line±1kV) IEC61000-4-5 (Lightning surge: Power supply (L1-L2) ±1kV, Power supply (L1-E,L2-E) ±2kV) IEC61000-4-6 (Conducted immunity: 10V/m 0.15-80MHz) IEC61000-4-8 (Magnetic field immunity: 36A/m) IEC61000-4-11 (Dips/Interrupts)
	Emission	Complied with the following: EN55011:2007+A2:2007 (Radiated disturbance) EN55011:2007+A2:2007 (Conducted disturbance)
Maximum scanning speed		28.76 rad/s
Scanner setting time		2 ms max.
Power supply voltage		24 V±1.2 V
Power consumption		Average: Approx. 7 W (per head), Peak: Approx. 40 W (per head)
External dimensions*		230(W) mm × 250(D) mm × 200(H) mm
Mass*		Approx. 6.5 kg

* Output unit, collimator lens and fθ lens are not included.

2. Lens Unit Lineup

2.1. GWM-STD/STD2-000 (for YAG Laser Welder)

Corresponding model	Collimator lens		f θ lens		Machining area (mm)
	Item No.	f	Item No.	f (mm)	
ML-2050A/2051A	1160914	f100	1193162 1203914	f80	ϕ 35
			1155528	f150	ϕ 60
			1155529	f165	ϕ 100
ML-2050A/2051A ML-2150A ML-2350A/2351A ML-2350AF/2351AF ML-2450A	1160913	f80	1193162 1203914	f80	ϕ 35
			1155528	f150	ϕ 60
			1155529	f165	ϕ 100
ML-2050A/2051A ML-2150A ML-2350A/2351A ML-2350AF/2351AF ML-2450A ML-2350A*/2351A* ML-2450A*/2451A ML-2550A/2551A/2552A/ 2553C ML-2650B/2651B * w/ expander	1160912	f50	1193162 1203914	f80	ϕ 35
			1155528	f150	ϕ 60
			1155529	f165	ϕ 100

2.2. GWM-STD/STD2-000 (for Fiber Laser Welder)

Corresponding model	Fiber connector	Collimator lens		f θ lens		Machining area (mm)
		Item No.	f	Item No.	f (mm)	
ML-6040A	D80LKA	1160907	f50	1186257	f82	\square 20
		1160908	f80	1187278	f163	\square 94
ML-6700B	D209HPN	1159528	f50	1186257	f82	\square 20
		1159527	f80	1187278	f163	\square 94
ML-6810B	QBH *	1172048	f50	1186257	f82	\square 20
		1172049	f80	1187278	f163	\square 94

* When using the QBH fiber connector, the fiber cooling chiller unit (item No.: 1173173) is required separately.

2.3. GWM-SHG

Corresponding model	Collimator lens		f θ lens		Machining area (mm)
	Item No.	f	Item No.	f (mm)	
ML-8150A	1160732	f80	1155531	f80	□35

3. Machining Parameters

3.1. GWM-STD/STD2-000 (for YAG Laser Welder)

Image ratio	Machining area	Work distance	Positioning resolution	Repeated positioning accuracy *	Machining position drift
1.6	φ35 mm ±0.5%	AS1193162: Approx. 80 mm AS1203914: Approx. 79 mm	1 μm	6 μm max.	2 μm/°C max.
1					
0.8					
3	φ60 mm ±0.5%	Approx. 174 mm	3 μm	10 μm max.	4 μm/°C max.
1.9					
1.5					
3.3	φ100 mm ±0.5%	Approx. 188 mm	4 μm	15 μm max.	6 μm/°C max.
2.1					
1.65					

* When the operating temperature variation range is 1°C or lower and thirty minutes have passed from warm-up.

3.2. GWM-STD/STD2-000 (for Fiber Laser Welder)

Image ratio	Machining area	Work distance	Positioning resolution	Repeated positioning accuracy *	Machining position drift
1.03	□20 mm ±0.5%	Approx. 84.6 mm	2 μm	8 μm max.	2 μm/°C max.
1.64					
3.26	□94 mm ±0.5%	Approx. 206 mm	4 μm	15 μm max.	6 μm/°C max.
2.04					

* When the operating temperature variation range is 1°C or lower and thirty minutes have passed from warm-up.

3.3. GWM-SHG

Image ratio	Machining area	Work distance	Positioning resolution	Repeated positioning accuracy *	Machining position drift
1	□35 mm ±0.5%	Approx. 74 mm	1 μm	6 μm max.	2 μm/°C max.

* When the operating temperature range is 1°C or lower and thirty minutes have passed from warm-up.

- Machining speed (Varies depending on operating conditions)

Time T required for machining one point is calculated approximately using the equation below, but actual machining times may differ.

$$T \text{ (ms)} = (\text{movement time}) + (\text{standing time after jump}) + 1 \text{ ms} \\ + (\text{laser output time}) + 1 \text{ ms}$$

$$\left(\begin{array}{l} \text{Where movement time (ms) = Movement distance (mm) / Jump speed (mm/s)} \\ \text{standing time after jump (ms) = 2 (default)} \\ \text{Laser output time (ms) = 1, 2, 3, ...} \end{array} \right)$$

- Usage conditions example 1

Laser output	Pulse width 2 ms
Distance between each point	1 mm max.
Machining area	35 mm dia.
Jump speed	2300 mm/s
Machining time per point	6 ms
Machining speed	Approx. 166 points per second

- Usage time example 2

Laser output	Pulse width 5 ms
Distance between each point	10 mm max.
Machining area	100 mm dia.
Jump speed	4700 mm/s
Machining time per point	9.002 ms
Machining speed	Approx. 111 points per second

However, must not exceed the maximum ratings of the laser welder used.

4. Parameter Setting Ranges for Various Lenses

4.1. GWM-STD/STD2-000 (for YAG Laser Welder)

Lens type		f80	f150	f165
Machining area	(mm)	Φ35	Φ60	Φ100
Starting X-Coord / X-Coordinate	Minimum (mm)	-17.5	-30	-50
	Maximum (mm)	17.5	30	50
Starting Y-Coord / Y-Coordinate	Minimum (mm)	-17.5	-30	-50
	Maximum (mm)	17.5	30	50
Ending X-Coord	Minimum (mm)	-17.5	-30	-50
	Maximum (mm)	17.5	30	50
Ending Y-Coord	Minimum (mm)	-17.5	-30	-50
	Maximum (mm)	17.5	30	50
Central X-Coord	Minimum (mm)	-17.5	-30	-50
	Maximum (mm)	17.5	30	50
Central Y-Coord	Minimum (mm)	-17.5	-30	-50
	Maximum (mm)	17.5	30	50
X-Coor Const Pt	Minimum (mm)	-17.5	-30	-50
	Maximum (mm)	17.5	30	50
Y-Coor Const Pt	Minimum (mm)	-17.5	-30	-50
	Maximum (mm)	17.5	30	50
Radius	Minimum (mm)	-17.5	-30	-50
	Maximum (mm)	17.5	30	50
X Offset / Y Offset	Minimum (mm)	-17.5	-30	-50
	Maximum (mm)	17.5	30	50
Scanning Speed	Minimum (mm/s)	1	1	1
	Maximum (mm/s)	2300	4300	4700
Jump Speed	Minimum (mm/s)	1	1	1
	Maximum (mm/s)	2300	4300	4700
Wobbling Width*	Minimum (mm)	0.01	0.01	0.01
	Maximum (mm)	5	5	5
Wobbling Frequency*	Minimum (Hz)	1	1	1
	Maximum (Hz)	1000	1000	1000

* “Wobbling Width” and “Wobbling Frequency” may not work as being set depending on the combination of parameters.

4.2. GWM-STD/STD2-000 (for Fiber Laser Welder)

Lens type		f82	f163
Machining area	(mm)	□20	□94
Starting X-Coord / X-Coordinate	Minimum (mm)	-10	-47
	Maximum (mm)	10	47
Starting Y-Coord / Y-Coordinate	Minimum (mm)	-10	-47
	Maximum (mm)	10	47
Ending X-Coord	Minimum (mm)	-10	-47
	Maximum (mm)	10	47
Ending Y-Coord	Minimum (mm)	-10	-47
	Maximum (mm)	10	47
Central X-Coord	Minimum (mm)	-10	-47
	Maximum (mm)	10	47
Central Y-Coord	Minimum (mm)	-10	-47
	Maximum (mm)	10	47
X-Coor Const Pt	Minimum (mm)	-10	-47
	Maximum (mm)	10	47
Y-Coor Const Pt	Minimum (mm)	-10	-47
	Maximum (mm)	10	47
Radius	Minimum (mm)	-10	-47
	Maximum (mm)	10	47
X Offset / Y Offset	Minimum (mm)	-10	-47
	Maximum (mm)	10	47
Scanning Speed	Minimum (mm/s)	1	1
	Maximum (mm/s)	2300	4600
Jump Speed	Minimum (mm/s)	1	1
	Maximum (mm/s)	2300	4600
Wobbling Width*	Minimum (mm)	0.01	0.01
	Maximum (mm)	5	5
Wobbling Frequency*	Minimum (Hz)	1	1
	Maximum (Hz)	1000	1000

* “Wobbling Width” and “Wobbling Frequency” may not work as being set depending on the combination of parameters.

4.3. GWM-SHG

Lens type		f80
Machining area	(mm)	□35
Starting X-Coord / X-Coordinate	Minimum (mm)	-17.500
	Maximum (mm)	17.500
Starting Y-Coord / Y-Coordinate	Minimum (mm)	-17.500
	Maximum (mm)	17.500
Ending X-Coord	Minimum (mm)	-17.500
	Maximum (mm)	17.500
Ending Y-Coord	Minimum (mm)	-17.500
	Maximum (mm)	17.500
Central X-Coord	Minimum (mm)	-17.500
	Maximum (mm)	17.500
Central Y-Coord	Minimum (mm)	-17.500
	Maximum (mm)	17.500
X-Coor Const Pt	Minimum (mm)	-17.500
	Maximum (mm)	17.500
Y-Coor Const Pt	Minimum (mm)	-17.500
	Maximum (mm)	17.500
Radius	Minimum (mm)	-17.500
	Maximum (mm)	17.500
X Offset / Y Offset	Minimum (mm)	-17.500
	Maximum (mm)	17.500
Scanning Speed	Minimum (mm/s)	1
	Maximum (mm/s)	2300
Jump Speed	Minimum (mm/s)	1
	Maximum (mm/s)	2300
Wobbling Width*	Minimum (mm)	0.01
	Maximum (mm)	5
Wobbling Frequency*	Minimum (Hz)	1
	Maximum (Hz)	1000


* “Wobbling Width” and “Wobbling Frequency” may not work as being set depending on the combination of parameters.

Chapter 6

Outline Drawing

1. Scanner Alone

Dimensions in mm




Output unit, collimator lens and f θ lens are not included in the drawing above.

2. Scanner Head Unit

2.1. GWM-STD/STD2-000 (for YAG Laser Welder f θ : f80 (AS1193162))

Total mass: Approx. 9.6 kg

Dimensions in mm




* For recommended dimensions of the mounting plate, see "Chapter 6-2.8.1. GWM-STD/STD2-000 (f θ : f80/f82/f165/f163) / GWM-SHG (f θ : f80)" (page 34) .

2.2. GWM-STD/STD2-000 (for YAG Laser Welder f θ : f80 (AS1203914))

Total mass: Approx. 9.1 kg

Dimensions in mm




* For recommended dimensions of the mounting plate, see "Chapter 6-2.8.1. GWM-STD/STD2-000 (f θ : f80/f82/f165/f163) / GWM-SHG (f θ : f80)" (page 34) .

2.3. GWM-STD/STD2-000 (for YAG Laser Welder fθ: f150)

Total mass: Approx. 9 kg

Dimensions in mm




* For recommended dimensions of the mounting plate, see "Chapter 6-2.8.2. GWM-STD/STD2-000 (fθ: f150)" (page 34) .

2.4. GWM-STD/STD2-000 (for YAG Laser Welder fθ: f165)

Total mass: Approx. 8.6 kg

Dimensions in mm




* For recommended dimensions of the mounting plate, see "Chapter 6-2.8.1. GWM-STD/STD2-000 (fθ: f80/f82/f165/f163) / GWM-SHG (fθ: f80)" (page 34) .

2.5. GWM-STD/STD2-000 (for Fiber Laser Welder f θ : f82)

Total mass: Approx. 9.6 kg

Dimensions in mm




* For recommended dimensions of the mounting plate, see "Chapter 6-2.8.1. GWM-STD/STD2-000 (f θ : f80/f82/f165/f163) / GWM-SHG (f θ : f80)" (page 34) .

2.6. GWM-STD/STD2-000 (for Fiber Laser Welder f θ : f163)

2.6.1. Fiber Connector D209

Total mass: Approx. 11 kg

Dimensions in mm




* For recommended dimensions of the mounting plate, see "Chapter 6-2.8.1. GWM-STD/STD2-000 (f θ : f80/f82/f165/f163) / GWM-SHG (f θ : f80)" (page 34) .

2.6.2. Fiber Connector QBH

Total mass: Approx. 12 kg


Dimensions in mm



* For recommended dimensions of the mounting plate, see "Chapter 6-2.8.1. GWM-STD/STD2-000 (f0: f80/f82/f165/f163) / GWM-SHG (f0: f80)" (page 34) .

2.6.3. Fiber Connector QBH, with CCD Camera (Option)


Dimensions in mm



* For recommended dimensions of the mounting plate, see "Chapter 6-2.8.1. GWM-STD/STD2-000 (f θ : f80/f82/f165/f163) / GWM-SHG (f θ : f80)" (page 34) .

2.7. GWM-SHG (fθ: f80)

Dimensions in mm




* For recommended dimensions of the mounting plate, see "Chapter 6-2.8.1. GWM-STD/STD2-000 (fθ: f80/f82/f165/f163) / GWM-SHG (fθ: f80)" (page 34) .

2.8. Recommended dimension of the mounting plate

2.8.1. GWM-STD/STD2-000 (fθ: f80/f82/f165/f163) / GWM-SHG (fθ: f80)


Dimensions in mm



fθ	Recommended hole diameter
f80	115
f82	103
f165	120
f163	160

2.8.2. GWM-STD/STD2-000 (fθ: f150)

Dimensions in mm



Chapter 7

Inspection and Parts Replacement

1. Before Inspection and Parts Replacement

This section describes simple maintenance tasks that can be performed by users.

 CAUTION	 Before performing any maintenance tasks, turn OFF the equipment and wait at least five minutes to stop the equipment safely. Touching the equipment interior when it is on may result in electric shock.
--	--

 CAUTION	<ul style="list-style-type: none"> • Use our genuine maintenance parts. • For defect caused by non-genuine maintenance parts or use of non-genuine maintenance parts, the repair is charged even if it is still within the maintenance contract period or the warranty period.
---	--

For optimal performance, we recommend performing annual inspections and comprehensive overhauls once every two years.

For more information, please contact us.

2. Parts Replacement

As user-serviceable parts wear with use, performance will decline, eventually requiring repairs or replacement.

Inspect the unit regularly, referring to the guidelines provided in the following table:

Component		Model No.	Schedule ^{*1} (Recommended)	Maintenance ^{*2}	
f0 lens	GWM-STD/ STD2-000 (for YAG laser welder)	f80 ^{*3}	PO1190918	5 years	Replace
			TSL-1064-40-80- D25		
		f150	TK7J7811P1		
		f165	FT-165		
	GWM-STD/ STD2-000 (for fiber laser welder)	f82	S4LFT0082/328		
		f163	S4LFT2174/328		
GWM-SHG	f80	S4LFT0080/121			

Component			Model No.	Schedule* ¹ (Recommended)	Maintenance* ²
fθ lens protective glass	GWM-STD/ STD2-000 (for YAG laser welder)	f80 * ³	S4LPG081/081	Daily 1 year * ⁴	Clean Replace
			WBK-98-2.5		
		f150	For TK7J7811P1 (FT-150)		
	f165	Protective glass for FT-165			
	GWM-STD/ STD2-000 (for fiber laser welder)	f82	S4LPG0082/328		
		f163	Protective glass for S4LFT2174 (2175)/ 328		
GWM-SHG	f80	S4LPG1081/121			
Scanner unit	GWM-STD/ STD2-000	X motor unit	PO1155776	10 ⁹ seek * ⁵	Replace
		Y motor unit	PO1155778		
	GWM-SHG	X motor unit	PO1155777		
		Y motor unit	PO1155779		

*1 The schedule means the maintenance time or expected life of the part, and is different from the warranty period.

*2 Replace parts when their service lives expire or if they are burned or defective.

*3 The lens and the protective glass for f80 should be the combination of PO1190918 and S4LPG1081/081 or TSL-1064-40-80-D25 and WBK-98-2.5. It is impossible to mount them when they are differently combined.

*4 Depends on the usage of equipment.

*5 The schedule for motor units is defined as the end of the service life of scanner motor bearing. The seek time that the bearing reaches the end of its service life is 1000000000 (ten billion) times. However, the actual schedule differs depending on your layout or operating time. For example, the bearing tends to be worn out quickly for the application like repeating movement in a very small angle at high speed.

3. Protective Glass Inspection and Replacement

The protective glass is designed to prevent the lens from atmospheric dust, spatter from the workpiece, and so on. If dirty, this may lead to laser power loss. Therefore, regular cleaning and replacement is necessary.

Clean or replace if the protective glass becomes dirty.

3.1. Preparation

Have the following ready when cleaning or replacing the protective glass.


- Air blow
- Lens cleaning paper
- Ethanol

3.2. Cleaning the Protective Glass

- 1 Turn OFF the power for the laser welder.
- 2 Blow off foreign particles by using the air blow.
- 3 If the foreign particles cannot be eliminated, apply a few drops of ethanol to the lens cleaning paper. Wipe the protective glass as shown, in a spiraling motion from the center out.

If the ethanol fails to clean the protective glass, replace the protective glass with a new one.

Bottom of scanner head




Wipe in a spiraling motion

3.3. Replacing the Protective Glass

- 1 Turn OFF the power for the laser welder.
- 2 Unscrew to remove the protective glass holder from the scanner head.

Bottom of scanner head




 CAUTION		To avoid damage, be careful to avoid dropping the protective glass.
--	---	---

- 3 Fit a new protective glass into the protective glass holder's stepped section.

 CAUTION		<ul style="list-style-type: none"> • The protective glass may be damaged if it is not properly fitted into the stepped section. • Depending on the protective glass, be careful of its orientation.
--	---	---

Protective glass sectional view



- 4 Reattach the protective glass holder to the scanner head.